

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tiny Land](#) /

› [Tiny Land 56-Piece Wooden Train Set Instruction Manual](#)

Tiny Land WT0003

Tiny Land 56-Piece Wooden Train Set Instruction Manual

Brand: Tiny Land | Model: WT0003

INTRODUCTION

Thank you for choosing the Tiny Land 56-Piece Wooden Train Set. This manual provides essential information for the safe and enjoyable use of your new toy. Designed for children aged 3 to 8 years, this set encourages creativity and imaginative play with its durable wooden tracks, trains, and accessories.



Image: A child engaged in play with the Tiny Land 56-Piece Wooden Train Set, featuring a detailed track layout, a red bridge, a yellow crane, and several wooden trains and figures on a wooden floor.

SAFETY INFORMATION

Please read and understand all safety warnings before use. This product is designed for children aged 36 months to 8 years.

- **Choking Hazard:** Contains small parts. Not suitable for children under 3 years. Adult supervision is recommended.
- **Material Safety:** These toys surpass US safety requirements to ASTM F963 and CPSIA. Tiny Land ensures no mold wood or toxic paint is used, promoting safe and healthy play.
- **Assembly:** Ensure all track pieces are securely connected to prevent accidental detachment during play.



Your Child's Safety is Priority No.1

Image: A young child playing with the wooden train set, highlighting the product's commitment to safety with visible icons indicating BPA-free, non-toxic, eco-friendly, and lead-free materials.

PACKAGE CONTENTS

Your Tiny Land 56-Piece Wooden Train Set includes the following components:

- Wooden Track Pieces (various shapes and sizes)
- Wooden Trains and Cars (with magnetic connectors)
- Magnetic Crane
- Trucks with Removable Cargo
- Bridge
- Wooden Play Figures
- Trees and Signs
- Storage Box

- Instruction Guide (for track layout)



Image: An overhead view of all the components of the 56-piece Tiny Land Wooden Train Set, neatly arranged to show the variety of track pieces, trains, a red bridge, a yellow crane, wooden figures, trees, and traffic signs.

SETUP

Follow these steps to assemble your wooden train set:

1. **Unpack Components:** Carefully remove all pieces from the storage box.
2. **Plan Your Layout:** Refer to the included instruction guide for suggested track layouts, or create your own unique design. The set includes 2 versatile 2-way track pieces for expansion.
3. **Connect Track Pieces:** Join the wooden track segments by aligning the male and female connectors. Ensure each connection is firm and flat to allow smooth train movement.
4. **Assemble Structures:** Place the bridge, crane, and other accessories (houses, trees, signs) around your track layout. The crane can be positioned to interact with the magnetic cargo cars.
5. **Position Trains:** Place the wooden trains and cars onto the tracks. The magnetic connectors allow you to link multiple cars together.

Your browser does not support the video tag.

Video: A demonstration of assembling the Tiny Land Wooden Train Set, showing how track pieces connect and how various accessories

are placed to create a complete railway scene.

OPERATING THE TRAIN SET

Engage in imaginative play with your Tiny Land train set:

- **Train Movement:** Gently push the wooden trains along the tracks. The magnetic connectors ensure cars stay linked during movement.
- **Magnetic Crane:** Use the magnetic crane to lift and move the removable cargo from the trucks and train cars. The crane features 360-degree rotation and up/down movement for interactive play.
- **Creative Scenarios:** Utilize the various figures, trees, and signs to create different play scenarios, fostering storytelling and role-playing.
- **Compatibility:** This set is compatible with other popular wooden toy train brands, allowing for expansion of your child's train world.



Image: A close-up of the yellow magnetic crane, demonstrating its functionality with magnetic cargo pieces. Arrows indicate 360-degree rotation and vertical lifting capabilities.

Your browser does not support the video tag.

Video: A compilation showing various elements of the wooden train set in action, including trains moving on tracks, the crane lifting cargo, and children interacting with the different components.

MAINTENANCE

To ensure the longevity of your Tiny Land Wooden Train Set:

- **Cleaning:** Wipe all wooden pieces with a damp cloth and mild soap if necessary. Avoid harsh chemicals or excessive water, which can damage the wood.
- **Storage:** Store all components in the provided storage box or a dry, cool place away from direct sunlight and extreme temperatures to prevent warping or fading.
- **Inspection:** Periodically inspect all pieces for any signs of wear or damage. Discontinue use if any part is broken or poses a safety risk.

TROUBLESHOOTING

If you encounter any issues with your train set, consider the following:

- **Trains Derailing:** Ensure all track pieces are securely connected and laid on a flat, stable surface. Check for any debris on the tracks.
- **Magnetic Connectors:** If train cars do not connect properly, ensure the magnets are clean and free from obstructions.
- **Missing Pieces:** Refer to the package contents list. If any pieces are missing upon arrival, contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	32 x 20 x 6 inches
Item Weight	4.09 pounds
Model Number	WT0003
Recommended Age	36 months - 8 years
Number of Pieces	56
Material	Wood



Image: A visual representation of the assembled train set on a floor, with arrows indicating its approximate dimensions of 32 inches in length and 20 inches in width.

WARRANTY AND SUPPORT

Tiny Land is committed to providing high-quality products. For any questions, concerns, or support regarding your 56-Piece Wooden Train Set, please contact Tiny Land customer service through the retailer's platform or the official Tiny Land website. Please retain your proof of purchase for any warranty claims.