

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Disney](#) /

› [Disney Grow and Go All-in-One Convertible Car Seat Instruction Manual, Model CC253FER](#)

Disney CC253FER

Disney Grow and Go All-in-One Convertible Car Seat Instruction Manual

Model: CC253FER

INTRODUCTION

This manual provides essential instructions for the safe and proper use of your Disney Grow and Go All-in-One Convertible Car Seat. This versatile car seat is designed to adapt to your child's growth, offering three modes of use: rear-facing for infants, forward-facing for toddlers, and a belt-positioning booster for older children. Please read all instructions carefully before installation and use to ensure maximum safety and comfort for your child. Retain this manual for future reference.



Image: The Disney Grow and Go All-in-One Convertible Car Seat in Simply Mickey design, showcasing its full structure and features.

SETUP AND INSTALLATION

Proper installation is crucial for child safety. This car seat is LATCH-equipped for easy and fast installation. Always refer to your vehicle's owner's manual for specific car seat installation instructions and locations of LATCH anchors.

Installation Modes:

- **Rear-Facing:** For infants weighing 5-40 lbs and measuring 19-40 inches.
- **Forward-Facing:** For toddlers weighing 30-65 lbs and measuring 34.4-49 inches.
- **Belt-Positioning Booster:** For children weighing 40-100 lbs and measuring 43.4-52 inches.

Key Installation Steps:

1. Select the appropriate recline position for the chosen mode (rear-facing, forward-facing). The car seat offers 3 recline positions.
2. Secure the car seat using either the vehicle's LATCH system or the vehicle's seat belt. Do not use both simultaneously unless explicitly instructed by the car seat manual.
3. Ensure the car seat is tightly secured and does not move more than one inch side-to-side or front-to-back at

the belt path.

4. Adjust the harness height to the correct position for your child's shoulders.

3-position recline



Image: Side view of the car seat illustrating its 3-position recline capability, indicated by numbers 1, 2, and 3.

OPERATING INSTRUCTIONS

Harness System:

The QuickFit Harness system allows for one-step adjustment of both the harness and headrest, ensuring a proper fit as your child grows. Always ensure the harness straps are snug against your child's body, and the chest clip is positioned at armpit level.

Harness holders



Easy to get your child in and out of the seat

Image: Close-up of the car seat's harness holders, designed to keep straps open for easy child placement and removal.

Grow-with-Baby Pillows:

The car seat includes grow-with-baby pillow inserts to provide additional comfort and support for smaller infants. These pillows can be easily removed as your child grows and no longer requires the extra padding.



Grow-with-baby pillows

Image: The car seat interior showing the grow-with-baby pillows in place, providing extra cushioning for infants.

Integrated Cup Holders:

Two integrated cup holders are provided for convenience. These are removable for easy cleaning.

2 Integrated cup holders



Image: The car seat featuring its two integrated cup holders on either side of the seat.

Side Impact Protection:

The car seat is designed with side impact protection to enhance safety during collisions.

Side Impact Protection



Image: Top-down view of the car seat highlighting the side impact protection elements near the headrest.

MAINTENANCE AND CARE

Cleaning the Seat Pad:

The seat pad is machine-washable and dryer-safe. It can be removed without detaching the harness, simplifying the cleaning process.



Removable seat pad is machine washable and dryer safe

Image: The car seat with an icon indicating the machine-washable and dryer-safe removable seat pad.

Cleaning Cup Holders:

The integrated cup holders are dishwasher safe for convenient cleaning.

General Care:

- Periodically inspect the car seat for any signs of wear or damage to the harness, buckles, or plastic components.
- Do not use abrasive cleaners or solvents on any part of the car seat.
- Refer to the care labels on the fabric for specific washing instructions.

TROUBLESHOOTING

If you encounter issues with your car seat, please review the following common solutions:

- **Harness not tightening:** Ensure the harness straps are not twisted and are routed correctly through the seat back. Check that the chest clip is unbuckled before attempting to tighten.
- **Car seat feels loose after installation:** Re-read the installation section of this manual and your vehicle's owner's manual. Apply more pressure to the car seat while tightening the LATCH connectors or seat belt. Ensure no more than 1 inch of movement at the belt path.
- **Buckle sticking:** Check for debris in the buckle mechanism. Clean with a damp cloth if necessary. Do not

use lubricants.

- **Child discomfort:** Ensure the harness is adjusted correctly and the grow-with-baby pillows are used or removed as appropriate for your child's size. Check for any tags or fabric folds causing irritation.

If problems persist, contact Disney customer support for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	CC253FER
Product Dimensions	24.5 x 24.25 x 19.25 inches
Item Weight	0.658 ounces (Note: This weight appears to be an error in the source data and should be verified with the manufacturer.)
Material Type	Fabric
Rear-Facing Child Weight	5 - 40 Pounds
Rear-Facing Child Height	19 - 40 Inches
Forward-Facing Child Weight	30 - 65 Pounds
Forward-Facing Child Height	34.4 - 49 Inches
Booster Child Weight	40 - 100 Pounds
Booster Child Height	43.4 - 52 Inches
Harness Type	5-Point
Number of Reclining Positions	3
Installation Type	LATCH



Image: A diagram illustrating the product dimensions: 24.5 inches height, 24.25 inches depth, and 19.25 inches width.

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your product or visit the official Disney Baby website. For customer support, inquiries, or to report any issues, please contact Disney customer service directly.

It is recommended to register your car seat with the manufacturer to receive important safety updates and recall notifications.

	<p>Disney Epic Mickey 2: Przewodnik po grze na Xbox 360</p> <p>Szczegółowy przewodnik po grze Disney Epic Mickey 2 na konsolę Xbox 360. Poznaj sterowanie, umiejętności postaci Mikięgo i Oswalda, mechaniki gry, rodzaje strażników oraz wskazówki dotyczące podróżowania po Pustkowiu.</p>
	<p>Holiday Mickey 23SV24033 Assembly and Operation Instructions</p> <p>Detailed assembly and operation guide for the Disney Holiday Mickey animated figure (Model 23SV24033) by Seasonal Visions International. Includes parts list, setup, troubleshooting, and care instructions for this festive decoration.</p>
	<p>4 FT Animated Mickey Use and Care Guide Disney Holiday Decoration</p> <p>Official use and care guide for the 4 FT Animated Mickey holiday decoration by Disney and Home Accents Holiday. Includes assembly instructions, operation details, parts list, and troubleshooting for model 23SV24033.</p>
	<p>Disney's Hollywood Studios Guide for Guests with Disabilities</p> <p>A comprehensive guide for guests with disabilities visiting Disney's Hollywood Studios, detailing accessibility services, amenities, transportation, dining, shopping, and attraction information.</p>
	<p>Disney Mickey Mouse Waffle Maker WM1-DIM-MM2: Operating and Safety Instructions</p> <p>Comprehensive operating and safety instructions for the Disney Mickey Mouse Waffle Maker (Model WM1-DIM-MM2) by Uncanny Brands. Learn how to safely use, clean, and maintain your waffle maker, with tips and a recipe.</p>
	<p>Setting Up a Disney MagicMobile Pass for iPhone, Apple Watch, and Android Devices</p> <p>Learn how to set up and use your Disney MagicMobile Pass on iPhone, Apple Watch, and Android smartphones with Google Wallet for seamless access to theme parks, Lightning Lane entrances, and more.</p>