

## Remington D5715

# Remington D 5715 Therma Care Pro 2300 Hairdryer User Manual

Model: D5715

Brand: Remington

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not use while bathing or in the shower.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
  - An appliance should never be left unattended when plugged in.
  - Close supervision is necessary when this appliance is used by, on, or near children or invalids.
  - Use this appliance only for its intended household use as described in this manual. Do not use attachments not recommended by the manufacturer.
  - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
  - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
  - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
  - Never use while sleeping.
  - Never drop or insert any object into any opening.
  - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
  - Do not direct hot air towards eyes or other heat-sensitive areas.
  - Attachments may be hot during use. Allow them to cool before handling.
  - Do not place the appliance on any surface while it is operating.

## 2. PRODUCT OVERVIEW

---

The Remington D 5715 Therma Care Pro 2300 Hairdryer is designed for efficient and protective hair drying. It features advanced Therma Care technology to minimize heat damage while delivering powerful performance.

### Key Features:

- **2300W Performance:** Provides fast and powerful drying.
- **Therma Care Technology:** Delivers optimal drying temperature for enhanced heat protection.
- **Ionic Conditioning:** Reduces frizz and static, leaving hair smooth and shiny.
- **Ceramic Ring:** Ensures even heat distribution.
- **Cool Shot Function:** Helps to set your style for long-lasting results.
- **Low Noise Operation:** Designed for a quieter drying experience.

### Components:



The Remington D 5715 Therma Care Pro 2300 Hairdryer shown with the diffuser attachment, ideal for enhancing natural curls and adding volume.



Included accessories: The hairdryer unit, two concentrator nozzles for precise styling, and one diffuser for gentle drying and volume.



Ergonomic design of the Remington D 5715 Hairdryer, demonstrating its comfortable grip and balanced feel during use.

### 3. SETUP

---

1. **Unpacking:** Carefully remove the hairdryer and all accessories from the packaging. Retain packaging for storage or future transport.
2. **Attaching Accessories:** To attach a concentrator or diffuser, align the accessory with the front nozzle of the hairdryer and push it firmly into place until it clicks. To remove, gently pull the accessory off. Ensure the hairdryer is cool before attaching or removing accessories.
3. **Power Connection:** Plug the hairdryer into a standard electrical outlet. Ensure your power supply matches the voltage requirements specified on the appliance.

### 4. OPERATING INSTRUCTIONS

---

Follow these steps for effective and safe use of your Remington D 5715 Hairdryer:

1. **Power On:** Plug the hairdryer into a suitable power outlet.
2. **Select Heat and Speed Settings:** Use the switches on the handle to select your desired heat and speed. This model typically offers multiple heat settings (e.g., low, medium, high) and speed settings (e.g., low, high). Start with a lower heat and speed setting for delicate hair or if you are new to the product.
3. **Direct Airflow:** Direct the airflow towards your hair, maintaining a safe distance to prevent overheating. For general drying, move the hairdryer continuously to avoid concentrating heat in one area.
4. **Using Concentrators:** For precise styling, attach one of the concentrator nozzles. This is ideal for straightening hair or creating specific styles. Direct the concentrated airflow down the hair shaft from roots to ends.
5. **Using the Diffuser:** For enhancing natural curls or adding volume, attach the diffuser. Gently cup sections of your hair with the diffuser, lifting towards the scalp. Use a low heat and speed setting for best results and to prevent frizz.
6. **Cool Shot Function:** Once your hair is almost dry or styled, press and hold the cool shot button to blast a stream of cool air. This helps to set your style and add shine.
7. **Power Off and Unplug:** When you have finished drying or styling your hair, switch the hairdryer off and unplug it from the power outlet. Allow the appliance to cool down before storing.

## 5. MAINTENANCE AND CLEANING

---

Regular maintenance ensures optimal performance and extends the life of your hairdryer.

- **Cleaning the Air Filter:** The rear filter grille should be cleaned regularly to prevent lint and hair buildup, which can affect performance and cause overheating. Ensure the hairdryer is unplugged and cool. Gently twist or pull off the rear grille (refer to diagram in full manual if available). Use a soft brush or cloth to remove any accumulated dust or hair. Replace the grille securely.
- **General Cleaning:** Wipe the exterior of the hairdryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, unplug the appliance. Allow it to cool down completely before storing. Do not wrap the cord around the hairdryer, as this can damage the cord. Use the hanging loop for convenient storage. Store in a cool, dry place, out of reach of children.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Hairdryer does not turn on.	Not plugged in correctly; no power from outlet; internal fault.	Ensure plug is fully inserted. Check power outlet with another appliance. If still no power, contact customer support.
Low airflow or weak performance.	Blocked air intake filter.	Unplug and clean the rear air filter grille as described in the Maintenance section.

Problem	Possible Cause	Solution
Hairdryer overheats and shuts off.	Blocked air intake/outlet; prolonged use on high heat.	Unplug and allow to cool for several minutes. Clean the air filter. Ensure air vents are not blocked during use. Reduce heat/speed settings if used for extended periods.
Unusual noise or smell.	Internal issue; foreign object.	Immediately unplug the hairdryer. Do not use. Contact customer support for assistance.

## 7. SPECIFICATIONS

---

- **Model Name:** D 5715 Therma Care Pro 2300
- **Model Number:** D5715
- **Power:** 2300W (Performance) / 2100W (Rated)
- **Material:** Ceramic
- **Color:** Black
- **Dimensions (L x W x H):** Approximately 20.4 x 9 x 28.8 cm
- **Weight:** Approximately 520 grams
- **Special Features:** Ion generator, Ceramic ring, Cool shot function, Diffuser, Narrow styling nozzle, Hanging loop
- **Included Components:** 2 Concentrators, 1 Diffuser
- **Power Source:** Corded Electric
- **Recommended Hair Type:** Thick

## 8. WARRANTY AND SUPPORT

---

This Remington product is manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Remington website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Remington customer service.

**Remington Official Website:** [www.remingtonproducts.com](http://www.remingtonproducts.com)