vhbw VHBW4062692057348

vhbw Microfilter Instruction Manual

Introduction

This manual provides instructions for the installation, maintenance, and care of your vhbw microfilter, designed for Miele T 8626 WP EcoComfort and T 8627 WP EcoComfort dryers. The microfilter plays a crucial role in maintaining the efficiency and longevity of your dryer by capturing lint and dust, preventing them from accumulating in the heat exchanger. Regular maintenance of the filter ensures optimal drying performance and energy consumption.

Package Contents

- 1x vhbw Microfilter

Compatibility

This vhbw microfilter is compatible with the following Miele dryer models:

- Miele T 8626 WP EcoComfort
- Miele T 8627 WP EcoComfort

It serves as a replacement for original part number **07070070**.

Setup and Installation

To install the microfilter, follow these general steps. Always refer to your dryer's original instruction manual for specific access panel locations and safety precautions.

1. **Power Off:** Ensure your dryer is unplugged from the power outlet before beginning any installation or maintenance.
2. **Locate Filter Compartment:** Identify the filter compartment, typically located at the bottom front of the dryer, often behind a removable panel or flap.
3. **Remove Old Filter:** Carefully remove the existing microfilter. Note its orientation for correct installation of the new filter.
4. **Insert New Filter:** Place the new vhbw microfilter into the compartment, ensuring it fits snugly and is correctly oriented.
5. **Secure Compartment:** Close and secure the filter compartment panel.
6. **Restore Power:** Plug the dryer back into the power outlet.




Image: Angled view of the vhbw microfilter, showing its overall shape and texture.

Operating Instructions

Once installed, the microfilter operates automatically as part of your dryer's filtration system. It continuously filters the air during the drying cycle, preventing lint and dust from reaching the heat exchanger and other internal components. No specific user interaction is required during operation beyond ensuring the filter is correctly installed and regularly maintained.

Maintenance

Regular cleaning and timely replacement of the microfilter are essential for maintaining your dryer's performance and energy efficiency.

Cleaning the Microfilter

The vhbw microfilter is washable. It is recommended to clean the filter regularly, ideally after every few drying cycles or when you notice a decrease in drying performance.

1. **Remove Filter:** Power off and unplug the dryer. Carefully remove the microfilter from its compartment as described in the Setup section.
2. **Rinse:** Rinse the filter under running water to remove accumulated lint and dust. You may use a soft brush if necessary to dislodge stubborn debris.
3. **Dry:** Allow the filter to air dry completely before reinserting it into the dryer. Ensure no moisture remains, as this can affect dryer operation.
4. **Reinstall:** Once dry, reinstall the filter and secure the compartment panel. Restore power to the dryer.




Image: Top-down view of the vhbw microfilter, illustrating the surface to be cleaned.

Filter Replacement

Even with regular cleaning, filters can degrade over time. Replace the microfilter if:

- Cleaning no longer restores optimal performance.
- The filter material shows signs of damage, such as tears or excessive wear.
- Your dryer's performance significantly decreases despite regular cleaning.

The frequency of replacement depends on usage, but generally, replacing the filter every 6-12 months is a good practice to ensure continued efficiency.

Troubleshooting

If you experience issues with your dryer's performance after installing the vhbw microfilter, consider the following:

- **Reduced Drying Performance:** This is often an indication that the microfilter is clogged. Remove and clean the filter thoroughly. Ensure it is completely dry before reinstallation.
- **Unusual Noises:** Check that the filter is correctly seated in its compartment. A loose filter can cause vibrations or rattling noises.
- **Error Codes:** If your dryer displays an error code related to filtration or airflow, first clean or replace the microfilter. If the issue persists, consult your dryer's original manual or contact a qualified technician.

Always ensure the dryer is unplugged before inspecting or handling the filter.

Specifications

Feature	Detail
Brand	vhbw

Feature	Detail
Model Number	VHBW4062692057348
Color	Black
Material	Foam rubber
Dimensions (L x W x H)	22 x 13.5 x 3 cm (8.66 x 5.31 x 1.18 inches)
Weight	17 g (0.6 oz)
Washable	Yes




Image: Close-up view of the foam rubber material of the vhbw microfilter.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question