

[Manuals.plus](#) /

› [Philips](#) /

› Philips Pro Wired Earbuds (Model: B07TDS4SG1) Instruction Manual

Philips B07TDS4SG1

Philips Pro Wired Earbuds (Model: B07TDS4SG1)

Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the Philips Pro Wired Earbuds, Model B07TDS4SG1. These in-ear headphones are designed for high-fidelity audio reproduction and feature a 3.5mm audio jack, a built-in microphone, and passive noise isolation. Please read this manual carefully to ensure proper use and maintenance of your earbuds.

WHAT'S IN THE BOX

Upon opening the package, verify that all components are present:

- Philips Pro Wired Earbuds
- Eartips (Small, Medium, Large sizes)



Image: A pair of Philips Pro Wired Earbuds, featuring a metallic finish on the earbud housing, a black cable, and a 3.5mm audio jack with an in-line microphone control.

SETUP

1. Selecting the Right Eartips

The earbuds come with three sizes of silicone eartips (Small, Medium, Large). Choosing the correct size is crucial for comfort, sound quality, and effective passive noise isolation.

1. Experiment with each size to find the one that creates a snug seal in your ear canal.
2. A good seal will block out external noise and provide optimal bass response.
3. If the eartips feel loose or uncomfortable, try a different size.



Image: An illustration showing a Philips Pro Wired Earbud correctly fitted in an ear, alongside three different sizes (S, M, L) of interchangeable ear tips.



Image: A close-up view of three black silicone ear tips in small, medium, and large sizes, designed for a comfortable and secure fit.

2. Connecting to Your Device

These earbuds connect via a standard 3.5mm audio jack.

1. Locate the 3.5mm audio port on your smartphone, tablet, laptop, or other compatible audio device.
2. Insert the 3.5mm jack firmly into the audio port until it clicks into place.
3. Ensure the connection is secure to prevent audio interruptions.

OPERATING INSTRUCTIONS

In-line Remote and Microphone

The earbuds feature an in-line remote with a built-in microphone for convenient control of audio playback and calls.

- **Play/Pause Music:** Press the button once to play or pause the current track.
- **Answer/End Calls:** Press the button once to answer an incoming call or end an active call.
- **Volume Control:** The in-line remote includes volume control functionality. Adjust the slider or buttons (if present) to increase or decrease audio volume.
- **Voice Assistant:** On some devices, a long press may activate the device's voice assistant.

For optimal microphone performance, ensure the microphone is positioned clearly and not obstructed.

COMFORT AND FIT

The Philips Pro Wired Earbuds are designed for extended wear with maximum comfort.

- The rounded earpiece shape is engineered to fit comfortably within the ear canal, reducing pressure points.
- Properly selected eartips create a secure fit that minimizes ear fatigue during long listening sessions.
- The snug fit also contributes to passive noise isolation, reducing ambient sounds without requiring active noise cancellation technology.

AUDIO QUALITY

These earbuds deliver high-resolution audio for a detailed listening experience.

- **Drivers:** Equipped with high-powered 8.6mm neodymium drivers for clear and dynamic sound.
- **Frequency Response:** A wide frequency range of 7 Hz to 40,000 Hz ensures reproduction of both deep bass and crisp high frequencies.
- **Hi-Res Audio:** Capable of reproducing audio at higher sampling rates than standard CDs, providing a more accurate and detailed sound.

MAINTENANCE

To ensure the longevity and optimal performance of your Philips Pro Wired Earbuds, follow these maintenance guidelines:

- **Cleaning Eartips:** Regularly remove the silicone eartips and clean them with a soft, damp cloth. Allow them to dry completely before reattaching.
- **Cleaning Earbuds:** Gently wipe the earbud housing with a dry, soft cloth. Avoid using harsh chemicals or abrasive materials.
- **Cable Care:** The cable is designed to be tangle-resistant. Avoid sharp bends or excessive pulling on the cable. When storing, coil the cable loosely.

- **Storage:** Store the earbuds in a clean, dry place, away from extreme temperatures and direct sunlight.
- **Water Resistance:** The product is rated as waterproof. However, avoid prolonged submersion or exposure to high-pressure water jets to prevent damage.

TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common problems and solutions:

Problem	Solution
No sound or intermittent sound	Ensure the 3.5mm jack is fully inserted into the device's audio port. Check the volume level on your device and on the in-line remote. Test the earbuds with another audio device to rule out a device-specific issue. Inspect the cable for any visible damage or kinks.
Poor sound quality (e.g., lack of bass, muffled sound)	Ensure the eartips create a proper seal in your ear canal. Try different eartip sizes. Clean the eartips and the earbud nozzles to remove any debris that might be obstructing sound. Verify the audio source is of good quality.
Microphone not working	Ensure the 3.5mm jack is fully inserted. Some devices require a TRRS jack for microphone functionality. Check your device's audio settings to ensure the external microphone is selected. Test the microphone with another device or application.

SPECIFICATIONS

Feature	Detail
Model Name	B07TDS4SG1
Brand	Philips
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Sound Isolation (Passive)
Frequency Range	7 Hz - 40,000 Hz
Impedance	16 Ohm
Audio Driver Type	Dynamic Driver
Audio Driver Size	8.6 Millimeters

Feature	Detail
Control Type	Volume Control, Microphone Feature
Cable Feature	Tangle-resistant
Item Weight	1.6 Ounces (approx. 45g)
Water Resistance Level	Waterproof
Compatible Devices	Devices with a 3.5mm audio jack (laptops, desktops, tablets, cellphones)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Philips support website. Keep your proof of purchase for warranty claims.

Online Support: www.philips.com/support

© 2023 Philips. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07TDS4SG1>

More documents and user manuals: <https://manuals.plus/>