

BlitzWolf BW-AS1

BlitzWolf BW-AS1 Wireless Bluetooth Speaker User Manual

Model: BW-AS1

1. INTRODUCTION

The BlitzWolf BW-AS1 is a high-fidelity wireless Bluetooth speaker designed to deliver clear, balanced audio. Featuring dual drivers and a robust battery, it offers versatile connectivity options including Bluetooth 4.0 and a 3.5mm AUX-in port, along with hands-free calling capabilities.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1x BlitzWolf BW-AS1 Wireless Bluetooth Speaker
- 1x USB Charging Cable
- 1x 3.5mm Audio Cable
- 1x User Manual

3. PRODUCT OVERVIEW




Figure 3.1: Top Panel Controls

This image displays the top surface of the BlitzWolf BW-AS1 speaker, highlighting the power button, play/pause button, and volume control buttons.



Figure 3.2: Rear Panel Ports

This image shows the back of the BlitzWolf BW-AS1 speaker, indicating the DC 5V charging port and the AUX-in port.

Button Functions:

- **Power Button:** Press and hold to power on/off. Short press to switch modes (Bluetooth/AUX).
- **Play/Pause Button:** Short press to play or pause music. During a call, short press to answer/end, long press to reject.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Volume Up (+):** Short press to increase volume. Long press for next track.

4. SETUP

4.1 Charging the Speaker

1. Connect the provided USB charging cable to the DC 5V port on the speaker.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. A full charge takes approximately 3.5 hours.
4. Once fully charged, the indicator light will change or turn off (refer to specific LED behavior in the next section).

4.2 Powering On/Off

- To power on, press and hold the **Power Button** until you hear an audible prompt.
- To power off, press and hold the **Power Button** again until you hear an audible prompt.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED, typically blue). If not, short press the **Power Button** to switch modes.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices. You should see "BW-AS1" in the list.
4. Select "BW-AS1" to connect. Once paired, the speaker will emit an audible confirmation, and the LED indicator will become solid blue.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

5.2 AUX-in Mode

1. Connect one end of the provided 3.5mm audio cable to the AUX-in port on the speaker.
2. Connect the other end of the 3.5mm audio cable to the audio output jack of your device (e.g., smartphone, MP3 player, computer).
3. The speaker will automatically switch to AUX-in mode, or you may need to short press the **Power Button** to cycle to AUX mode.
4. Audio will now play through the speaker from your connected device. Volume can be controlled via both the speaker and the connected device.

5.3 Hands-Free Calling

- When a call comes in while connected via Bluetooth, the music will pause.
- Short press the **Play/Pause Button** to answer the call.
- To end the call, short press the **Play/Pause Button** again.
- To reject an incoming call, long press the **Play/Pause Button**.

6. MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or high humidity.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Do not attempt to disassemble or repair the speaker yourself, as this will void the warranty and may cause damage.

7. TROUBLESHOOTING







Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the USB cable.


Problem	Possible Solution
Cannot pair via Bluetooth.	<ul style="list-style-type: none">• Ensure the speaker is in Bluetooth pairing mode (flashing LED).• Make sure Bluetooth is enabled on your device.• Move the speaker closer to your device (within 10 meters).• Forget "BW-AS1" from your device's Bluetooth list and try pairing again.• Restart both the speaker and your device.
No sound in AUX mode.	<ul style="list-style-type: none">• Ensure the 3.5mm audio cable is securely connected to both the speaker and your device.• Verify that the speaker is in AUX mode (short press Power Button to cycle modes).• Check the volume levels on both the speaker and your connected device.• Test with a different 3.5mm audio cable if available.
Poor sound quality.	<ul style="list-style-type: none">• Ensure the speaker is within the effective Bluetooth range (10m) and there are no obstructions.• Check the audio source quality.• Try adjusting the volume on both the speaker and the connected device.

8. SPECIFICATIONS

Brand	BlitzWolf
Model	BW-AS1
Material	Aluminum alloy + PC
Dimensions	2.5 x 2.5 x 8.1 inches (approx.)
Microphone	Yes (Built-in)
Connectivity	Bluetooth / 3.5mm AUX-in
Bluetooth Version	V4.0
Transmission Distance	Up to 10 meters (33 feet)
Output Power	2 x 10W (Total 20W)
Frequency Response	20Hz - 20kHz
Battery Capacity	5200mAh (2 x 2600mAh, 3.7V)
Charging Time	Approximately 3.5 hours
Working Time	7-11 hours (at 70% volume)
Waterproof	TRUE (as per specifications)

Related Documents - BW-AS1

	<p>BlitzWolf BW-IS20 User Manual and Quick Start Guide</p> <p>Comprehensive user manual and quick start guide for the BlitzWolf BW-IS20 smart device, covering product features, installation, setup, operation, and troubleshooting.</p>
	<p>BlitzWolf BW-WD3 Wireless Charger User Manual</p> <p>Comprehensive user manual for the BlitzWolf BW-WD3 wireless charger, detailing features, specifications, operation, safety, and troubleshooting. Learn how to use your BW-WD3 effectively.</p>
	<p>BlitzWolf BW-VP13 1080p WiFi Projector User Manual</p> <p>User manual for the BlitzWolf BW-VP13 1080p WiFi Projector, covering function overview, quick start, wired and wireless projection methods, input sources, projection distance and screen size, product specifications, and troubleshooting.</p>
	<p>BlitzWolf BW-VC3 Robot Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the BlitzWolf BW-VC3 Robot Vacuum Cleaner, covering setup, operation, maintenance, and troubleshooting. Learn how to get the most out of your automated cleaning device.</p>
	<p>BlitzWolf BW-CDW1 User Manual</p> <p>User manual for the BlitzWolf BW-CDW1, providing instructions and specifications for its operation.</p>
	<p>BlitzWolf BW-BTS8 User Manual</p> <p>User manual for the BlitzWolf BW-BTS8 earphones, detailing specifications, wearing method, features, basic operations, button functions, and FCC compliance.</p>




[\[pdf\]](#) Test Report

Measurement Report Kent Test Tong De Limited Company BW AS1 Bluetooth Speaker 2AOGN

2AOGNBWAS1 bw as1

S T S L A B RADIO TESTREPORT Report No: STS1712253W01 Issued for Tong De Limited Company BR.VIRGIN ISLANDS, Palm Grove House, P.O.Box 438, Road Town, Tortola, VG Product Name: Bluetooth Speaker Brand Name: BlitzWolf Model Name: **BW-AS1** Series Model: N/A FCC ID: 2AOGN**BW-AS1** Test Standard: FCC Part 1...

lang:en score:28 filesize: 2.57 M page_count: 71 document date: 2018-01-08



[\[pdf\]](#) Test Report

Measurement Report Kent Test Tong De Limited Company BW AS1 Bluetooth Speaker 2AOGN

2AOGNBWAS1 bw as1

S T S L A B RADIO TESTREPORT Report No: STS1712253W01 Issued for Tong De Limited Company BR.VIRGIN ISLANDS, Palm Grove House, P.O.Box 438, Road Town, Tortola, VG Product Name: Bluetooth Speaker Brand Name: BlitzWolf Model Name: **BW-AS1** Series Model: N/A FCC ID: 2AOGN**BW-AS1** Test Standard: FCC Part 1...

lang:en score:28 filesize: 2.57 M page_count: 71 document date: 2018-01-08