

[Manuals.plus](#) /

› [Realspace](#) /

› Realspace Torval Big & Tall Bonded Leather High-Back Office Chair Instruction Manual

Realspace Torval

Realspace Torval Big & Tall Bonded Leather High-Back Office Chair

MODEL: TORVAL

Product Overview

The Realspace Torval Big & Tall Bonded Leather High-Back Computer Office Chair is designed for comfort and support in an office environment. Featuring a bonded leather exterior and a high-back design with a waterfall seat cushion, this chair provides a comfortable seating experience. Constructed with a durable nylon and steel frame, it offers reliable support for users up to 400 lbs. This product is BIFMA Compliant, ensuring it meets rigorous performance and safety standards.

Safety Information

Always read and follow all assembly instructions and safety warnings before using this product. Failure to do so may result in injury or damage to the product. Keep all small parts away from children.

Package Contents

Before beginning assembly, ensure all components are present and undamaged. Refer to the detailed assembly instructions included in the packaging for a complete list of parts. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Setup and Assembly

Assembly of the Realspace Torval chair requires careful attention to the included instructions. It is recommended to have two people for certain steps, particularly when attaching the seat back to the seat base, to ensure proper alignment and secure fastening. Lay out all parts on a soft, clean surface to prevent scratching.

Key Assembly Steps:

1. Attach the casters to the chair base.

2. Insert the gas lift cylinder into the center of the chair base.
3. Secure the armrests to the seat cushion.
4. Attach the backrest to the seat cushion and armrests.
5. Place the assembled seat onto the gas lift cylinder.

Refer to the detailed assembly instructions provided in your product packaging for step-by-step illustrations and specific hardware requirements.



Figure 1: Realspace Torval Chair Dimensions. This diagram illustrates the overall dimensions of the chair, including height, width, and depth measurements.

Operating Instructions

The Realspace Torval chair offers several adjustable features to customize your seating experience:

- **Seat Height Adjustment:** Locate the lever on the right side beneath the seat. Pull the lever up to raise the seat. To lower, remain seated and pull the lever up. Release the lever at the desired height.
- **Tilt Lock and Tension:** The same lever used for height adjustment can also lock the chair in an upright position. Push the lever in to lock the tilt, pull it out to allow tilting. The tilt tension knob, located at the front center under the seat, can be rotated to adjust the resistance when reclining. Turn clockwise for more resistance, counter-clockwise for less.
- **Armrest Adjustment:** The padded armrests can be adjusted for height and can also pivot upwards to allow closer access to a desk or for easier entry/exit. Locate the buttons or levers on the armrest supports to make these adjustments.
- **Headrest Adjustment:** The integrated headrest moves up or down to provide optimal support for your head and neck. Adjust as needed for comfort.



Figure 2: Front view of the Realspace Torval chair, showcasing its high-back design and padded armrests.



Figure 3: Side view demonstrating the adjustable armrests, which can be raised for convenience.

Maintenance

To maintain the appearance and longevity of your Realspace Torval chair, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the bonded leather and other materials.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Caster Care:** Keep casters free of debris to ensure smooth movement.



Figure 4: Close-up of the chair's seat and armrest, showing material detail. Regular cleaning helps preserve the bonded leather.

Troubleshooting

If you encounter issues with your Realspace Torval chair, consider the following:

- **Chair Wobbles:** Ensure all assembly bolts are securely tightened. Check that the chair is on a flat, even surface.
- **Difficulty Adjusting Height:** Verify that the gas lift cylinder is correctly installed and not obstructed. If the issue persists, the gas lift may need replacement.
- **Casters Not Rolling Smoothly:** Inspect casters for trapped hair or debris and clean as necessary.
- **Squeaking Noises:** Apply a small amount of silicone lubricant to moving parts or connection points, avoiding contact with upholstery.

For persistent issues, contact customer support.

Specifications

Brand	Realspace
Model Name	Torval
Color	Black/Silver
Material	Bonded Leather, Nylon, Alloy Steel (Frame), Foam (Fill)
Product Dimensions (D x W x H)	33.86" x 17.32" x 27.56"
Item Weight	54.02 Pounds
Maximum Weight Recommendation	400 Pounds
Compliance	ANSI/BIFMA Compliant
Care Instructions	Wipe Clean

Warranty and Support

The Realspace Torval Big & Tall Bonded Leather High-Back Computer Office Chair is backed by the manufacturer's 5-year limited warranty. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or to order replacement parts, please contact Realspace customer service. Refer to your purchase documentation for specific contact details or visit the official Realspace website.