

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Decathlon](#) /

› [Pongori TTR 100 3* All - Round School Table Tennis Bat User Manual](#)

Decathlon 2697567

Pongori TTR 100 3* All - Round School Table Tennis Bat User Manual

Brand: Decathlon | Model: 2697567

INTRODUCTION

This manual provides essential information for the proper use, maintenance, and care of your Pongori TTR 100 3* All-Round School Table Tennis Bat. Designed for beginners and school use, this bat helps in learning to add spin while maintaining ball control, making it ideal for your first rallies.

PRODUCT OVERVIEW

What's in the Box

- 1 x Pongori TTR 100 Table Tennis Bat

Note: Balls are not included with the bat.

Key Features

- Enables control over opponent's balls for precise placement.
- Tacky surface allows for fast spin application.
- Aids in limiting opponent's reaction time.
- Durable construction with 100% wood bat and EVA protection cover.



Image: Two Pongori TTR 100 table tennis bats (one red, one black) and three orange table tennis balls. This image illustrates the typical appearance of the product and associated accessories, though balls are sold separately.

SETUP

The Pongori TTR 100 table tennis bat comes pre-assembled and ready for immediate use. No complex setup or assembly is required.

- 1. Unpacking:** Carefully remove the bat from its packaging.
- 2. Inspection:** Inspect the bat for any visible damage or defects. If any issues are found, contact customer support.
- 3. Ready to Play:** The bat is now ready for use with standard table tennis balls and a table.



Image: Front view of a single Pongori TTR 100 table tennis bat with red rubber. This shows the ready-to-use state of the bat.

OPERATING INSTRUCTIONS

The Pongori TTR 100 bat is designed for all-round play, focusing on control and spin. Here are general guidelines for effective use:

- **Grip:** Hold the bat firmly but comfortably. The handle is designed for a natural grip, allowing for wrist flexibility.
- **Spin Control:** The tacky rubber surface allows for imparting spin on the ball. For topspin, brush upwards on the ball. For backspin, brush downwards.
- **Ball Control:** Focus on the angle of the bat face upon impact to direct the ball accurately. The bat's design aids in controlling the ball's trajectory.
- **Practice:** Consistent practice is key to mastering control and spin with this bat.



Image: A young person playing table tennis with the Pongori TTR 100 bat. This illustrates the bat in active use during a game.

MAINTENANCE

Proper maintenance will extend the life and performance of your table tennis bat.

- **Cleaning the Rubber:** After each use, gently wipe the rubber surface with a damp, soft cloth to remove dust and sweat. Avoid harsh chemicals or abrasive materials, as they can damage the rubber.
- **Storage:** Store the bat in a cool, dry place, away from direct sunlight and extreme temperatures. Using a bat cover (not included) is recommended to protect the rubber from dust and damage.
- **Handle Care:** Keep the wooden handle dry. If it becomes dirty, wipe it with a slightly damp cloth and dry immediately.
- **Avoid Impact:** Do not drop the bat or hit it against hard surfaces, as this can damage the wood blade or rubber.



Image: Angled close-up view of the red rubber and wooden blade edge of the bat. This highlights the rubber surface that requires regular cleaning.

TROUBLESHOOTING

This section addresses common concerns you might encounter with your table tennis bat.

Problem	Possible Cause	Solution
Reduced Spin/Tackiness	Dust, dirt, or oil buildup on the rubber surface.	Clean the rubber surface with a damp, soft cloth. For stubborn dirt, use a specialized table tennis rubber cleaner.
Rubber Peeling/Bubbling	Exposure to extreme temperatures, improper storage, or excessive moisture.	Ensure proper storage in a cool, dry place. If damage is significant, the rubber may need replacement (professional service recommended).
Handle feels slippery	Sweat or dirt on the handle.	Wipe the handle with a dry or slightly damp cloth. Ensure hands are clean and dry before playing.

SPECIFICATIONS

Attribute	Detail
Model Name	TTR 100 3* All-Round School Table Tennis Bat
Model Number	2697567
Brand	Decathlon (Pongori)
Skill Level	Beginner
Bat Composition	100% Wood

Attribute	Detail
Protection Cover Material	50% Ethylene Vinyl Acetate (EVA)
Sport	Table Tennis
Size	One Size
Item Weight	220 g
Age Range	Adult

WARRANTY AND SUPPORT

The Pongori TTR 100 Table Tennis Bat comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use conditions.

Warranty Exclusions:

- Damage caused by misuse, abuse, or neglect.
- Normal wear and tear, including rubber degradation over time.
- Damage from unauthorized repairs or modifications.
- Damage due to improper storage or exposure to extreme conditions.

Customer Support:

For warranty claims, technical assistance, or any product-related inquiries, please contact Decathlon customer service through their official website or the retailer where the product was purchased. Please have your proof of purchase and product model number (2697567) ready when contacting support.