

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PURPLE LEAF](#) /

› [PURPLE LEAF 2-Seat Deluxe Outdoor Patio Porch Swing Instruction Manual \(Model: B07TGHVR9V\)](#)

PURPLE LEAF B07TGHVR9V

PURPLE LEAF 2-Seat Deluxe Outdoor Patio Porch Swing Instruction Manual

Model: B07TGHVR9V

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Failure to follow these instructions may result in serious injury.

- Ensure all parts are present and undamaged before assembly.
- Assemble the swing on a flat, stable surface.
- Do not overtighten bolts during initial assembly; tighten fully only when instructed.
- Maximum weight capacity: 600 lbs (2 people). Do not exceed this limit.
- Keep children and pets away from the assembly area.
- Regularly inspect all bolts and connections to ensure they are secure.
- Do not use the swing during strong winds or severe weather conditions.
- Always ensure the canopy is securely locked in position when in use.

PACKAGE CONTENTS

Verify all components are included before beginning assembly. Refer to the assembly diagram for part identification.

Your browser does not support the video tag.

Video: Porch Swing Installation Overview. This video provides a visual guide to the assembly process, including identifying parts and initial setup steps.

The package includes the main frame components, seat, canopy, cushions, and hardware. Ensure you have all necessary screws, bolts, and tools as specified in the manual.

SETUP AND ASSEMBLY

Assembly typically requires two adults. Follow the steps below carefully.

Step 1: Assemble the Main Frame

1. Connect the base bars (B1 and B2) using the provided screws.
2. Attach the side support bars (A1 and A2) to the base. Ensure the correct orientation for each piece.
3. Secure the side panels (D) to the main frame using the designated bolts.

Your browser does not support the video tag.

Video: Porch Swing Installation. This video demonstrates the step-by-step assembly of the swing's main frame and components.

Step 2: Install the Seat and Armrests

1. Attach the seat frame to the hanging chains.
2. Secure the armrests to the seat frame using the adjustable knobs.
3. Ensure the springs are correctly attached for proper swinging motion.




Image: Heavy-duty spring mechanism for smooth swinging.

Step 3: Attach the Canopy

1. Slide the canopy fabric onto the canopy frame.
2. Attach the canopy frame to the main swing frame, securing it with the adjustment knobs.
3. Adjust the canopy tilt as desired.




Image: Detail of the 240G yarn-dyed fabric, highlighting its water-repellent, UV rays protection, and premium colorfast material properties.

OPERATING INSTRUCTIONS

Adjusting the Canopy

The canopy features an adjustable tilt mechanism. Loosen the knobs on both sides of the canopy frame, adjust to the desired angle for optimal shade, and then tighten the knobs to secure it in place.

Your browser does not support the video tag.

Video: Patio Porch Swing with Canopy. This video demonstrates the adjustable canopy feature, showing how to tilt it for sun protection.

Using the Foldable Side Tables

The swing includes two foldable side tables. To use, simply pull the table outwards until it locks into a horizontal position. These tables are designed to hold drinks, mobile phones, or small items. To fold away, release the locking mechanism and push the table back against the frame.



Foldable Tray

Place drinks, phone or other small items.

Image: Foldable side table in use, showing space for drinks and a phone.

Converting to a Lay-Flat Bed

This swing can be converted into a lay-flat bed. Locate the adjustment mechanisms on the sides of the seat. Release the locks and gently recline the backrest until it is flat, aligning with the seat. Secure the mechanism to hold the bed position. To return to the upright position, reverse the process.

Your browser does not support the video tag.

Video: Outdoor Patio Swing. This video showcases the swing's features, including its ability to convert into a lay-flat bed for relaxation.

MAINTENANCE

- **Cleaning:** Wipe the steel frame with a damp cloth and mild soap. The cushions are made from water-repellent fabric and can be spot cleaned. For deeper cleaning, the cushion covers are removable via zippers.
- **Weather Protection:** The fabric is UV resistant and fade resistant. For prolonged lifespan, especially during harsh weather or off-season, consider using a protective cover or storing cushions indoors.
- **Inspection:** Periodically check all nuts, bolts, and connections to ensure they remain tight and secure.

Velcro Paste Design

Ensuring that the cushions & backrest remain securely in place.



Image: Velcro straps on cushions to keep them securely in place on the metal seat, preventing sliding.

TROUBLESHOOTING

- Squeaking Noise:** If the swing makes a squeaking noise, apply a small amount of lubricant to the spring hooks and pivot points.
- Unstable Swing:** Ensure all bolts are tightened correctly. Verify the swing is placed on a level surface.
- Canopy Adjustment Issues:** Check that the adjustment knobs are fully loosened before attempting to tilt the canopy. Ensure no fabric is caught in the mechanism.

SPECIFICATIONS

Feature	Detail
Model	B07TGHVR9V
Brand	PURPLE LEAF
Product Dimensions	49.2"D x 61.4"W x 67.3"H
Seating Capacity	2-seater
Frame Material	Alloy Steel
Finish Type	Powder Coated
Cushion Material	Polyester (Yarn-Dyed, UV/Fade/Water-Resistant)
Weight Capacity	600 lbs
Item Weight	73.5 pounds
UPC	611550863771

Product Size Information



Image: Detailed product dimensions for the 2-seat porch swing.

WARRANTY AND SUPPORT

For warranty information or customer support, please contact PURPLE LEAF directly. Refer to the product packaging or the official PURPLE LEAF website for contact details.

Note: This product is sold by PurpleLeafLeisureLife and offers 30-day easy returns.

Visit the [PURPLE LEAF Store](#) for more products and information.