

Midland C1285

Midland Street Guardian Dual C1285 Dash Camera User Manual

Model: C1285 | Brand: Midland

1. INTRODUCTION

The Midland Street Guardian Dual C1285 is a dual dash camera system designed to record events both outside and inside your vehicle. It features Full HD 1080p recording, a 160° wide-angle lens, night vision capabilities, continuous loop recording, motion detection, and integrated GPS for location tracking. This device serves as a reliable witness for incidents on the road.

Key Features:

- Dual Recording:** Simultaneously captures footage from both the front and interior of the vehicle.
- Full HD 1080p Resolution:** Provides clear and detailed video recordings.
- 160° Wide-Angle Lens:** Offers an expansive view of the road and cabin.
- Night Vision Technology:** Enhances recording clarity in low-light conditions.
- Continuous Loop Recording:** Automatically overwrites older footage when the memory card is full, ensuring uninterrupted recording.
- Motion Detection:** Initiates recording when movement is detected, useful for parking surveillance.
- Integrated GPS:** Records location and speed data, providing a detailed travel log.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Midland Street Guardian Dual C1285 Dash Camera
- Suction Cup Mount with Integrated GPS
- 12V Cigarette Lighter Power Cable (3.4m)
- USB to Mini-USB Cable (for PC connection)
- User Manual (this document)



Image: The Midland Street Guardian Dual C1285 dash camera, suction cup mount, 12V car charger cable, and USB cable.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your dash camera.



Image: A close-up front view of the Midland Street Guardian Dual C1285 dash camera, highlighting its cylindrical design and front lens.



Image: The rear view of the dash camera showing the 1.5-inch display screen, control buttons (Power, OK, Menu, Up/Down), and the interior-facing camera lens, attached to the GPS suction cup mount.

Main Components:

- **Front Camera Lens:** Records the road ahead.
- **Interior Camera Lens:** Records the vehicle's cabin.
- **1.5-inch LCD Screen:** For viewing live footage, playback, and menu navigation.
- **Control Buttons:** Power, OK, Menu, Up/Down navigation.
- **MicroSD Card Slot:** For memory card insertion (card not included).
- **Mini-USB Port:** For power supply and PC connection.
- **Speaker/Microphone:** For audio recording and playback.

- **GPS Module (integrated in mount):** For location and speed data.

4. SETUP AND INSTALLATION

4.1 Inserting the MicroSD Card

1. Ensure the dash camera is powered off.
2. Locate the MicroSD card slot on the side of the device.
3. Insert a Class 10 or higher MicroSD card (up to 32GB recommended) into the slot until it clicks into place.
4. To remove, gently push the card in until it springs out.

Note: A MicroSD card is not included and must be purchased separately. It is recommended to format the card within the camera before first use.

4.2 Mounting the Dash Camera

1. Clean the chosen area on your windshield thoroughly.
2. Attach the dash camera to the suction cup mount.
3. Press the suction cup firmly against the windshield and flip the lever to secure it.
4. Adjust the camera angle to ensure a clear view of the road and the vehicle interior.

4.3 Powering the Device

1. Connect the mini-USB end of the power cable to the dash camera's USB port.
2. Plug the 12V cigarette lighter adapter into your vehicle's power outlet.
3. The camera will automatically power on and begin recording when the vehicle's ignition is turned on.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

- **Power On/Off:** The camera powers on/off automatically with vehicle ignition. You can also manually power on/off by pressing and holding the Power button.
- **Recording:** Once powered on, the camera automatically starts continuous loop recording. A red indicator light or icon on the screen will confirm recording is active.
- **Emergency Recording:** In case of a sudden impact or collision, the built-in G-sensor will automatically lock the current video segment, preventing it from being overwritten. You can also manually trigger emergency recording by pressing a designated button (refer to on-screen prompts or specific button layout).

5.2 Menu Navigation

Press the **Menu** button to access settings. Use the **Up/Down** buttons to navigate through options and the **OK** button to select.

5.3 Key Settings

- **Resolution:** Set video recording quality (e.g., 1080p, 720p).
- **Loop Recording:** Adjust the duration of video segments (e.g., 1, 3, 5 minutes).

- **G-Sensor Sensitivity:** Adjust the sensitivity of the impact detection.
- **Motion Detection:** Enable or disable this feature for parking surveillance.
- **Date/Time Stamp:** Ensure the correct date and time are displayed on recordings.
- **GPS Information:** View GPS status and ensure location data is being recorded.
- **Format SD Card:** Erase all data on the MicroSD card and prepare it for recording.

5.4 Playback

1. Stop recording by pressing the OK button if currently recording.
2. Enter playback mode (usually by pressing the Mode button or navigating through the menu).
3. Use the Up/Down buttons to browse through recorded video files.
4. Press the OK button to play a selected video.

6. MAINTENANCE

6.1 Formatting the MicroSD Card

Regularly formatting the MicroSD card (e.g., once a month) helps maintain its performance and prevents data corruption. This will erase all recorded files.

1. Access the camera's menu.
2. Navigate to the 'Format' option.
3. Confirm the action to format the MicroSD card.

6.2 Cleaning the Device

- Use a soft, dry cloth to clean the camera body.
- For the lenses, use a specialized lens cleaning cloth to avoid scratches.
- Do not use harsh chemicals or abrasive cleaners.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	No power supply; faulty cable; low internal battery.	Check power connection to cigarette lighter. Ensure cable is securely connected. Charge the internal battery by keeping it connected to power.
Recording stops unexpectedly.	MicroSD card full or corrupted; card speed too slow.	Format the MicroSD card. Replace with a new Class 10 or higher speed card.
Video footage is blurry.	Protective film on lens; dirty lens; incorrect focus.	Remove any protective film. Clean the lens with a soft cloth. Ensure the camera is securely mounted and not vibrating.




Problem	Possible Cause	Solution
GPS not acquiring signal.	Poor satellite reception; GPS module obstructed.	Ensure the camera has a clear view of the sky. Avoid mounting near metallic objects or tinted areas that might block the signal.
Screen freezes or malfunctions.	Software glitch.	Perform a soft reset by pressing and holding the power button until the device restarts. If available, check for firmware updates.

8. SPECIFICATIONS


Feature	Specification
Model Number	C1285
Brand	Midland
Color	Black
Screen Size	1.5 Inches
Video Recording Resolution	1080p Full HD
Field of View	160 Degrees
Special Features	Night Vision, Motion Detection, Integrated GPS
Connections	USB
Compatible Devices	Personal Computer, Car
Battery Composition	Lithium-ion
Rechargeable Battery	Yes
Mounting Type	Suction Cup Mount

9. WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not available in the provided product data. Please refer to the official Midland website or your point of purchase for warranty claims and technical assistance.

	<p>Midland Bike Guardian Wi-Fi Dash Cam User Guide</p> <p>A comprehensive guide to the Midland Bike Guardian Wi-Fi dash cam, detailing its features, controls, setup, operation, and file management. Features Full HD video, 170° wide-angle lens, IP68 rating, and Wi-Fi connectivity.</p>
	<p>Midland Bike Guardian Pro: Quick Start Guide for Action Camera</p> <p>Get started with your Midland Bike Guardian Pro action camera. This guide covers main features, key descriptions, battery charging, PC connection, recording modes, Wi-Fi setup, and app usage.</p>
	<p>Midland H5 WiFi Action Cam User Manual</p> <p>Comprehensive user manual for the Midland H5 WiFi Action Cam, covering setup, controls, configuration, accessories, and specifications. Learn how to use your action camera for video, photo, and car modes.</p>
	<p>Midland Bike Guardian Pro User Manual: Features, Setup, and Specifications</p> <p>Comprehensive user manual for the Midland Bike Guardian Pro action camera and motorcycle dash cam. Learn about its features, setup, charging, app usage, technical specifications, and safety precautions.</p>

Documents - Midland – C1285



[Midland Catalogue 2019: CB Radios, Walkie Talkies, and More](#)

Explore the Midland Catalogue 2019, featuring innovative CB radios like the DualMike, M-5, M-MINI, M-10, and M-20, alongside a wide range of walkie-talkies, amateur VHF/UHF, professional VHF/UHF, and marine VHF devices. Discover accessories and solutions for seamless communication.

lang:en score:19 filesize: 17.81 M page_count: 94 document date: 2019-03-22

[\[pdf\] User Manual](#)



STREET GUARDIAN DUAL 5 Ora inserite il cavo all interno della fessura come indicato nell'immagine A

Quando questa funzione è on la videocamera si spegne automaticamente C1285 myjni eu products

6611 manuals RO |||

STREET GUARDIAN DUAL ROMANA Informatii privind acest ghid de utilizare

Continutul acestui ghid vine divulgat doar cu scop informativ si poate fi modificat fara preaviz. Am facut tot posibil ca acest manual sa fie precis si complet. Cu toate acestea, nu ne asumam nici o responsabilitate pentru ...

lang:it score:18 filesize: 11.74 M page_count: 16 document date: 2020-07-28




[\[pdf\] Reference Guide Guide Catalog](#)

Radio Shack Semiconductor Reference Guide 1988 worldradiohistory BOOKSHELF ARH Technology |||

INCLUDES OVER 92,000 SEMICONDUCTOR SUBSTITUTIONS INTEGRATED

CIRCUITS INDEX BY GENERIC NUMBER GENE ... 0 1104 CT256 1122 CI257 1104 C7258 1102 C7259 1102 CT282 1122 C7283 1104 CT284 1102 **C1285** 1102 C7286 1103 C1300 1104 C7461 1123 C1600 1104 CT1012 2016 CT1013 2016 CT1018 ...

lang:i-klingon score:16 filesize: 27.45 M page_count: 568 document date: 2023-10-12



[\[pdf\] Reference Guide Guide](#)

Radio Shack Semiconductor Reference Guide Notebook worldradiohistory BOOKSHELF ARH

Technology |||

Aep-ARCHER_I Engineer s Cat. No. 276-5001 1.99 Noteboo 1 1 4. 1vote s ime le j 3 be, sPaz ... 0 1104 CT256 1122 CI257 1104 C7258 1102 C7259 1102 CT282 1122 C7283 1104 CT284 1102 **C1285** 1102 C7286 1103 C1300 1104 C7461 1123 C1600 1104 CT1012 2016 CT1013 2016 CT1018 ...

lang:en score:16 filesize: 46.39 M page_count: 942 document date: 2023-08-28



[\[pdf\] Catalog](#)

Midland Katalog 2020 engl alan electronics de CustomUpload

37403570340037003560369035003200363035203650

CATALOGUE 2020 www.midlandeurope.com Midland World info midlandeurope.com

604314 - Printed in March ... corder, suction cup mount with GPS, 12V cigarette

lighter socket, USB cable for PC connection. code **C1285** OPTIONAL ADHESIVE

SUPPORT C1434 80 CAMERAS TRUCK GUARDIAN WIRELESS TRUCK AND

CARAVAN VIDEO...

lang:en score:13 filesize: 18.01 M page_count: 98 document date: 2020-04-03

[\[pdf\] Catalog](#)




2020generalcat en ctfassets net 319pqsbj036y 6U8a1Gr81Zd9QhmaVXugK8

f821ff44e0a44e5d38d5fed82d448351 Download English midlandeurope Product Catalogues Midland Online Shop 2020GENERALCAT EN 79vMViShxdrUw9d8lcIN03 a13b5ed22688f774a813101635a19c94 |||

CATALOGUE 2020 www.midlandeurope.com Midland World info midlandeurope.com 604314 - Printed in March ... corder, suction cup mount with GPS, 12V cigarette lighter socket, USB cable for PC connection. code **C1285** OPTIONAL ADHESIVE SUPPORT C1434 80 CAMERAS TRUCK GUARDIAN WIRELESS TRUCK AND CARAVAN VIDEO...

lang:en **score:12** filesize: 18.02 M page_count: 98 document date: 2020-02-27



[\[pdf\] Accessories](#)

Helmholt Elektronik A S Midland 2022 katalog Eng Side 3 view publitas 21162 1499644 s 8acca69e 8c6f 4076 be90 ef6a735fc5c1 response content disposition attachment filename* UTF 8 |||

Our tale of innovation for over 60 years. 1959 Founding year 1977 1st certified CB Radio on the euro ... sh cam, suction cup mount with GPS, 12V cigarette lighter socket, USB cable for PC connection. code **C1285** BLACK BOX NIGHT VISION 4 IR LED CYCLE RECORDING WIDE ANGLE MOTION DETECTION 160 OUT 120 I...

lang:en **score:12** filesize: 12.53 M page_count: 96 document date: 2022-06-27



[\[pdf\] Guide Catalog Label](#)

His Masters Voice Recorded Music 1948 49 18 gen 2024 — Guide 12 Glossary of Musical Terms 15 Royal Records 23 General Quick Steps Correct Tempo Intro The way you look to night Smoke gets in your hismastersvoicer00unse 0 archive org |||

8Y APPOINTMENT SUPPLIERS OP GRAMOPHONES, RECORDS, RADIO AND TELEVISION APPARATUS TO HIS MAJESTY THE ... e Boheme In a Monastery Garden Ketelbey -- C2595 By Peter Dawson with Orch.. Organ and Chorus **C1285** By Reginald Foort Cinema Organ C3127 By Coldstream Guards Band with Vocal Quartet and Orga...

lang:en **score:11** filesize: 23.06 M page_count: 334 document date: 2018-02-28