

[Manuals.plus](#) /

› [CAT](#) /

› CAT Junior Crew Lil' Movers Remote Control Dump Truck Instruction Manual

CAT 82454

CAT Junior Crew Lil' Movers Remote Control Dump Truck Instruction Manual

Model: 82454

INTRODUCTION

This manual provides essential information for the safe and proper operation and maintenance of your CAT Junior Crew Lil' Movers Remote Control Dump Truck. Please read these instructions thoroughly before first use and retain them for future reference.



Image: The CAT Junior Crew Lil' Movers Remote Control Dump Truck, a yellow toy dump truck with a friendly face, shown alongside its yellow circular remote control.

SAFETY INFORMATION

Warning! Not suitable for children under 36 months. Small parts. Choking hazard.

- Always supervise children during play.
- Do not operate the toy near stairs, roads, or other hazardous areas.
- Keep hair, loose clothing, and fingers away from moving wheels.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries from the toy and controller when not in use for extended periods.

WHAT'S IN THE BOX

Upon opening the package, ensure all components are present:

- JR CREW LIL' MIGHTY RC DUMP TRUCK
- Remote Control



Image: The CAT Junior Crew Lil' Movers Remote Control Dump Truck visible inside its retail packaging.

SETUP: BATTERY INSTALLATION

The CAT Junior Crew Lil' Movers Remote Control Dump Truck requires batteries for both the vehicle and the remote control. Batteries are not included.

1. For the Dump Truck:

- Locate the battery compartment on the underside of the dump truck.
- Using a screwdriver, open the battery compartment cover.
- Insert 3 x AA batteries, ensuring correct polarity (+/-).
- Replace the battery compartment cover and secure it with the screw.

2. For the Remote Control:

- Locate the battery compartment on the back of the remote control.
- Using a screwdriver, open the battery compartment cover.
- Insert 2 x AAA batteries, ensuring correct polarity (+/-).
- Replace the battery compartment cover and secure it with the screw.

After installing batteries, turn the power switch on the dump truck to the "ON" position. The headlights will flash if the truck batteries are working correctly.

OPERATING INSTRUCTIONS

The CAT Junior Crew Lil' Movers Remote Control Dump Truck features a child-friendly controller designed for ease of use.



Image: A close-up of the yellow circular remote control with two large buttons, one red and one triangular yellow.

1. **Power On:** Ensure both the dump truck and the remote control are switched to the "ON" position.
2. **Forward Movement:** Press and hold the large triangular button on the remote control to move the dump truck forward. The headlights will illuminate during operation.
3. **Reverse and Turn:** Press and hold the large red button on the remote control to move the dump truck backward. While moving backward, the truck will also turn. This is the primary method for steering the vehicle.
4. **Stowable Controller:** When not in use, the remote control can be securely attached to the dump truck for convenient storage.

Practice controlling the truck in an open area to familiarize yourself with its movement and turning capabilities.

MAINTENANCE

- **Cleaning:** Wipe the toy and remote control with a clean, damp cloth. Do not immerse in water.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight. Remove batteries if storing for an extended period to prevent leakage.
- **Battery Care:** Always use fresh batteries of the recommended type. Dispose of used batteries responsibly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Truck does not move or respond to remote.	Batteries are dead or incorrectly installed. Power switch is off. Remote control is out of range.	Replace batteries in both truck and remote, ensuring correct polarity. Ensure both power switches are in the "ON" position. Move closer to the truck.
Headlights do not turn on.	Truck batteries are low or dead. Power switch is off.	Replace truck batteries. Ensure power switch is in the "ON" position.
Truck moves slowly.	Low batteries. Operating on a difficult surface (e.g., thick carpet, carrying heavy load).	Replace batteries. Operate on smoother surfaces or with lighter loads.

SPECIFICATIONS

- **Model Number:** 82454
- **Product Dimensions:** 10 x 4.5 x 6 inches (25.4 x 11.4 x 15.2 cm)
- **Item Weight:** 1.57 pounds (0.71 kg)
- **Recommended Age:** 36 months - 8 years
- **Batteries Required:**
 - Truck: 3 x AA batteries (not included)
 - Remote Control: 2 x AAA batteries (not included)
- **Manufacturer:** Funrise, Inc.



Image: A diagram illustrating the dimensions of the yellow CAT Junior Crew Lil' Movers Remote Control Dump Truck, showing its length, width, and height.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the packaging or contact the manufacturer directly. You may also visit the official CAT Toys website for additional resources.

Manufacturer: Funrise, Inc.

For further assistance, please visit: [CAT Toys Official Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question