



Manuals.plus /

› SogesHome /

› SogesHome Gaming Desk ST-140BK-SH Instruction Manual

SogesHome ST-140BK-SH

SogesHome Gaming Desk ST-140BK-SH Instruction Manual

Model: ST-140BK-SH

INTRODUCTION

Thank you for choosing the SogesHome Gaming Desk ST-140BK-SH. This ergonomic gaming desk is designed to provide a comfortable and efficient setup for your gaming or work needs. It features a spacious desktop, integrated accessories like a cup holder and headphone hook, and effective cable management. This manual provides detailed instructions for assembly, proper usage, maintenance, and troubleshooting to ensure you get the most out of your new desk.

SAFETY INFORMATION

- Read all instructions carefully before beginning assembly.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly; tighten them only after all parts are correctly aligned.
- Ensure the desk is placed on a stable and level surface to prevent wobbling.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs) for the desktop.
- Use two people for assembly, especially when handling heavier components, to ensure safety and ease of installation.

PACKAGE CONTENTS

Please verify that all components listed below are present before starting assembly. If any parts are missing or damaged, please contact customer service.

- Desktop Panels (with carbon fiber texture)
- Desk Legs (Steel frame)
- Support Beams/Crossbars
- Adjustable Foot Pads
- Cup Holder
- Headphone Hook
- Large Mouse Pad (integrated design)
- Cable Management Grommets
- Hardware Pack (screws, bolts, Allen key, spare parts)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Refer to the parts list to ensure all items are present.
2. **Attach Legs to Desktop:** Position the desktop panels upside down. Attach the steel desk legs to the designated mounting points on the desktop using the provided screws. Ensure the legs are oriented correctly; double-check the diagrams in the included manual to avoid incorrect placement.
3. **Install Support Beams:** Connect the support beams or crossbars between the desk legs. This step enhances the desk's stability. Insert screws loosely at first.
4. **Attach Accessories:** Install the cup holder and headphone hook to the side of the desk as shown in the diagrams. Secure them with the appropriate hardware.
5. **Final Tightening:** Once all parts are in their correct positions and loosely assembled, proceed to fully tighten all screws. Do not overtighten, but ensure all connections are firm and secure.
6. **Place Mouse Pad:** Lay the large integrated mouse pad over the desktop surface.
7. **Adjust Foot Pads:** Turn the desk upright. Adjust the adjustable foot pads at the bottom of the legs to ensure the desk is stable and level on your floor.



Figure 1: Desk Dimensions. The desk measures 140cm in length, 65cm in width, and 75cm in height. The leg base is 55cm wide.



Figure 2: Adjustable Foot Pad. Each desk leg is equipped with an adjustable foot pad to ensure stability on uneven surfaces and protect your floor.

USAGE

The SogesHome Gaming Desk ST-140BK-SH is designed for versatility and convenience.

- **Spacious Desktop:** The 140cm x 65cm surface provides ample space for multiple monitors, keyboards, mice, and other gaming peripherals.
- **Integrated Mouse Pad:** The large, integrated mouse pad covers the entire desktop, offering a smooth and consistent surface for precise mouse movements.
- **Cup Holder:** Utilize the convenient cup holder to keep your beverages secure and prevent spills on your equipment.
- **Headphone Hook:** Hang your headphones on the dedicated hook to keep them easily accessible and off the desk surface, reducing clutter.
- **Cable Management:** Use the cable grommets on the desktop to route and organize your cables, keeping your setup tidy and preventing tangles.



Figure 3: Desk in Use. This image shows the desk set up with a monitor, keyboard, mouse, and other gaming accessories, demonstrating its spacious design.



Figure 4: Integrated Accessories. A detailed view of the cup holder, headphone hook, and cable management grommet, highlighting their convenient placement.



Figure 5: Carbon Fiber Texture and Cable Grommet. This image shows the elegant carbon fiber texture of the desktop and a cable grommet for organized wiring.

MAINTENANCE

To ensure the longevity and appearance of your SogesHome Gaming Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or solvents, as these can damage the finish of the desk.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Mouse Pad Care:** The integrated mouse pad can be wiped clean with a damp cloth. Avoid soaking or machine washing.

TROUBLESHOOTING

If you encounter any issues with your gaming desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Uneven floor surface; loose screws; incorrect assembly.	<ul style="list-style-type: none"> Adjust the foot pads at the bottom of each leg until the desk is stable. Check and tighten all assembly screws. Review assembly instructions to ensure all parts are correctly installed.
Parts do not fit together during assembly.	Incorrect orientation of parts; manufacturing defect.	<ul style="list-style-type: none"> Carefully re-examine the instruction manual diagrams for correct part orientation. Do not force parts. If a part appears defective, contact customer service.
Missing hardware or components.	Packaging error.	Contact SogesHome customer service with your purchase details and a list of missing items.

SPECIFICATIONS

- **Model:** ST-140BK-SH
- **Brand:** SogesHome
- **Dimensions (L x W x H):** 140 cm x 65 cm x 75 cm (55.1 x 25.6 x 29.5 inches)
- **Weight:** 27.5 kg (60.6 lbs)
- **Material:** Metal (frame), Wood (desktop), Alloy Steel (base)
- **Color:** Black
- **Weight Capacity:** Up to 150 kg (330 lbs)
- **Special Features:** Adjustable foot pads, integrated cup holder, headphone hook, cable management grommets, full-surface mouse pad.

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact SogesHome customer service directly. Please have your purchase receipt and model number (ST-140BK-SH) available when contacting support.

You can typically find contact information on the SogesHome official website or through the retailer where you purchased the product.

