

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GhostStop](#) /

› [P-SB7 Spirit Box - Latest Version - Ghost Hunting EVP](#)

GhostStop SB7T-R5

P-SB7 Spirit Box Instruction Manual

Model: SB7T-R5 | Brand: GhostStop

1. OVERVIEW

The P-SB7 Spirit Box is a sophisticated device designed for paranormal research, specifically for Electronic Voice Phenomena (EVP) investigations. This 7th revision offers enhanced capabilities for clearer communication and an improved user experience. The 'T' has been dropped from the product name, but the Automatic Temperature Deviation Detection (ATDD) feature, which the 'T' originally represented, is still included. ATDD provides an alert when the ambient temperature changes by +/- 5°F, a useful indicator during investigations.

2. FEATURES

- Newest model with noise reduction and ATDD (Automatic Temperature Deviation Detection) alert.
- Built-in flashlight for use in low-light conditions.
- Adjustable sweep speed and direction (forward and backward sweeping) for customized scanning.
- Backlit display for easy viewing in the dark.
- Features a half frequency step between each frequency, allowing for more precise and potentially clearer communication.
- Scans a wide range from 76 MHz to 87.9 MHz, broader than many similar devices.
- User selectable FM and AM bands.

3. SETUP


3.1 Battery Installation

The P-SB7 Spirit Box operates on 3 AAA batteries (included). To install the batteries, locate the battery compartment cover on the back of the unit. Slide the cover open, insert the batteries ensuring correct polarity (+/-), and then close the cover securely.





SPROUT



TEMP.
RESET

DC 4.5V

Model: P-SB7 Spirit Box Rev7
Power: DC4.5V 3X"AAA"(UM-4)

DAS Distribution Inc.

Figure 1: Rear view of the P-SB7 Spirit Box, highlighting the battery compartment.

3.2 Powering On/Off

Press the 'POWER' button located on the front panel to turn the device on or off. The backlit display will illuminate upon activation, indicating the device is ready for use.



Figure 2: Front view of the P-SB7 Spirit Box, showing the display and control buttons.

4. OPERATING INSTRUCTIONS

4.1 Sweep Function

The P-SB7 scans radio frequencies to generate a 'white noise' or 'radio sweep' effect, which is commonly used in EVP investigations. Use the 'SWEEP RATE' button to adjust the speed at which the frequencies are scanned. The 'SWEEP FWD' and 'SWEEP REV' buttons control the direction of the frequency sweep (forward or reverse).

4.2 Volume Control

Adjust the audio output level using the 'VOL+' and 'VOL-' buttons to suit your listening preference.

4.3 AM/FM Selection

Toggle between the AM and FM radio bands using the 'AM/FM C/F' button. The device is capable of scanning frequencies from 76 MHz to 87.9 MHz.

4.4 ATDD (Automatic Temperature Deviation Detection)

The ATDD feature is always active and will provide an alert if the ambient temperature changes by +/- 5°F. This can be a significant environmental indicator during paranormal investigations.

4.5 Flashlight

To activate the built-in flashlight, press the 'BACK LIGHT / LAMP' button. This feature is useful for illuminating your immediate area in dark environments.

4.6 External Audio Connection

For private listening or connecting the device to an external recording unit or speaker, utilize the 3.5mm headphone jack or the 'SPOUT' port located on the top edge of the unit.



Figure 3: Top view of the P-SB7 Spirit Box, illustrating the headphone and SPOUT ports.

5. MAINTENANCE

To ensure the longevity and optimal performance of your P-SB7 Spirit Box, keep the device clean by wiping it with a soft, dry cloth. Avoid exposing the unit to extreme temperatures, high moisture, or direct sunlight. If the device will not be used for an extended period, it is recommended to remove the batteries to prevent potential leakage and damage.

6. TROUBLESHOOTING

- **No Power:** Ensure the batteries are correctly installed with the proper polarity and are not depleted. Press the 'POWER' button firmly.
- **No Sound:** Verify that the volume is turned up. If headphones are connected, ensure they are properly plugged in or removed if you intend to use the internal speaker. Check the selected AM/FM

band.

- **Interference/Poor Reception:** The device is designed to sweep through frequencies, so continuous clear reception is not expected. However, excessive interference might be caused by nearby electronic devices. Try moving to a different location away from potential sources of electromagnetic interference.

7. SPECIFICATIONS

Feature	Detail
Model Number	SB7T-R5
Brand	GhostStop
Item Dimensions (LxWxH)	4 x 2.2 x 0.75 inches
Package Dimensions (LxWxH)	5.24 x 5.16 x 1.65 inches
Package Weight	0.12 Kilograms
Color	Black
Material	Plastic
Power Source	Battery Powered (3x AAA)
Tuner Technology	AM/FM
Radio Bands Supported	AM/FM (76 MHz to 87.9 MHz)
Special Feature	Added half step in each frequency, ATDD
Included Components	Main Unit

8. WARRANTY AND SUPPORT

The P-SB7 Spirit Box comes with a 1-year manufacturer warranty. For any support inquiries, troubleshooting assistance beyond this manual, or to make a warranty claim, please contact GhostStop customer service directly. Refer to your purchase documentation for specific contact details or visit the official GhostStop website.