

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KOIOS](#) /

› [KOIOS Air Fryer, Electric Hot Airfryers Oven/XXL 7.8 QT Large Air Fryer Dehydrator, 1800-Watt 4 * 6 Presets Rotisserie Oven, Oilless Pressure Cooker with Digital Touchscreen & Cookbook \(160 Recipes\)](#)

KOIOS 39006

KOIOS Air Fryer Instruction Manual

Model: 39006

Brand: KOIOS

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation of your KOIOS Air Fryer. The KOIOS Air Fryer is an electric hot air fryer designed for healthier cooking with less fat and oil, while preserving nutrients. It features an 1800-Watt heating element for faster cooking and crispier results.

Key Features:

- Tasty food with less fat and oil: Reduces fat and calories in fried and crispy foods, preserving nutrients.
- Faster cooking time: 1800-Watt KOIOS air fryer oven cooks faster than most electric hot air fryers, with crispier results.
- 160 recipes and 6x4 presets: 4 functions, 6 presets for popular dishes, and a 160-recipe cookbook for culinary inspiration.
- Smart operation and easy cleaning: One-touch digital function, nonstick pan, and dishwasher-safe parts for hassle-free use.



Figure 1: KOIOS Air Fryer with its basket containing a cooked whole chicken and fresh vegetables.

2. SETUP

Before first use, carefully unpack all components and remove any packaging materials, stickers, or labels. Ensure all parts are present and undamaged. Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.

Initial Cleaning:

- Wipe the exterior of the air fryer with a damp cloth.
- Wash the removable basket and grid with hot soapy water. Rinse thoroughly and dry completely before reassembling.

- Do not immerse the main unit (fryer body) in water or any other liquid.

Placement:

Ensure the air fryer is placed on a flat, stable, heat-resistant surface. Allow at least 4 inches (10 cm) of space on all sides of the appliance for proper ventilation during operation.

3. PARTS DESCRIPTION

The KOIOS Air Fryer consists of several key components designed for optimal performance and ease of use:

- **Main Unit (Fryer):** The primary body of the appliance, housing the heating element, fan, and control panel.
- **Digital Touchscreen Control Panel:** Located on the top, it features temperature and time adjustments, preset cooking functions, and power controls.
- **Removable Basket:** The large capacity (7.38 Liters / 7.8 QT) nonstick basket where food is placed for cooking. It features a handle for easy insertion and removal.
- **Removable Grid/Crisper Plate:** Sits at the bottom of the basket, allowing air to circulate around the food and excess oil to drip below.



Figure 2: Digital Touchscreen Control Panel with preset icons for various foods.

4. OPERATING INSTRUCTIONS

The KOIOS Air Fryer offers intuitive digital controls for various cooking needs.

Basic Operation:

- Power On:** Plug the air fryer into a grounded electrical outlet. The digital display will illuminate. Press the "On/Off" button to activate the control panel.
- Preheating (Optional):** For best results, preheat the air fryer. Select your desired temperature using the temperature control arrows (up/down). Set a short time (e.g., 3-5 minutes) and press "Start/Pause".

3. **Loading Food:** Once preheated (or ready to cook), carefully pull out the removable basket using the handle. Place your food onto the crisper plate inside the basket. Do not overfill the basket to ensure even cooking.
4. **Setting Time and Temperature:**
 - Use the temperature control arrows to set the desired cooking temperature (105°F–400°F).
 - Use the time control arrows to set the desired cooking time.
5. **Using Presets:** The air fryer comes with 6 presets for common dishes (Fries, Frozen Fries, Nuggets, Steak, Poultry, Fish). Simply press the corresponding preset icon on the control panel to automatically set the recommended time and temperature.
6. **Start Cooking:** Press the "Start/Pause" button to begin the cooking cycle. The fan and heating element will activate.
7. **Shaking/Flipping Food:** For even cooking, especially for smaller items, pull out the basket halfway through the cooking time and gently shake or flip the food. Reinsert the basket to resume cooking.
8. **Completion:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and transfer the cooked food to a serving plate.
9. **Power Off:** Press the "On/Off" button to turn off the air fryer. Unplug the appliance from the wall outlet when not in use.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your KOIOS Air Fryer.

Cleaning Instructions:

1. **Unplug and Cool Down:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean the Basket and Grid:** The nonstick basket and crisper plate are dishwasher-safe. Alternatively, they can be washed by hand with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in warm soapy water for about 10 minutes before cleaning.
3. **Clean the Interior:** Wipe the interior of the air fryer with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
4. **Clean the Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food residue. Ensure the appliance is completely cool and unplugged.

Caution: Never immerse the main unit of the air fryer in water or any other liquid. Ensure all parts are completely dry before storing or using the appliance again.

6. TROUBLESHOOTING

If you encounter any issues with your KOIOS Air Fryer, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in or power outlet is faulty.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overcrowded or food was not shaken/flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use or high-fat food.	Clean the basket and interior thoroughly. For high-fat foods, drain excess oil from the basket during cooking.

Problem	Possible Cause	Solution
Food is not crispy.	Not enough oil, wrong temperature/time, or too much moisture.	Lightly coat food with oil. Adjust temperature and time as needed. Pat dry moist foods before air frying.

For issues not listed here, please contact KOIOS customer support.


7. SPECIFICATIONS

Feature	Detail
Brand	KOIOS
Model Name	Air Fryer
Item Model Number	39006
Capacity	7.38 Liters (7.8 QT)
Output Wattage	1800 Watts
Voltage	240 Volts
Control Method	Touch
Product Dimensions	15.7"D x 11.6"W x 13.4"H
Item Weight	14.97 Pounds
Material	Plastic (Outer), Stainless Steel (Inner)
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes
UPC	710877116864

8. WARRANTY AND SUPPORT

KOIOS offers a **24-month warranty** on this air fryer, ensuring peace of mind for your purchase. For warranty activation and exclusive gifts, please refer to the registration card included in your product packaging or visit the official KOIOS website.

For any product inquiries, technical support, or warranty claims, please contact KOIOS customer service through their official channels. Contact information can typically be found on the product packaging or the brand's official website.

 <p>PERSONAL BLENDER HEALTHY RECIPES</p>	<p>KOIOS Personal Blender Healthy Recipes</p> <p>A collection of healthy recipes for smoothies, juices, and shakes, designed for use with the KOIOS Personal Blender. Includes ingredients and preparation instructions for various delicious and nutritious drinks.</p>
 <p>KOIOS User manual ST800 4L Ultrasonic Humidifier</p>	<p>KOIOS ST800 4L Ultrasonic Humidifier User Manual</p> <p>User manual for the KOIOS ST800 4L Ultrasonic Humidifier, covering specifications, features, functions, usage, cleaning, safety precautions, and troubleshooting.</p>
 <p>KOIOS AIR PURIFIER USER MANUAL www.koiosshop.com</p>	<p>KOIOS B-D02L Air Purifier User Manual and Specifications</p> <p>Comprehensive user manual for the KOIOS B-D02L Air Purifier, detailing important safeguards, technical features, operation instructions, troubleshooting, and specifications. Learn how to use and maintain your air purifier for optimal performance.</p>
 <p>KOIOS MULTIFUNCTIONAL BLENDER USER MANUAL www.koiosshop.com</p>	<p>KOIOS WBL-702 Multifunctional Blender User Manual</p> <p>Comprehensive user manual for the KOIOS WBL-702 Multifunctional Blender, covering safety instructions, product overview, assembly, operation, troubleshooting, cleaning, and warranty information.</p>
	<p>KOIOS Centrifugal Juicer Instruction Manual</p> <p>This manual provides instructions for the safe and effective use of the KOIOS Centrifugal Juicer. It includes general parts description, important safeguards, preparation for use, operating instructions, dismantling and assembly, cleaning and care, and specifications.</p>
 <p>KOIOS ESPRESSO MAKER Get Started <small>This short guide is not intended to explain all the functions of the appliance. Please read the owner's instruction booklet before using the appliance.</small></p>	<p>KOIOS Espresso Maker User Guide: Brewing Perfect Espresso and Steaming Milk</p> <p>A concise guide to operating your KOIOS Espresso Maker, covering tips for brewing the perfect espresso and steaming milk for lattes and cappuccinos. Learn about grind size, tamping, extraction times, and milk frothing techniques.</p>