

[Manuals.plus](#) /

> [WilTec](#) /

> Wiltec XXL Cat Tree - 240-260 cm Adjustable Ceiling Height - Instruction Manual

WilTec 62104

Wiltec XXL Cat Tree Instruction Manual

Model: 62104

1. INTRODUCTION

Thank you for choosing the Wiltec XXL Cat Tree. This cat tree is designed to provide a stimulating and comfortable environment for your feline companions, offering multiple levels for climbing, scratching, playing, and resting. Its adjustable height feature ensures a secure fit in various indoor spaces.

Key Features:

- Adjustable height from 240 cm to 260 cm for ceiling tensioning.
- Multiple elevated platforms for observation and relaxation.
- Durable sisal-wrapped posts for scratching.
- Two hammocks, two cat houses, and one tunnel for resting.
- Two suspended play balls to stimulate hunting instincts.

2. SAFETY INSTRUCTIONS

- Ensure all components are securely fastened during assembly to prevent instability.
- Regularly check the stability of the cat tree, especially the ceiling tensioning mechanism.
- Place the cat tree on a flat, stable surface.
- Keep small children away from the cat tree during assembly and ensure they do not climb on it.
- Inspect the cat tree periodically for any loose parts, wear, or damage. Replace worn components as necessary.
- This product is intended for indoor use only.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. The package should contain:

- Sisal posts
- 3 observation platforms

- 2 cat houses
- 2 sleeping surfaces (hammocks)
- 1 tunnel
- 2 play balls
- Ceiling mounting components
- Base plate (45 x 60 cm)
- Assembly hardware (screws, connectors, tools if included)

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Wiltec XXL Cat Tree. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the package contents list.
2. **Assemble Base:** Attach the lowest sisal posts to the base plate (45 x 60 cm) using the provided hardware. Ensure they are tightened securely.
3. **Build Upwards:** Continue attaching platforms, cat houses, hammocks, and additional sisal posts layer by layer. Refer to the diagram for the correct placement of each component.
4. **Attach Ladders and Tunnel:** Securely attach any ladders and the tunnel to their designated platforms.
5. **Install Play Balls:** Attach the two play balls to the designated areas, typically hanging from platforms or cat houses.
6. **Adjust Ceiling Height:** Once the main structure is assembled, adjust the top sisal post to fit snugly between the top platform and your ceiling. Twist the adjustable section until it creates firm tension against the ceiling, ensuring stability. The height is adjustable between 240 cm and 260 cm.
7. **Final Check:** Double-check all screws and connections to ensure they are tight and the entire structure is stable.





Figure 1: Fully assembled Wiltec XXL Cat Tree.



260cm



60cm

45cm

Figure 2: Cat tree dimensions for placement planning.



Figure 3: Detail of an upper cat house and hammock.





Figure 4: Detail of a lower cat house and tunnel.

5. OPERATING INSTRUCTIONS

The Wiltec XXL Cat Tree is designed for intuitive use by your cats. No specific 'operation' is required from the user beyond initial setup.

- **Scratching:** The sisal-wrapped posts provide an ideal surface for cats to sharpen their claws, helping to protect your furniture.
- **Climbing and Exploration:** The multi-level design encourages natural climbing behavior and exploration.
- **Resting and Hiding:** Cats can utilize the hammocks, cat houses, and tunnel for comfortable resting, napping, or hiding.
- **Play:** The suspended play balls are designed to engage your cat's hunting instincts.

6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your cat tree.

- **Cleaning:** Clean the cat tree with a dry or damp cloth. Avoid harsh chemicals that could be harmful to your pets.
- **Regular Inspection:** Periodically check all connections, especially the ceiling tensioning, for tightness. Re-tighten as needed.
- **Wear and Tear:** Inspect sisal posts and fabric surfaces for significant wear. While sisal is durable, it will fray over time with use. Consider replacing heavily worn components if available from the manufacturer.
- **Odor Control:** If odors develop, sprinkle baking soda on fabric surfaces, let it sit for a few hours, then vacuum thoroughly.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Instability:** If the cat tree feels wobbly, ensure the base is on a flat surface and the ceiling tensioning post is securely tightened. Check all screw connections.
- **Sisal Wear:** It is normal for sisal to show wear from scratching. If the sisal is completely worn in areas, consider wrapping new sisal rope around the posts or contacting Wiltec for replacement parts.
- **Fabric Damage:** If the fabric covering on platforms or houses becomes damaged, it may be due to excessive scratching in non-sisal areas. Encourage your cat to use the sisal posts.
- **Cats Not Using the Tree:** Introduce your cat to the tree gradually. Use catnip, treats, or favorite toys to encourage exploration. Place the tree in an area where your cat enjoys spending time.

8. SPECIFICATIONS

Feature	Detail
Brand	WilTec
Model Number	62104
Material	Sisal, Plush Fabric
Color	Dark Grey
Height	240-260 cm (Adjustable)
Base Plate Dimensions	45 x 60 cm
Number of Levels	5
Weight	40.79 lbs (approx. 18.5 kg)

Feature	Detail
Recommended Use	Indoor
Pet Type	Cat (suitable for small, medium, and large breeds)
Care Instructions	Clean with a dry or damp cloth

9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact Wiltec customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can often find support information on the official Wiltec website or through the retailer where you purchased the product.

