



[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns Adjustable C Table (Model HOGA-C0110) Instruction Manual

Tribesigns HOGA-C0110

Tribesigns Adjustable C Table (Model HOGA-C0110) Instruction Manual

Welcome to your new Tribesigns Adjustable C Table. This manual provides essential information for assembly, operation, maintenance, and troubleshooting.

1. PRODUCT OVERVIEW

The Tribesigns Adjustable C Table is a versatile and mobile furniture piece designed for various uses, including as a bedside table, sofa side table, or laptop cart. It features an adjustable height mechanism, two-tier storage shelves, and lockable rolling casters for easy movement and stability.



Figure 1.1: Tribesigns Adjustable C Table in use.

The table's C-shaped design allows it to slide easily under sofas, beds, or chairs, bringing the tabletop closer to you. The height can be adjusted to suit different needs and preferences.



Figure 1.2: Product dimensions and key features.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 200 pounds (90.7 kg) on the tabletop.
- **Stability:** Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as needed.
- **Caster Locks:** Always engage the caster locks when the table needs to remain stationary to prevent accidental movement.
- **Adjusting Height:** When adjusting the table height, ensure no items are on the tabletop that could fall or be damaged. Adjust slowly and carefully.
- **Children:** Keep small parts away from children during assembly. Do not allow children to climb on or play with the table.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop
- Metal Frame Components
- Storage Shelves (2)
- Casters with Brakes (4)
- Assembly Hardware (screws, nuts, etc.)
- Installation Tool (Allen Key, Screwdriver, Wrench)
- Assembly Guide

4. SETUP & ASSEMBLY

Assembly typically takes approximately 30 minutes. It is recommended that two people assemble the table for ease and safety. All necessary tools and hardware are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Base Frame:** Attach the horizontal support bars to the vertical frame pieces using the provided screws and tools. Ensure the C-shaped base is correctly oriented.
3. **Install Casters:** Screw the four casters into the designated holes on the bottom of the base frame. Ensure two of the casters have locking mechanisms.
4. **Attach Storage Shelves:** Secure the two-tier storage shelves to the vertical frame using the appropriate hardware.
5. **Mount Tabletop Support:** Attach the adjustable height mechanism to the main vertical frame.
6. **Secure Tabletop:** Place the tabletop onto the support mechanism and fasten it securely.
7. **Final Check:** Verify that all screws are tightened and the table is stable before use.

Your browser does not support the video tag.

Video 4.1: A demonstration of the Tribesigns C Table's features and assembly process.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

The C Table features an adjustable height mechanism, allowing you to customize its height from 28.3 inches to 35.4 inches.

1. **Loosen Knobs:** Locate the adjustment knobs on the vertical support poles. Turn them counter-clockwise to loosen.

2. **Adjust Height:** Carefully raise or lower the tabletop to your desired height.
3. **Tighten Knobs:** Once the desired height is reached, turn the knobs clockwise firmly to secure the tabletop in place. Ensure both knobs are equally tightened for stability.



Figure 5.1: Table at minimum height (28.3 inches).




Figure 5.2: Table at maximum height (35.4 inches).

5.2 Using Rolling Casters

The table is equipped with four rolling casters, two of which have locking mechanisms, for easy mobility and secure positioning.

- **Moving the Table:** To move the table, ensure the caster locks are disengaged. Gently push or pull the table to its desired location.
- **Locking the Table:** To keep the table stationary, press down on the lever of the two locking casters until they click into place. This prevents unintended movement.
- **Unlocking the Table:** To move the table again, lift the lever on the locking casters to disengage the brake.



Figure 5.3: Detail of a rolling caster with brake.

5.3 General Use

The Tribesigns C Table is designed for various applications:

- **Laptop Workstation:** Use it as a convenient surface for your laptop while working from a sofa or bed.
- **Snack/Meal Table:** Ideal for enjoying snacks, meals, or drinks while relaxing on your couch or in bed.
- **Bedside Table:** Provides a stable surface for books, lamps, or personal items next to your bed.
- **Storage:** The two-tier shelves offer additional space for books, magazines, or other small items.



Figure 5.4: C Table in a living room setting.



Figure 5.5: C Table used as a bedside table.

6. MAINTENANCE

- **Cleaning:** Wipe the tabletop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the table to prevent buildup.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Casters:** Keep casters free of debris (hair, lint) to ensure smooth rolling.

7. TROUBLESHOOTING

- **Table Wobbles:**

Solution: Ensure all assembly screws are fully tightened. Check that the table is on a flat, even surface. If the floor is uneven, consider using furniture pads to stabilize.

- **Height Adjustment is Stiff:**

Solution: Loosen the adjustment knobs slightly more before attempting to adjust the height. Ensure the vertical poles are clean and free of obstructions. Applying a small amount of silicone lubricant (avoiding contact with wood surfaces) to the sliding mechanism might help, but do so sparingly.

- **Casters Not Rolling Smoothly or Locking:**

Solution: Check casters for trapped debris (e.g., hair, carpet fibers) and remove them. Ensure the locking mechanism is fully engaged or disengaged. If casters are damaged, they may need replacement.

- **Parts Missing or Damaged:**

Solution: Refer to Section 9 (Warranty & Support) for contact information to request replacement parts.

8. SPECIFICATIONS

Feature	Specification
Brand	Tribesigns
Model Number	HOGA-C0110
Product Dimensions (D x W x H)	15.7"D x 32.5"W x 28.3"H
Adjustable Height Range	28.3" to 35.4"
Item Weight	28 Pounds (12.7 kg)
Maximum Weight Recommendation	200 Pounds (90.7 kg)
Frame Material	Metal
Top Material Type	Engineered Wood (E1 Particle Board)

Feature	Specification
Color	Oak+Black
Number of Shelves	2
Assembly Required	Yes
Recommended People for Assembly	2

9. WARRANTY & SUPPORT

Tribesigns products come with **18 months of quality assurance**. If you encounter any issues with your Adjustable C Table, or if you have questions regarding assembly, parts, or operation, please contact Tribesigns customer service.

For support, please visit the official Tribesigns website or contact their customer service department through the retailer where you purchased the product. Have your model number (HOGA-C0110) and purchase date ready for faster service.

Thank you for choosing Tribesigns.