

[manuals.plus](#) /› [Fossil](#) /› [Fossil Flynn Chronograph Brown Leather Watch User Manual](#)

## Fossil BQ2125

# Fossil Flynn Chronograph Brown Leather Watch User Manual

Model: BQ2125



## INTRODUCTION

---

Thank you for choosing the Fossil Flynn Chronograph Brown Leather Watch, Model BQ2125. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.



**Figure 1:** Front view of the Fossil Flynn Chronograph watch, showcasing its blue dial, silver-tone case, and brown leather strap. The watch features three subdials and Roman numeral hour markers at the 12, 6, and 9 o'clock positions.

## SETUP

---

### 1. Initial Setup and Time Setting

1. **Unpacking:** Carefully remove the watch from its packaging. Inspect for any visible damage.
2. **Crown Operation:** The crown (the knob on the side of the watch) has multiple positions.
  - **Position 0 (Normal):** Crown pushed in completely.
  - **Position 1 (Date Setting - if applicable):** Pull the crown out one click. Turn the crown to set the date.
  - **Position 2 (Time Setting):** Pull the crown out two clicks. The second hand will stop. Turn the crown to set the hour and minute hands. Push the crown back to Position 0 to start the watch.

### 2. Adjusting the Leather Strap

The watch features a brown leather strap with a tang buckle clasp. To adjust the fit, simply insert the tang (pin) into the desired hole on the strap. Ensure the watch is snug but comfortable on your wrist, allowing for proper blood circulation.

## OPERATING THE CHRONOGRAPH

---

Your Fossil Flynn watch is equipped with a chronograph function, allowing you to measure elapsed time. The chronograph is operated using the two pushers located above and below the crown.



**Figure 2:** Side view of the watch, highlighting the main crown and the two chronograph pushers. The top pusher typically starts/stops the chronograph, and the bottom pusher resets it.

- Starting the Chronograph:** Press the **top pusher** (A) once to start the chronograph. The chronograph second hand (large central second hand) and subdial hands will begin to move.
- Stopping the Chronograph:** Press the **top pusher** (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands on the main dial and subdials.
- Resetting the Chronograph:** After stopping, press the **bottom pusher** (B) once to reset the chronograph hands to their zero positions. The chronograph must be stopped before it can be reset.
- Accumulated Elapsed Time:** To measure multiple time segments (e.g., lap times), press the top pusher to stop, then press it again to restart from where it left off. Press the bottom pusher only when you wish to fully reset.

## Water Resistance

This watch is water resistant to 5 ATM (50 meters). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown or pushers when the watch is wet or submerged, as this can compromise the water resistance.

## MAINTENANCE

---

### 1. Cleaning Your Watch

- Case and Crystal:** Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, but ensure no water enters the watch. Dry thoroughly with a clean, soft cloth.
- Leather Strap:** Leather straps can be cleaned with a slightly damp cloth. Avoid excessive moisture, harsh chemicals, or prolonged exposure to direct sunlight, which can cause the leather to dry, crack, or discolor. Allow the strap to air dry naturally.

### 2. Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to skip (indicating low battery), it is time for a battery replacement. It is highly recommended to have the battery replaced by a qualified watchmaker or an authorized Fossil service center to ensure proper sealing and maintain water resistance.





**Figure 3:** Rear view of the watch, displaying the stainless steel case back with model number BQ2125 and water resistance rating (5 ATM). This area is where battery replacement would be performed by a professional.

### 3. Storage

When not in use, store your watch in a cool, dry place away from direct sunlight and extreme temperatures. The original watch tin or a watch box is ideal for protection.

### TROUBLESHOOTING

| Problem               | Possible Cause                         | Solution   |
|-----------------------|--|--|
| Watch is not running. | Battery depleted. Crown is pulled out. | Replace battery (professional service recommended). Push crown fully in. |

| Problem   | Possible Cause   | Solution   |
|---|--|--|
| Chronograph hands do not reset to zero.                   | Chronograph was not stopped before resetting. Minor misalignment.        | Ensure chronograph is stopped before pressing the reset pusher. Consult a watchmaker for adjustment if persistent. |
| Condensation under the crystal.                           | Exposure to extreme temperature changes or compromised water resistance. | Seek professional service immediately to prevent internal damage.  |
| Date (if applicable) changes at noon instead of midnight. | Time is set for AM/PM incorrectly.                                       | Advance the hour hand by 12 hours.   |

For issues not listed above or if solutions do not resolve the problem, please contact Fossil customer support or an authorized service center.

## SPECIFICATIONS

- Model Number:** BQ2125
- Case Size:** 48mm
- Case Material:** Stainless Steel
- Band Width:** 26mm
- Band Material:** Leather
- Clasp Type:** Tang Buckle
- Water Resistance:** 5 ATM (50 meters)
- Movement:** Quartz Chronograph
- Product Dimensions:** 1.89 x 1.02 x 0.51 inches; 3.53 ounces
- Batteries:** 1 Product Specific battery required (included)

## WARRANTY AND SUPPORT

### Warranty Information

Fossil watches typically come with a limited warranty covering manufacturing defects. Specific warranty terms and conditions are usually provided with your purchase documentation or can be found on the official Fossil website. Please retain your proof of purchase for warranty claims.

### Customer Support

For further assistance, service, or inquiries regarding your Fossil Flynn Chronograph watch, please visit the official Fossil website or contact their customer support.

[Fossil Official Store: Visit the Fossil Store on Amazon](#)