

Oneach AMZ-F2016-BK

Oneach AMZ-F2016-BK Industrial Floor Lamp User Manual

Model: AMZ-F2016-BK | Brand: Oneach

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure the lamp is unplugged before assembly, cleaning, or changing the bulb.
- Do not exceed the maximum wattage specified for the bulb.
- Keep the lamp away from water and moisture.
- This lamp is designed for indoor use only.
- The lamp has passed ETL and UL Safety Standard Tests, ensuring safe operation when used as directed.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Lamp Pole Sections
- Lamp Base
- Lamp Head with E26 Socket
- Power Cord with Foot Switch
- *Note: Light bulb is not included.*

3. SETUP AND ASSEMBLY

The Oneach Industrial Floor Lamp is designed for easy assembly without the need for additional tools.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Lamp Pole:** Screw the lamp pole sections together clockwise until they are securely tightened. Ensure all connections are firm.
3. **Attach Lamp Head:** Screw the lamp head onto the top pole section.

4. **Attach Lamp Base:** Screw the assembled lamp pole into the lamp base clockwise until it is stable.
5. **Install Light Bulb:** Insert an E26 base light bulb (maximum 60W, not included) into the lamp socket. Compatible with LED or CFL bulbs.
6. **Position Lamp:** Place the lamp in your desired location. The 6-foot cord provides flexibility for placement.
7. **Connect to Power:** Plug the power cord into a standard electrical outlet.



Image: Fully assembled Oneach Industrial Floor Lamp, showcasing its minimalist design and exposed bulb socket.

Replaceable bulb

Design your own lamp

(Excluding light bulbs)



Image: Illustration showing various compatible E26 base light bulbs that can be used with the lamp, allowing for personalized style.

4. OPERATING INSTRUCTIONS

The Oneach Industrial Floor Lamp features a convenient foot switch for easy operation.

- **To Turn On:** Gently tap the foot switch located on the power cord.
- **To Turn Off:** Tap the foot switch again.

Scientific Design

Bulb not included



Image: Diagram illustrating the lamp's dimensions (63.75" height, 9" base diameter) and a close-up of the integrated foot switch for operation.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your floor lamp.

- **Cleaning:** Ensure the lamp is unplugged. Wipe the metal surfaces with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Bulb Replacement:** Always unplug the lamp before replacing the light bulb. Allow the old bulb to cool completely before removal. Screw in a new E26 base bulb, ensuring it does not exceed 60W.

6. TROUBLESHOOTING

If you encounter any issues with your Oneach Industrial Floor Lamp, refer to the following common solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp is unplugged. Light bulb is loose or burnt out. Power outlet is not functioning.	Ensure the power cord is securely plugged into a working outlet. Check and tighten the light bulb, or replace it if burnt out. Test the outlet with another device.
Lamp flickers.	Loose bulb connection. Incompatible bulb type.	Tighten the light bulb. Ensure the bulb is compatible with an E26 base and within the 60W limit.

7. SPECIFICATIONS

Brand	Oneach
Model Number	AMZ-F2016-BK
Product Dimensions	11.99"D x 11.99"W x 63.75"H
Item Weight	5.68 pounds
Material	Metal
Finish Type	Painted
Bulb Base	E26
Max Wattage	60W (Bulb not included)
Voltage	120 Volts
Power Source	Corded Electric
Switch Type	Foot Switch
Certifications	ETL, UL
Indoor/Outdoor Usage	Indoor




8. WARRANTY AND SUPPORT

The Oneach Industrial Floor Lamp comes with a **1-year warranty** from the date of purchase.

For warranty claims, technical support, or any questions regarding your product, please contact Oneach customer service. Refer to your purchase documentation or the Oneach official website for specific contact details.

Oneach is committed to customer satisfaction and will assist with any issues you may encounter.

Related Documents - AMZ-F2016-BK

	<p>SOFTLIGHTING Floor Lamp F2016 Installation Manual and Product Information</p> <p>Comprehensive installation guide and specifications for the Chipy SOFTLIGHTING Floor Lamp (Model F2016, SF210-107/SF211-107/SF220-107). Learn how to assemble, maintain, and use your contemporary floor lamp.</p>
	<p>Luminzone Outdoor Lamp Post Light Assembly & Installation Guide</p> <p>Step-by-step assembly and installation instructions for the Luminzone 3-Head Outdoor Lamp Post Light, including a parts list and wiring guide. Ensure safe installation by following all safety warnings and N.E.C. requirements.</p>
	<p>Inspire Arquitecto Desk Lamp - User Manual and Safety Instructions</p> <p>Comprehensive user manual for the Inspire Arquitecto desk lamp, covering installation, operation, safety precautions, technical specifications, and warranty information. Learn how to safely use and maintain your Inspire Arquitecto lamp.</p>
	<p>LI-HY-0205-BK-QU Eye Protection Lamp User Manual</p> <p>Comprehensive user manual for the LI-HY-0205-BK-QU eye protection lamp, detailing features, specifications, usage, and safety guidelines for optimal eye comfort and reduced eye strain.</p>
	<p>KDG LED Lamp Instruction Manual & Product Information</p> <p>Comprehensive guide for the KDG LED Lamp (AMZ-TBL-036), covering product specifications, charging, dimming, remote control, precautions, FCC compliance, and warranty details from Zhongshan Cook Lighting.</p>
	<p>INSPIRE LINA Floor Lamp - User Manual and Safety Instructions</p> <p>Comprehensive user manual and safety instructions for the INSPIRE LINA floor lamp (Model YF4750). Includes technical specifications, assembly guide, maintenance, warranty information, and important safety warnings for indoor use.</p>