

IKEA LUSTIGT

IKEA LUSTIGT Coloring Paper Roll Instruction Manual

1. INTRODUCTION

The IKEA LUSTIGT Coloring Paper Roll is a creative tool designed for drawing and coloring activities. This 10-meter long roll features detailed and imaginative patterns, providing an extensive surface for artistic expression. It is suitable for use with various coloring mediums such as felt-tip pens and watercolors. This manual provides essential information for the proper use and care of your coloring paper roll.

2. SETUP

To begin using your LUSTIGT Coloring Paper Roll, follow these simple steps:

- Unroll the Paper:** Carefully unroll the desired length of paper from the roll onto a flat, clean, and stable surface.
- Protect Your Surface:** If you plan to use wet mediums like watercolors or markers that might bleed, place a protective mat or newspaper underneath the paper to prevent damage to your table or floor.
- Optional Paper Roll Holder:** The paper can be used directly on a table. For easier dispensing and cutting, you may place the roll on a compatible paper roll holder (sold separately).



Image: A child unrolling the LUSTIGT paper from a wooden holder, preparing to color.

3. OPERATING INSTRUCTIONS

The LUSTIGT Coloring Paper Roll is designed for creative expression. Here's how to use it:

1. **Choose Your Tools:** Select your preferred coloring tools, such as felt-tip pens, crayons, colored pencils, or watercolors.
2. **Begin Coloring:** Start coloring the pre-printed patterns on the paper. The large format allows for individual or collaborative coloring projects.
3. **Continue or Cut:** Once a section is complete, you may cut it off using scissors or a paper cutter, or continue unrolling for more creative space.



Image: Close-up of a child's hands coloring a section of the LUSTIGT paper roll with colorful felt-tip pens.

4. MAINTENANCE

Proper storage and care will ensure the longevity of your coloring paper roll:

- **Storage:** Store the paper roll in a dry environment to prevent moisture damage, which can cause the paper to warp or become discolored.
- **Avoid Sunlight:** Keep the roll away from direct sunlight to prevent fading of the paper or any pre-printed designs.
- **Drying:** If using wet mediums, allow the colored sections to dry completely before rolling them back up or stacking them to prevent smudging or sticking.



Image: Two rolls of LUSTIGT coloring paper, showcasing the detailed patterns when rolled.

5. TROUBLESHOOTING

While the LUSTIGT Coloring Paper Roll is a simple product, here are some common issues and their solutions:

- **Problem:** Paper tears easily during use.
Solution: Ensure the surface beneath the paper is smooth and free of sharp objects. Apply gentle pressure when coloring, especially with pointed tools.

- **Problem:** Colors bleed through the paper.

Solution: While the paper is designed for various mediums, excessive saturation with very wet watercolors or markers may cause bleed-through. Use a protective mat underneath if this is a concern.

6. SPECIFICATIONS

Brand	IKEA
Model Number	LUSTIGT
UPC	300846146567
Paper Material	Wood pulp, Chlorine-free bleached paper
Paper Size	10 meters (approximately 394 inches)
Paper Finish	Matte
Number of Sheets	1 (roll)
Recommended Uses	Drawing with felt-tip pens, Watercolor painting
Product Dimensions	43.7 x 29.2 x 5.3 cm
Product Weight	400 grams (0.4 kg)
First Available Date	May 10, 2022

7. WARRANTY INFORMATION

Specific warranty information for the IKEA LUSTIGT Coloring Paper Roll is not provided in the product details. Please refer to IKEA's general warranty policies or contact IKEA customer service for details regarding their art and craft supplies.

8. SUPPORT

For further assistance or inquiries regarding the IKEA LUSTIGT Coloring Paper Roll, please visit the official IKEA website or contact IKEA customer support directly. Contact information can typically be found on their website or on your purchase receipt.