

[Manuals.plus](#) /

› [iLive Electronics](#) /

› iLive Electronics Radio Frequency Wireless Headphones with Transmitter/Charging Dock (IAHRF79B) Instruction Manual

iLive Electronics IAHRF79B

iLive Electronics Radio Frequency Wireless Headphones with Transmitter/Charging Dock (IAHRF79B) Instruction Manual

Model: IAHRF79B

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your iLive Electronics Radio Frequency Wireless Headphones with Transmitter/Charging Dock, model IAHRF79B. Please read this manual thoroughly before using the product to ensure proper function and longevity.

WHAT'S INCLUDED

Carefully unpack all items from the box. Ensure all components listed below are present:

- iLive Radio Frequency Wireless Headphones
- Transmitter/Charging Dock
- Optical Audio Cable
- 3.5mm Audio Cable
- 3.5mm to RCA Audio Adapter
- Micro-USB to USB Cable
- AC/DC Power Adapter
- User's Guide
- Warranty Information



Image: The iLive Radio Frequency Wireless Headphones resting on their charging dock, showcasing the complete product.

KEY FEATURES

The iLive Radio Frequency Wireless Headphones offer a range of features designed for an enhanced audio experience:

- **2.4GHz Wireless Technology:** Provides reliable connectivity up to 100 feet.
- **Auto Pairing:** Simplifies the connection process between headphones and transmitter.
- **On-Ear Volume Control:** Conveniently adjust audio levels directly from the headphones.
- **LED Power Indicator:** Displays the power status of the headphones.
- **Soft Cushioned Ear Pads & Adjustable Headband:** Designed for comfort during extended use.
- **Built-in Rechargeable Lithium-Ion Battery:** Offers approximately 7 hours of listening time at 100% volume.
- **Versatile Connectivity:** Compatible with TVs and other devices via Optical audio cable, 3.5mm audio cable, or 3.5mm to RCA audio adapter.
- **Transmitter Dock:** Features a 3.5mm audio input and an LED power charging indicator.

RF WIRELESS HEADPHONES



IAHRF79

Image: A detailed diagram highlighting key features of the iLive Wireless Headphones, including the adjustable headband, earcups, on-ear controls, and various audio inputs on the charging base.

Product Overview Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and functionality of the iLive Radio Frequency Wireless Headphones.

SETUP

1. Connecting the Transmitter Dock

The transmitter dock serves as the audio source and charging station. Connect it to your audio device (TV, computer, etc.) using one of the provided cables:

- **Optical Audio Cable:** For devices with an optical audio output. Connect one end to the device's optical output and

the other to the optical input on the transmitter dock.

- **3.5mm Audio Cable:** For devices with a 3.5mm headphone jack or audio output. Connect one end to the device and the other to the 3.5mm audio input on the transmitter dock.
- **3.5mm to RCA Audio Adapter:** For devices with RCA audio outputs (red and white ports). Connect the RCA ends to your device's audio outputs, then connect the 3.5mm end of the adapter to the 3.5mm audio input on the transmitter dock.

Once the audio cable is connected, plug the AC/DC power adapter into the transmitter dock and then into a power outlet. The LED power charging indicator on the dock will illuminate.

2. Powering On and Pairing the Headphones

The headphones feature an auto-pairing function. To power on the headphones, press and hold the power button located on one of the earcups until the LED power indicator on the headphones illuminates. The headphones will automatically attempt to pair with the powered-on transmitter dock. A successful connection is typically indicated by a steady blue light on both the headphones and the dock (refer to the LED indicator section for specific light patterns).





Image: The iLive Wireless Headphones and their charging dock displayed separately, illustrating the components involved in the setup process.

OPERATION

Wearing the Headphones

Adjust the headband to ensure a comfortable and secure fit. The soft cushioned ear pads are designed for extended listening sessions. Ensure the earcups fully cover your ears for optimal sound isolation.

Adjusting Volume

Use the on-ear volume control buttons located on the right earcup to increase or decrease the audio volume. Adjust to a comfortable listening level.





Image: A close-up view of the right earcup of the iLive Wireless Headphones, showing the on-ear volume controls and power button.

Charging the Headphones

To charge the headphones, place them onto the transmitter/charging dock. Ensure the charging contacts on the headphones align with the pins on the dock. The LED power charging indicator on the dock will change to indicate charging status (e.g., red for charging, blue for fully charged). A full charge provides approximately 7 hours of playback at 100% volume.



Image: The iLive Wireless Headphones correctly placed on their charging dock, with the indicator light visible.

MAINTENANCE

To ensure the longevity and optimal performance of your headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones and charging dock. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the headphones on the charging dock or in a safe, dry place away from extreme temperatures and direct sunlight.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not used for extended periods.
- **Avoid Moisture:** Keep the headphones and dock away from water and excessive humidity.

TROUBLESHOOTING

If you encounter issues with your iLive Wireless Headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound or intermittent audio	Headphones not paired; Transmitter not powered; Audio cable loose or incorrect input selected on source device; Out of range.	Ensure transmitter is powered and connected correctly. Verify source device audio output is active. Check headphone power and pairing status. Move closer to the transmitter (within 100 ft).
Headphones not charging	Headphones not properly seated on dock; Dock not powered; Charging contacts dirty.	Ensure headphones are correctly placed on the dock and contacts align. Verify the AC/DC adapter is plugged into the dock and a live power outlet. Clean charging contacts on both headphones and dock with a dry cloth.
Poor sound quality or static	Interference; Weak signal; Low battery.	Move away from other 2.4GHz devices (Wi-Fi routers, cordless phones). Ensure headphones are within range of the transmitter. Charge the headphones fully.
Headphones won't turn on	Battery fully discharged.	Place headphones on the charging dock and allow them to charge for at least 30 minutes before attempting to power on again.

SPECIFICATIONS

Feature	Detail
Model Number	IAHRF79B
Connectivity Technology	RF (Radio Frequency)
Wireless Communication Technology	RF
Wireless Range	Up to 100 feet
Battery Type	Built-in Rechargeable Lithium Ion
Battery Life	Approx. 7 hours (at 100% volume)
Charging Port	Micro-USB (for headphones)
Transmitter Audio Inputs	3.5mm Audio, Optical Audio

Feature	Detail
Headphones Jack	3.5 mm Jack (for wired use, if applicable)
Ear Placement	Over Ear
Noise Control	Sound Isolation, Noise Cancelling
Control Type	Volume Control (on-ear)
Product Dimensions	6.7 x 3 x 7.68 inches
Item Weight	1.77 pounds
Material	Plastic
UPC	047323704406

WARRANTY INFORMATION

This product is covered by a **Limited 90-Day Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty document included in your product packaging.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact iLive Electronics customer service. Refer to the contact information provided in your product packaging or visit the official iLive Electronics website.

Online Support: [Visit the iLive Electronics Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07TKDTLW3>

More documents and user manuals: <https://manuals.plus/>