



[Manuals.plus](#) /

› [Bestway](#) /

› Pavillo Cool Mount 4 Pop Up Tent User Manual

Bestway 68087

Pavillo Cool Mount 4 Pop Up Tent User Manual

Model: 68087 | Brand: Bestway

INTRODUCTION

Thank you for choosing the Pavillo Cool Mount 4 Pop Up Tent. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your tent. Please read it carefully before use to ensure a safe and enjoyable experience.

This tent is designed for outdoor recreational use, suitable for camping, beach trips, and picnics. It features a self-assembly design for quick setup, fire-retardant fabric, and waterproof seams for enhanced durability and protection.

SETUP INSTRUCTIONS

The Pavillo Cool Mount 4 Pop Up Tent is designed for rapid deployment, setting up in seconds. Follow these steps for a smooth setup:

1. **Unpack the Tent:** Remove the tent from its carry bag. The tent is spring-loaded and will partially unfold on its own.
2. **Allow to Pop Up:** Gently guide the tent as it springs open. Ensure there are no obstructions.
3. **Lay Flat:** Lay the tent flat on your chosen ground, ensuring the floor is spread out evenly.
4. **Secure with Pegs:** Use the included 8 tent pegs to secure the tent to the ground through the designated loops. This prevents the tent from shifting in wind.
5. **Extend Guylines:** If necessary, extend and secure the 8 guylines for additional stability, especially in windy conditions.



Image: The Pavillo Cool Mount 4 Pop Up Tent fully set up, showcasing its dome shape and vibrant colors.



Image: The tent pitched in a grassy outdoor environment, demonstrating its compact footprint.

OPERATING THE TENT

Your Pavillo Cool Mount 4 tent is designed for comfort and convenience during your outdoor adventures.

Ventilation

The tent features one main entrance and two side windows, providing excellent cross-ventilation. Open the zippered entrance and side windows to allow air circulation, which helps regulate temperature and reduce condensation inside the tent.



Image: The tent with its main entrance fully unzipped and open, revealing the interior.



Image: A side view of the tent with one of its mesh windows unzipped and rolled up for ventilation.

Internal Storage

An integrated inner pocket is provided for storing small personal items, keeping them organized and easily accessible within the tent.

Folding and Packing

Folding a pop-up tent requires a specific technique. While it pops up quickly, practice may be needed to master the folding process back into its compact circular shape. Refer to the instructions provided on the tent's carry bag or manufacturer's website for detailed folding steps.



Image: The Pavillo Cool Mount 4 Pop Up Tent neatly folded and stored in its compact circular carry bag.

MAINTENANCE

Proper maintenance will extend the life of your Pavillo Cool Mount 4 Pop Up Tent.

Cleaning

The tent material should be hand washed only. Use mild soap and water to clean any dirt or stains. Do not use harsh detergents, bleach, or abrasive cleaners, as these can damage the fabric and waterproof coating.

Drying and Storage

Always ensure the tent is completely dry before folding and storing it. Storing a damp tent can lead to mildew growth and fabric degradation. Store the tent in its original carry bag in a cool, dry place away from direct sunlight.

Inspection

Periodically inspect the tent for any signs of wear and tear, such as rips, frayed seams, or damaged poles. Address minor issues promptly to prevent them from worsening.

TROUBLESHOOTING

Here are solutions to common issues you might encounter with your tent:

- **Difficulty Folding:** Pop-up tents have a specific folding method. If you are struggling, refer to the folding instructions often printed on the carry bag or search for video tutorials specific to pop-up tents. Practice makes perfect.
- **Water Leakage:** While the tent features waterproof seams and material, extreme weather conditions or improper

setup can sometimes lead to moisture inside. Ensure all zippers are fully closed, and the tent is pitched on level ground. For prolonged heavy rain, consider adding an external tarp for extra protection.

- **Limited Space:** The Pavillo Cool Mount 4 tent is rated for 4 persons. This rating typically refers to sleeping capacity without much gear. For maximum comfort, especially with camping gear, it may be more suitable for 2-3 adults or 2 adults and 2 small children.

SPECIFICATIONS

Brand	Bestway
Model Name	Coolmount 4
Product Dimensions (L x W x H)	94.49" x 82.68" x 39.37" (240 cm x 210 cm x 100 cm)
Item Weight	3.96 pounds (1.8 Kilograms)
Occupancy	4 Person
Material	190T Polyester (Outer Tent), 120G/M2 PE (Ground Protection)
Poles	Fibreglass - Ø 6.0 mm (0.24")
Water Resistance	Waterproof material and seams (PU2000 mm coating)
Fire Retardant	Yes
Number of Doors	1
Number of Windows	2 (side windows)
Included Components	1 tent, 1 carry bag, 8 tent pegs



Image: Diagram illustrating the dimensions of the Pavillo Cool Mount 4 Pop Up Tent.

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or contact the retailer from whom you purchased the tent. Bestway, the manufacturer, can also provide details on their official website. If you require further assistance or have questions not covered in this manual, please contact the retailer or Bestway customer support. Keep your proof of purchase handy for any warranty claims or support inquiries.