

Bestway 54153

Bestway Backyard Oasis Family Pool Model 54153 Instruction Manual

Your guide to safe and enjoyable use of your inflatable pool.

[Safety Information](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SAFETY INFORMATION

Read and understand all instructions before setting up and using this product. Failure to follow these warnings and instructions can result in serious injury or death to users, especially children.

- **Adult Supervision Required:** Always keep children in direct sight when they are in or near the pool. Drowning can occur quickly and silently.
- **Age Recommendation:** This pool is suitable for users aged 6 years and older.
- **Secure Area:** Ensure the pool is placed on a flat, level surface, free from sharp objects. Do not set up the pool on a slope or uneven ground.
- **Empty When Not in Use:** Always empty the pool completely when it is not in use to prevent water accumulation, which can be a drowning hazard for small children.
- **No Diving or Jumping:** The pool is not deep enough for diving or jumping. Serious injury can result.
- **Chemicals:** Use pool chemicals strictly according to manufacturer instructions. Improper use can cause skin irritation or other health hazards.
- **Electrical Safety:** Keep all electrical devices away from the pool area.

2. SETUP INSTRUCTIONS

Setting up your Bestway Backyard Oasis Family Pool is quick and easy, typically taking about 10 minutes.

1. **Choose a Location:** Select a solid, level surface in your backyard, clear of any debris, sharp objects, or uneven ground. Ensure there is adequate space around the pool.
2. **Unpack the Pool:** Carefully remove the pool from its packaging. Unfold the pool and lay it flat in your chosen location.
3. **Inflate the Pool:** The pool features extra-wide side walls and two air rings. Use an air pump (not included)

to inflate each air chamber until it is firm to the touch but not overinflated. Ensure all inflation valves are securely closed after inflation.

Inflatable Walls

Quick and easy set up



Image: Inflatable walls for quick and easy setup.

4. **Fill with Water:** Once inflated, begin filling the pool with water. The pool has a water capacity of 575 liters. Fill to the recommended water line, ensuring the pool walls remain stable.

Water Capacity 575 L



Easy To Store



No Tools Required



Full Colour Box

Image: Top-down view highlighting the 575L water capacity and ease of setup.

The pool is designed to be foldable for easy storage and requires no tools for assembly.

3. OPERATING YOUR POOL

Enjoying your Bestway Backyard Oasis Family Pool is simple with its user-friendly features.

- **Using Cup Holders and Headrests:** The pool includes two integrated cup holders and comfortable headrests. These are designed for convenience, allowing you to relax while enjoying the water.



Image: Detail of the integrated cup holders and headrests.

- **Supervision:** Always ensure constant adult supervision when children are in or around the pool.
- **Entry and Exit:** Use caution when entering and exiting the pool.

4. MAINTENANCE

Proper maintenance will extend the life of your Bestway Family Pool and ensure a hygienic swimming environment.

- **Cleaning:** Regularly clean the pool walls and floor to prevent algae and dirt buildup. Use a soft brush or cloth and mild soap if necessary, then rinse thoroughly.
- **Water Treatment:** For prolonged use, consider using appropriate pool chemicals to maintain water quality. Follow chemical manufacturer instructions carefully.
- **Draining:** The pool is equipped with a drain valve for easy emptying. Connect a garden hose to the drain valve (if applicable) or simply open the valve to release water in a suitable drainage area.
- **Drying:** After draining, allow the pool to dry completely in the sun before folding and storing. This prevents mold and mildew.
- **Storage:** Deflate the pool and fold it neatly. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Spare Parts:** For any repairs or replacements, always use original Bestway spare parts and accessories. Using third-party parts may void warranty and Bestway will not be liable for any resulting damage.

5. TROUBLESHOOTING

Here are some common issues and their solutions:

- **Pool is losing air:** Check all inflation valves to ensure they are securely closed. Inspect the pool surface for any punctures or small holes. Use a patch kit (often included or sold separately) for repairs.
- **Water is dirty/cloudy:** This indicates a need for cleaning or water treatment. Drain, clean, and refill the pool, or apply appropriate pool chemicals as per their instructions.
- **Pool walls are unstable:** Ensure the pool is on a perfectly level surface. Overfilling can also cause instability; check the recommended water line.

6. SPECIFICATIONS

Model Number	54153
Brand	Bestway
Product Dimensions (L x W x H)	2.13m x 2.06m x 0.69m (7' x 6'9" x 27")
Shape	Pentagonal
Material	Polyvinyl Chloride (PVC)
Water Capacity	575 Liters (151.899 Gallons)
Age Range (Description)	6+
Item Weight	3.57 Kilograms
Assembly Time	Approximately 10 Minutes
Special Features	Drain Hole, Foldable, Inflatable, Lightweight, Portable, 2 Cup Holders, Cushions, Headrests
Included Components	Family Inflatable Pool

Dimensions



Image: Product dimensions and water capacity.

7. WARRANTY & SUPPORT

Bestway products are manufactured to high-quality standards. For warranty information or support, please refer to the documentation included with your purchase or visit the official Bestway website.

Important Note: To ensure product longevity and safety, always use original Bestway spare parts and accessories, even after the warranty period. Bestway will not be held liable for any damage or issues arising from the use or installation of third-party components.