

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Farberware](#) /

› Farberware Countertop Microwave 1100 Watts, 1.6 cu ft - Smart Sensor Microwave Oven User Manual

## Farberware FMO16AHTPLB

# Farberware Countertop Microwave 1100 Watts, 1.6 cu ft User Manual

Model: FMO16AHTPLB

## INTRODUCTION

Welcome to the user manual for your new Farberware Countertop Microwave Oven. This appliance is designed for convenient and efficient cooking, offering 1100 watts of power and a spacious 1.6 cubic feet capacity. It features smart sensor technology, one-touch cooking programs, and a child safety lock for enhanced usability and safety. This manual provides essential information on setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your microwave.



Image: Front view of the Farberware Countertop Microwave in black stainless steel, showcasing its sleek design and control panel.

## SAFETY INFORMATION

Please read all instructions carefully before using your microwave oven. Always follow basic safety precautions to reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open or if the door is damaged.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- The microwave features a **Child Safety Lock**. To activate, press and hold the 'STOP/CANCEL' button for 3 seconds. The lock indicator will appear on the display. To deactivate, repeat the process.

## SETUP

Before first use, ensure proper placement and preparation of your microwave oven.

1. **Unpacking:** Carefully remove all packaging materials. Check for any damage.
2. **Placement:** Place the microwave on a flat, stable surface such as a countertop. Ensure adequate ventilation around the unit. The product dimensions are approximately 19.2"D x 21.8"W x 12.9"H.
3. **Turntable Installation:** Place the turntable ring inside the oven cavity, then position the glass turntable plate securely on top of the ring.
4. **Power Connection:** Plug the microwave into a grounded electrical outlet.

# Get the Perfect Fit.

deluxe size to make the most of your space



Image: Side view of the microwave with dimensions (21.85" width, 12.83" height, 19.48" depth) indicated, illustrating its compact size for various spaces.

## OPERATING INSTRUCTIONS

Your Farberware microwave is designed for ease of use with intuitive controls and preset functions.

- **Setting the Clock:** Press the 'Clock' button, enter the current time using the number pad, then press 'Clock' again to confirm.
- **Express Cook:** For quick cooking, simply press a number from 1 to 6 on the keypad to cook for that many minutes at full power. For example, pressing '1' will cook for 1 minute.
- **One-Touch Cooking Programs:** The microwave features six popular one-touch options: 'Popcorn', 'Potato', 'Frozen Pizza', 'Frozen Entrée', 'Rice', and 'Vegetable'. Simply press the corresponding button for automatic cooking.
- **Sensor Reheat:** Use the 'Sensor Reheat' function to automatically reheat food based on its moisture content, ensuring optimal results without guesswork.
- **Defrost Options:** Choose between 'Time Defrost' to set a specific defrosting duration or 'Weight Defrost' to defrost based on the food's weight.

- **Power Levels:** The microwave offers 10 power levels. Press 'Power Level' and then the desired number (1-10) to adjust the cooking intensity.



# Cooking Made Easy.

smart sensor technology

defrost options

intuitive control panel

one touch start

child safety lock

Image: Close-up of the microwave's control panel, highlighting features like smart sensor technology, defrost options, intuitive controls, one-touch start, and child safety lock.

Video: An official product overview demonstrating the microwave's features, including its compact size, easy-to-clean interior, and various cooking functions. This video highlights the convenience and efficiency of the appliance.

## MAINTENANCE AND CLEANING

Regular cleaning and maintenance will help ensure your microwave oven operates efficiently and extends its lifespan.

- **Interior Cleaning:** Wipe the interior cavity, including the turntable and roller ring, with a damp cloth after each use to prevent food buildup. For stubborn stains, use a mild detergent.
- **Exterior Cleaning:** Clean the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners that may scratch the stainless steel finish.

- **Door Seal:** Regularly inspect the door seals and surrounding areas for any food debris or damage. Clean gently to ensure a proper seal.

# Easy, Clean, Convenient.

easy-to-clean  
interior is perfect for  
the home and office



## FARBERWARE

Image: The interior of the microwave showing a bowl of popcorn on the turntable, emphasizing the easy-to-clean surfaces and ample cooking space.

## TROUBLESHOOTING

If you encounter any issues with your microwave, refer to the following common troubleshooting tips. For more detailed solutions, please consult the official user manual PDF.

Problem	Possible Cause	Solution
Oven will not start	Door not closed properly; Power cord not plugged in; Fuse blown or circuit breaker tripped.	Ensure door is securely closed; Check power cord connection; Check household fuse/circuit breaker.
Food not heating	Incorrect cooking time/power level; Door not closed properly.	Adjust cooking time/power level; Ensure door is securely closed.

Problem	Possible Cause	Solution
Display shows "E-" error	Internal sensor error.	Unplug the microwave for 30 seconds, then plug back in. If the error persists, contact customer support.

## SPECIFICATIONS

Key technical specifications for your Farberware Countertop Microwave Oven:

Feature	Specification
Capacity	1.6 Cubic Feet
Item Weight	34.5 Pounds
Product Dimensions (D x W x H)	19.2" x 21.8" x 12.9"
Wattage	1100 watts
Voltage	1100 Volts
Material	Stainless Steel
Special Feature	Child Safety Lock

## ADDITIONAL SUPPORT

For further assistance, detailed troubleshooting, or warranty information, please refer to the official user manual PDF provided by Farberware. You can access it via the following link:

[Download Official User Manual \(PDF\)](#)

Additionally, protection plans are available for purchase to extend coverage beyond the standard warranty. Please check the product listing for details on available 3-Year, 4-Year, and Complete Protect plans.