



[Manuals.plus](#) /

› [WisFox](#) /

› WisFox Wired Rainbow LED Backlit Gaming Keyboard User Manual

WisFox B07TMPL269

WisFox Wired Rainbow LED Backlit Gaming Keyboard User Manual

INTRODUCTION

Thank you for choosing the WisFox Wired Rainbow LED Backlit Gaming Keyboard. This manual provides essential information for setting up, operating, and maintaining your keyboard to ensure optimal performance. This keyboard features a durable full metal panel, vibrant rainbow LED backlighting, 12 multimedia keys, and 19 anti-ghosting keys, designed for both gaming and general computer use.



The WisFox gaming keyboard connected to a computer setup, demonstrating its use for both work and gaming.

SETUP

The WisFox Gaming Keyboard is a plug-and-play device, requiring no additional software installation for basic functionality.

1. Locate an available USB port on your computer.
2. Connect the USB cable from the keyboard to the USB port on your computer.
3. The operating system will automatically detect and install the necessary drivers.
4. The keyboard is ready for use once the LED backlighting illuminates.

Compatibility: This keyboard is compatible with Windows 95/98/XP/2000/ME/VISTA/7/8/10 and Mac OS. Please note that multimedia functions may not be available when used with Mac OS.

OPERATING INSTRUCTIONS

LED Backlight Control

The keyboard features rainbow LED backlighting with adjustable modes and intensity.

- **Brightness Adjustment:** Press **Fn + PgUp** to increase brightness. Press **Fn + PgDn** to decrease brightness.

- **Light ON/OFF:** Press **Fn +** (light bulb icon) to toggle the backlight on or off.
- **Breathing Speed Control:** Press **Fn + -** to slow down the breathing effect. Press **Fn + =** to speed up the breathing effect.
- **Mode Switch:** Press **Fn +** (star icon) to switch between permanent lighting and automatic breathing lighting modes.



Diagram illustrating how to adjust LED brightness, turn lights on/off, control breathing speed, and switch between backlight modes using Fn key combinations.

Multimedia Keys

The keyboard includes 12 multimedia shortcut keys for convenient control of media playback and system functions. These keys are accessed by pressing the **Fn** key in combination with the corresponding F1-F12 keys.

- **Fn + F1:** Media Player
- **Fn + F2:** Volume Down
- **Fn + F3:** Volume Up
- **Fn + F4:** Mute

- **Fn + F5:** Stop
- **Fn + F6:** Previous Track
- **Fn + F7:** Play/Pause
- **Fn + F8:** Next Track
- **Fn + F9:** Email
- **Fn + F10:** Web Browser
- **Fn + F11:** My Computer
- **Fn + F12:** Calculator



Image highlighting the 12 multimedia shortcut keys and the 19 anti-ghosting keys for enhanced gaming performance.

Anti-Ghosting Keys

The keyboard features 19 non-conflicting keys, ensuring that multiple key presses are registered simultaneously and accurately, which is crucial for fast-paced gaming.

WASD and Arrow Key Swap

For gaming convenience, you can swap the functionality of the WASD keys with the arrow keys.

- To swap: Press **Fn + W**.
- To revert: Press **Fn + W** again.

CLAVIER ULTRA MINCE FLOTTANT
CONCEPTION UNIQUE DE CARACTÈRES DE GRAVURE UV AU LASER

50,000,000
Fois Test De Frappe

Detachable Keycap Quick Response

Illustration demonstrating the ability to swap W, A, S, D keys with arrow keys using the Fn + W combination.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your keyboard.

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For deeper cleaning, a slightly damp cloth (water only) can be used, ensuring no liquid enters the key switches or internal components.
- **Spill Resistance:** The keyboard features a splash-resistant design. In case of accidental spills, immediately disconnect the keyboard from your computer and allow it to dry completely before reconnecting. Avoid submerging the keyboard in liquid.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the keyboard's finish and keycap legends.



Close-up view of the keyboard keys with water droplets, illustrating its splash-resistant design.

TROUBLESHOOTING

If you encounter issues with your WisFox Gaming Keyboard, please refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and the computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Test the keyboard on another computer to determine if the issue is with the keyboard or the computer system.
- **Backlighting Not Working:**
 - Verify that the backlight is not turned off by pressing **Fn +** .
 - Adjust the brightness using **Fn + PgUp** or **Fn + PgDn**.

- **Multimedia Keys Not Functioning (Mac OS):**

- As stated in the compatibility section, multimedia functions may not be fully supported on Mac OS. This is expected behavior.

- **Keys Feeling Stuck or Unresponsive:**

- Gently remove the keycap and inspect for any debris or obstructions beneath it. Clean if necessary.
- Ensure the keycap is properly seated on the switch.

SPECIFICATIONS

| | |
|--------------------------------|--|
| Brand | WisFox |
| Model Number | B07TMPL269 |
| Connectivity Technology | Wired USB |
| Keyboard Layout | QWERTY |
| Number of Keys | 105 |
| Anti-Ghosting | 19 keys |
| Multimedia Keys | 12 combinations |
| Backlight | Rainbow LED, RGB support, permanent and breathing modes |
| Material | Full Metal Panel |
| Durability | Over 10,000,000 keystrokes |
| Special Features | Splash-resistant, Shortcut keys, Multimedia keys, Backlit |
| Compatibility | Windows 95/98/XP/2000/ME/VISTA/7/8/10, Mac OS (limited multimedia) |
| Cable Length | 6 feet (approx. 1.8 meters) |
| Color | Black |
| GTIN/UPC | 738678075425 |

WARRANTY AND SUPPORT

Specific warranty details are not provided within this manual. For information regarding warranty coverage, returns, or technical support, please refer to the documentation included with your purchase or contact the retailer or manufacturer directly. Keep your proof of purchase for any warranty claims.