

Decathlon 2697569

Decathlon Pongori TTR 500 Table Tennis Bat Instruction Manual

This manual provides essential information for the proper use, care, and maintenance of your Decathlon Pongori TTR 500 Table Tennis Bat.

1. PRODUCT OVERVIEW

The Decathlon Pongori TTR 500 is an all-round table tennis bat designed for regular play, offering a balance of control, spin, and speed. Its construction is optimized for versatile playing styles, allowing players to adapt to various game situations.



Figure 1: Front view of the Decathlon Pongori TTR 500 Table Tennis Bat, showcasing the red rubber and handle design.

Key characteristics include its ability to facilitate ball control, enabling precise shot placement, and its tacky rubber surface for generating significant spin. This bat is suitable for intermediate players looking to enhance their game.

2. FEATURES

- **Enhanced Ball Control:** Designed to allow players to control the ball effectively and place shots accurately.
- **High Spin Capability:** The tacky rubber surface facilitates the generation of fast spin on the ball.
- **Versatile Play:** Suitable for various playing styles, adapting to offensive and defensive strategies.
- **Durable Construction:** Bat composed of 100% wood, with a protection cover made of 50% Ethylene Vinyl Acetate (EVA).



Figure 2: Angled view highlighting the rubber surface and handle grip, demonstrating the bat's construction.

3. SETUP

The Decathlon Pongori TTR 500 Table Tennis Bat comes pre-assembled and ready for immediate use. No additional setup or assembly is required. Simply remove it from its packaging and protective cover (if included).

1. **Unpacking:** Carefully remove the bat from its packaging.
2. **Inspection:** Before first use, inspect the bat for any visible damage to the rubber or handle.
3. **Protective Film:** If a clear protective film is present on the rubber, gently peel it off before playing. This film is designed to protect the tackiness of the rubber during storage and transport.

4. OPERATING INSTRUCTIONS

Using the Pongori TTR 500 bat involves standard table tennis techniques. Its design supports a balanced approach to the game.

- **Grip:** Hold the bat firmly but comfortably. The handle is designed for a secure grip during play.
- **Control Shots:** Utilize the bat's control characteristics for precise pushes, blocks, and placements.
- **Spin Shots:** Leverage the tacky rubber to impart topspin or backspin on the ball. Brush the ball with a quick motion to maximize spin.
- **Adaptability:** Experiment with different strokes to find the optimal balance between power, control, and spin for your playing style.



Figure 3: Side profile of the bat, illustrating the thickness of the rubber and wood layers.

5. MAINTENANCE AND CARE

Proper maintenance extends the life and performance of your table tennis bat.

- **Cleaning the Rubber:** After each use, gently wipe the rubber surfaces with a damp, soft cloth to remove dust and sweat. For stubborn dirt, use a specialized table tennis rubber cleaner. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the bat in a protective cover or case when not in use. This prevents dust accumulation and protects the rubber from damage and loss of tackiness.
- **Temperature and Humidity:** Avoid exposing the bat to extreme temperatures or high humidity, as this can affect the wood and rubber properties.
- **Avoid Impact:** Protect the bat from impacts or drops, which can damage the wood blade or rubber.



Figure 4: Rear view of the bat, showing the handle and the reverse side of the rubber.

6. TROUBLESHOOTING

Most issues with a table tennis bat relate to wear and tear or improper care. Here are some common observations and solutions:

- **Loss of Tackiness/Spin:** This is typically due to dust, dirt, or natural wear of the rubber. Clean the rubber thoroughly with a specialized cleaner. If the rubber is old and worn, replacement may be necessary.
- **Reduced Control:** Can be a symptom of worn rubber or damage to the blade. Inspect the bat for any visible damage. Ensure the rubber is clean.
- **Handle Discomfort:** If the handle feels uncomfortable or slippery, ensure your hands are dry during play. Over-grips can be applied for personalized comfort, though not typically needed for this model.

If you experience persistent issues not covered here, please refer to the warranty and support section.

7. SPECIFICATIONS

Attribute	Value
Brand	Decathlon
Model Number	2697569
Sport	Table Tennis
Skill Level	Intermediate
Frame Material	Wood (100%)
Protection Cover Material	Ethylene Vinyl Acetate (EVA) (50%)

Attribute	Value
Item Weight	179 Grams
Age Range (Description)	Youth, Teen, Kid



Figure 5: Detail of the bat handle, showing the Pongori branding and TTR 500 model designation.

8. WARRANTY AND SUPPORT

Your Decathlon Pongori TTR 500 Table Tennis Bat comes with a **2-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

The warranty does not cover damage resulting from misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

For warranty service, technical support, or any inquiries regarding your product, please contact Decathlon customer service:


Online Support: Visit the official [Decathlon India website](#) for contact information and support resources.

In-Store Support: Visit your nearest Decathlon store for assistance.

© 2025 Decathlon. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - 2697569

	<p>PONGORI PPT 530 M Outdoor Table Tennis Table Assembly Instructions</p> <p>Detailed assembly instructions for the PONGORI PPT 530 M outdoor table tennis table. Includes parts list, step-by-step guidance, and setup information for safe and correct assembly.</p>
	<p>Decathlon Pongori BT 500 US Billiard Table Assembly Instructions</p> <p>Detailed assembly instructions for the Decathlon Pongori BT 500 US foldable billiard table. Includes parts list and step-by-step assembly guide.</p>
	<p>DECATHLON PONGORI BF 500 Foosball Table Assembly Instructions</p> <p>Step-by-step assembly guide for the DECATHLON PONGORI BF 500 foosball table, detailing all components and assembly procedures for a complete setup.</p>




Guide d'utilisation du podomètre GEONAUTE ONwalk 500

Découvrez comment utiliser votre podomètre GEONAUTE ONwalk 500. Ce guide couvre la présentation, les premiers réglages, l'utilisation, la notification d'objectifs et les précautions d'usage.



Domyos Treadmill W900: Care, Storage, and Maintenance Guide

Comprehensive guide for the Domyos Treadmill W900, covering essential care, safe storage, usage tips, and maintenance procedures to ensure optimal performance and longevity.



[Notice d'information : Contrat d'assurance Fitness DECATHLON Extension de garantie 3 ans](#)

Ce document détaille les conditions générales du contrat d'assurance Fitness DECATHLON Extension de garantie 3 ans (ICIDKTFIT24), couvrant votre équipement sportif. Il explique les garanties, exclusions, procédures de sinistre, renonciation et résiliation, avec les informations sur DECATHLON et Evy.