

Manuals.plus /

- › [UpStart Components](#) /
› UpStart Components 6912A40002E Microwave Oven Light Bulb Replacement Manual

UpStart Components ALB-6912A40002E-6PK-DL32

UpStart Components 6912A40002E Microwave Oven Light Bulb Replacement Manual

Model: ALB-6912A40002E-6PK-DL32 | Brand: UpStart Components

1. INTRODUCTION

This manual provides essential information and instructions for the UpStart Components 6912A40002E Microwave Oven Light Bulb. This product is designed as a direct replacement for various microwave oven models, including Kenmore/Sears 72180833500 and LG 6912A40002E compatible bulbs. Please read this manual thoroughly before installation to ensure safe and correct usage.

2. SAFETY INFORMATION

Always prioritize safety when working with electrical appliances. Failure to follow these safety guidelines may result in electric shock, injury, or damage to the appliance.

- **Disconnect Power:** Before attempting any installation or replacement, always unplug the microwave oven from the power outlet or turn off the circuit breaker to prevent electric shock.
- **Handle with Care:** Light bulbs can be fragile. Handle the new bulb carefully to avoid breakage. Avoid touching the glass portion of the bulb directly with bare hands, as oils can reduce bulb life.
- **Verify Compatibility:** Ensure the replacement bulb specifications (voltage, wattage, base type) match the original bulb and your microwave oven's requirements.
- **Proper Disposal:** Dispose of old bulbs according to local regulations.

3. PRODUCT OVERVIEW

The UpStart Components 6912A40002E Microwave Oven Light Bulb is a high-quality replacement part engineered for lasting performance. It features a G8 base type and operates at 20 watts and 120 volts, ensuring compatibility with specified microwave models.



UPStart

Components



Image 1: A pack of six UpStart Components 6912A40002E microwave oven light bulbs, showcasing their compact design and G8 base.

4. INSTALLATION INSTRUCTIONS

Follow these steps to safely replace the microwave oven light bulb:

1. **Disconnect Power:** Unplug the microwave oven from the wall outlet. This is a critical safety step.
2. **Locate Bulb Access:** Depending on your microwave model, the light bulb may be accessible from the interior of the oven, behind a vent grille, or from the back panel. Consult your microwave oven's original manual if you are unsure.
3. **Remove Cover (if applicable):** If the bulb is behind a cover (e.g., a glass lens or a metal panel), carefully remove it. This may involve unscrewing fasteners or prying gently with a flat-head screwdriver.
4. **Remove Old Bulb:** Gently pull the old bulb straight out from its socket. If it's a screw-in type, unscrew it counter-clockwise.
5. **Insert New Bulb:** Align the pins of the new UpStart Components 6912A40002E bulb with the holes in the socket. Gently push the bulb straight into the socket until it is firmly seated. Do not force it.



Image 2: A detailed view of a single 6912A40002E bulb, highlighting its G8 base for proper insertion.

6. **Replace Cover:** Reattach any covers or panels that were removed, ensuring they are securely fastened.
7. **Restore Power:** Plug the microwave oven back into the power outlet.
8. **Test:** Turn on the microwave oven and check if the new light bulb illuminates correctly.

5. MAINTENANCE

The UpStart Components 6912A40002E light bulb is designed for durability and does not require routine maintenance. Replace the bulb only when it burns out. The lifespan of a bulb can vary based on usage patterns.

6. TROUBLESHOOTING

If the new light bulb does not illuminate after installation, consider the following:

- **No Power:** Ensure the microwave oven is properly plugged in and receiving power. Check your household circuit breaker.
- **Improper Installation:** Verify that the bulb is fully and correctly seated in its socket. Remove and reinsert if necessary, ensuring pins are aligned.
- **Faulty Bulb:** Although rare, a new bulb can sometimes be faulty. If you have multiple bulbs, try another one from the pack.
- **Microwave Issue:** If multiple bulbs fail to work, there might be an issue with the microwave oven's socket or wiring. In this case, professional service may be required.

7. SPECIFICATIONS

Feature	Specification
Model Number	ALB-6912A40002E-6PK-DL32
Part Number	6912A40002E
Brand	UpStart Components
Wattage	20 Watts
Voltage	120 Volts
Base Type	G8
Shape	Bulb
Unit Count	6 Count
Compatibility	Kenmore/Sears 72180833500, LG 6912A40002E

8. WARRANTY AND SUPPORT

This product is offered by UpStart Components. Any warranties for this product are provided solely by UpStart Components. For support, warranty claims, or further assistance, please refer to the contact information provided with your purchase or visit the official UpStart Components website.

Please note: This is an UpStart Components Brand replacement part and is not an OEM product. All mentions of other brand names or model descriptions are made strictly to illustrate compatibility.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07TPQX12R>

More documents and user manuals: <https://manuals.plus/>