EGLO 203387A

EGLO Barbotto 203387A LED Table Lamp User Manual

Model: 203387A

INTRODUCTION

Thank you for purchasing the EGLO Barbotto 203387A LED Table Lamp. This manual provides essential information for the safe and efficient use of your new lighting fixture. Please read these instructions carefully before assembly and operation, and retain them for future reference.

The EGLO Barbotto 203387A is a modern LED table lamp featuring a matte black exterior finish with a silver interior, designed to provide ambient lighting for indoor spaces such as living rooms, bedrooms, dorms, and offices.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and personal injury.

- **Indoor Use Only:** This lamp is designed for indoor, dry locations. Do not use it in wet or damp environments.

- **Electrical Connection:** Ensure the power outlet matches the lamp's voltage (120 Volts). Always plug the lamp into a properly grounded outlet.

- **Power Cord:** Do not place the power cord near heat sources. Do not operate the lamp with a damaged cord or plug.

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth. Do not use liquid or abrasive cleaners.

- **Bulb Replacement:** This lamp uses integrated LED lighting. Do not attempt to replace the LED light source yourself. Contact qualified personnel for service.

- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x EGLO Barbotto 203387A LED Table Lamp Unit
- 1 x Power Cord with In-Line Switch (attached)
- 1 x User Manual (this document)

SETUP AND ASSEMBLY

Assembly is required for this product. Follow these steps to set up your lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, flat, and soft surface to prevent scratches.

2. **Base Assembly (if separate):** If the lamp base is separate from the main body, securely attach it according to the included diagrams (if any). Ensure all connections are tight.

3. **Positioning:** Place the lamp on a stable, flat surface in your desired indoor location. Ensure it is away from water sources and excessive heat.

4. **Power Connection:** Plug the lamp's power cord into a standard 120V AC wall outlet. The plug format is A-US style.

Image: The EGLO Barbotto 203387A LED Table Lamp positioned on a desk, illustrating typical placement.

Image: The EGLO Barbotto 203387A LED Table Lamp on a bedside table, demonstrating its use in a bedroom setting.

OPERATING INSTRUCTIONS

The EGLO Barbotto 203387A LED Table Lamp is simple to operate.

1. **Power On/Off:** Locate the in-line switch on the power cord. Press the switch to turn the lamp ON or OFF.

2. **Non-Dimmable:** This lamp is non-dimmable. It operates at a single brightness level when turned on.

3. **Light Output:** The lamp provides an up/down light effect, illuminating both upwards and downwards from its cylindrical design.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Before cleaning, always unplug the lamp from the power outlet. Use a soft, dry, lint-free cloth to wipe the exterior surfaces. Do not use harsh chemicals, abrasive cleaners, or sprays, as these can damage the finish or electrical components.

- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.
- **LED Light Source:** The LED light source is integrated and not user-replaceable. Do not attempt to open the lamp housing.

TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet. Lamp not plugged in correctly. In-line switch is off. Damaged power cord or internal wiring.	Check if the outlet is working by plugging in another device. Ensure the plug is fully inserted into the outlet. Press the in-line switch to the 'ON' position. If cord is damaged, discontinue use and contact support.
Light flickers.	Loose connection. Power fluctuations.	Ensure the plug is securely seated in the outlet. Try plugging the lamp into a different outlet.
Lamp is hot to the touch.	Normal operation (LEDs generate some heat). Poor ventilation.	Ensure the lamp is placed in an area with adequate air circulation. If excessively hot, unplug and contact support.

If these solutions do not resolve the issue, please contact EGLO customer support for further assistance.

SPECIFICATIONS

Detailed technical specifications for the EGLO Barbotto 203387A LED Table Lamp:

Image: Dimensional diagram of the EGLO Barbotto 203387A LED Table Lamp.

Model Name	203387A
Brand	EGLO
Product Dimensions	4"D x 4"W x 16"H (15.5-Inch Height)
Item Weight	2.58 Pounds
Lamp Type	Table Lamp
Light Source Type	LED (Integrated)
Wattage	10 watts
Voltage	120 Volts
Power Source	Corded Electric

Switch Type	In-Line Switch
Dimmable	No
Shade Color	Black (exterior), Silver (interior)
Material	Alloy Steel, Glass (shade)
Indoor/Outdoor Usage	Indoor Only
Assembly Required	Yes
Plug Format	A- US style

WARRANTY

The EGLO Barbotto 203387A LED Table Lamp comes with a**1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

SUPPORT AND CONTACT INFORMATION

For technical assistance, warranty claims, or any questions regarding your EGLO Barbotto 203387A LED Table Lamp, please contact EGLO customer support:

- **Website:** Visit the official EGLO website for support resources and contact details.
- **Customer Service:** Refer to the contact information provided on your product packaging or the EGLO website.

When contacting support, please have your model number (203387A) and proof of purchase readily available.