Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tosuny AR-RAH1E AR-RAH2E

Tosuny Remote Control Instruction Manual

For Fujitsu AR-RAH1E and AR-RAH2E Air Conditioning Units

Introduction

This manual provides comprehensive instructions for the Tosuny replacement remote control, designed for use with Fujitsu AR-RAH1E and AR-RAH2E air conditioning units. Please read this manual carefully before using the remote control to ensure proper operation and longevity of the device.



Image: The Tosuny remote control, specifically designed for Fujitsu air conditioning units.

The remote control is constructed from high-quality ABS material, ensuring durability and resistance to wear for extended use. It offers a reliable replacement for your original or lost Fujitsu air conditioner remote.



Image: Close-up of the remote control, highlighting its durable ABS construction.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the release tab and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. **Note: AAA batteries are not included with the remote control.**
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: The remote control with its battery compartment open, illustrating the insertion of two AAA batteries.



Image: A detailed view of the open battery compartment, ready for battery insertion.

Operating Instructions

The remote control operates via infrared signals. Ensure a clear line of sight between the remote control and the air conditioning unit's receiver. The effective operating distance is typically greater than 8 meters, depending on environmental factors and the specific air conditioner model.



Image: A hand holding the remote control, pointing towards an active air conditioning unit.

Basic Functions

- **START/STOP Button:** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Cycles through operating modes such as Auto, Cool, Dry, Fan, and Heat.
- **SET TEMP Buttons (Up/Down Arrows):** Adjusts the desired temperature setting.
- **FAN Button:** Controls the fan speed (e.g., Low, Medium, High, Auto).
- **SWING Button:** Activates or deactivates the air deflector swing function.
- **TIMER MODE Button:** Used to set the ON/OFF timer for the air conditioner.
- **CLOCK ADJUST Button:** Sets the current time on the remote's display.
- **MIN.HEAT / ECONOMY / SLEEP Buttons:** Activates specific functions for minimum heating, energy-saving mode, or sleep mode, respectively.



Image: A hand demonstrating how to press buttons on the remote control.

Temperature Display

Please note that some units of this remote control may display temperature in Fahrenheit (°F) by default. Based on user feedback, there may not be a direct method to switch the display to Celsius (°C) on all units. Users have reported varying experiences regarding this functionality.

Maintenance

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's finish or internal components.

Battery Replacement

Replace the AAA batteries when the remote control's display becomes dim or when the remote fails to operate the air conditioner from a normal distance. Always replace both batteries simultaneously with new ones of the same type. Remove batteries if the remote control will not be used for an extended period to prevent leakage.

Troubleshooting

- **Remote control not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there is a clear line of sight between the remote control and the air conditioner's infrared receiver. Remove any obstructions.
  - Confirm that the remote control is compatible with your specific Fujitsu air conditioner model (AR-RAH1E or AR-RAH2E).
- **Temperature display in Fahrenheit (°F) only:**
  - Some units of this remote control are designed to display temperature only in Fahrenheit. There may not be an option to switch to Celsius. This is a characteristic of certain production batches.

Specifications

Brand	Tosuny
Model Name	AR-RAH1E AR-RAH2E
Compatible Devices	Fujitsu Air Conditioners (AR-RAH1E, AR-RAH2E)
Connectivity Technology	Infrared
Maximum Range	8+ meters
Material	ABS
Battery Type	2 x AAA (not included)
Number of Buttons	7
Special Feature	Ergonomic design
Item Weight	82.25 Grams

Warranty and Support

Specific warranty information for this Tosuny remote control is not provided in the product details. For any warranty claims or technical support, please refer to the retailer or the point of purchase. Keep your purchase receipt as proof of purchase.

© 2024 Tosuny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TSWHZLG

More documents and user manuals: **https://manuals.plus/**