

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Best Choice Products](#) /
- › [Best Choice Products Kids 3-in-1 Sand & Water Table Instruction Manual](#)

### Best Choice Products SKY5313

# Best Choice Products Kids 3-in-1 Sand & Water Table Instruction Manual

Model: SKY5313

## INTRODUCTION

---

This manual provides essential information for the safe and proper assembly, operation, and maintenance of your Best Choice Products Kids 3-in-1 Sand & Water Table. Please read all instructions carefully before use and retain this manual for future reference.

This versatile outdoor table is designed to function as a picnic table, a sand table, or a water table, offering multiple play and dining options for children. It features a durable hemlock wood construction and an adjustable umbrella for shade.



Image: The Best Choice Products Kids 3-in-1 Sand & Water Table in its full configuration, featuring the green and white striped umbrella, two blue activity bins, and various sand and water play accessories. The table is constructed from natural wood.

## SAFETY INFORMATION

---

**WARNING:** Not for children under 3 years old. Adult supervision is required at all times when children are using the table, especially during water play.

- Ensure all components are securely fastened before use.
- Do not allow children to stand on the table or benches.
- Regularly inspect the table for loose parts, damage, or wear. Discontinue use if any damage is found.
- Place the table on a flat, stable surface to prevent tipping.
- When using as a water table, ensure water levels are appropriate for the child's age and ability, and always empty

water after use to prevent drowning hazards and mosquito breeding.

- When using as a sand table, ensure play-grade sand is used.
- The umbrella provides shade but does not offer complete UV protection. Always use additional sun protection for children.
- Keep small parts away from young children to prevent choking hazards.

## SETUP AND ASSEMBLY

---

The Best Choice Products Kids 3-in-1 Sand & Water Table requires assembly. An Assembly Guide is included with your product. Please follow the step-by-step instructions provided in the guide for proper and safe assembly.

### Tools Required:

- Hammer
- Screwdriver

### Assembly Tips:

- Unpack all components and verify against the parts list in the Assembly Guide.
- Assemble on a soft, clean surface to prevent scratching the wood.
- Do not overtighten screws during initial assembly; tighten all fasteners once the structure is complete.
- Ensure all wooden pieces are correctly oriented as per the diagrams in the Assembly Guide.

# PRODUCT DIMENSIONS




Image: A diagram illustrating the overall dimensions of the Best Choice Products Kids 3-in-1 Sand & Water Table. The table measures 38 inches in length, 37.75 inches in width, and 19.5 inches in height. The adjustable umbrella height ranges from 43.5 to 66.5 inches, with a diameter of 51.25 inches.

## OPERATING INSTRUCTIONS

### 3-in-1 Functionality:

The table is designed for versatile use. The main tabletop can be removed to reveal two plastic activity bins underneath, allowing for conversion between a picnic table, a sand table, or a water table.

- **Picnic Table Mode:** Keep the wooden tabletop in place. This configuration provides a flat surface for dining, drawing, or other activities. The benches can comfortably seat up to 4 children.
- **Sand Table Mode:** Remove the wooden tabletop. Fill one or both blue plastic bins with play-grade sand. Ensure sand is dry before storing the table.
- **Water Table Mode:** Remove the wooden tabletop. Fill one or both blue plastic bins with water. Always supervise children during water play and empty the bins completely after use.

# 3-in-1 Design

Remove the table top to switch between a picnic set, a sand table, or a water table!



Sand Table

OR



Water Table



Image: A visual representation of the table's 3-in-1 design. It shows the wooden tabletop in place for picnic use, and then removed to reveal two blue bins for sand or water play. The image highlights the versatility of the product.

## Adjustable Umbrella:

The included umbrella provides shade and can be adjusted in height. Use the simple release system to raise or lower the umbrella to the desired position for optimal sun protection.

- To adjust height: Locate the hook and latch system on the umbrella pole. Release the latch, adjust the pole to the desired height, and secure the latch.
- To collapse for storage: Fully lower the umbrella and fold the canopy.

# Adjustable Umbrella

Freely raise and lower the umbrella for maximum coverage throughout the day



Hook & Latch System



Collapsible Umbrella

Image: A diagram illustrating the adjustable height feature of the umbrella. It shows the umbrella pole with a hook and latch system, allowing the umbrella to be raised or lowered between 43.5 inches and 66.5 inches. The image also shows the umbrella in a collapsed state for storage.



## Perfect For Sunny Days

Turn a sunny afternoon into hours of small outdoor dining, play, and activities!

Image: Two children, a boy and a girl, are shown happily playing at the Best Choice Products Kids 3-in-1 Sand & Water Table outdoors near a swimming pool. The umbrella provides shade, and the table is configured for sand and water play with toys in the bins.

## MAINTENANCE

---

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth and mild soap as needed. For the plastic bins, wash with soap and water. Ensure all parts are dry before storage to prevent mold or mildew.
- **Wood Care:** The table is crafted from hemlock wood. To prolong its lifespan and maintain its appearance, consider applying a wood sealant annually, especially if exposed to harsh weather conditions.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability and safety.
- **Storage:** When not in use for extended periods, especially during off-seasons, store the table in a dry, covered area to protect it from extreme weather. The umbrella can be collapsed for compact storage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Table feels wobbly or unstable.	Loose fasteners or uneven assembly.	Check and tighten all screws and bolts. Ensure the table is placed on a flat, level surface. Review assembly steps in the manual.
Umbrella does not stay at desired height.	Latching mechanism is not fully engaged or is damaged.	Ensure the hook and latch system is securely fastened. Inspect the mechanism for any obstructions or damage.
Wood appears faded or weathered.	Prolonged exposure to sun and elements without protection.	Clean the wood and apply a suitable outdoor wood sealant or stain. Store in a covered area when not in use.
Plastic bins are difficult to remove or insert.	Debris in the slots or bins are not aligned correctly.	Clear any debris from the slots. Ensure the bins are aligned properly before attempting to slide them in or out.

## PRODUCT SPECIFICATIONS

<b>Brand:</b>	Best Choice Products
<b>Model Name:</b>	3-in-1 Kids Sand & Water Table Outdoor Wood Picnic Table w/ Umbrella
<b>Model Number:</b>	SKY5313
<b>UPC:</b>	842957117772
<b>Color:</b>	Green (Umbrella) / Natural Wood (Table)
<b>Material Type:</b>	Hemlock Wood (Frame, Top), Plastic (Bins), Polyester (Umbrella)
<b>Overall Dimensions (L x W x H):</b>	38" x 37.75" x 19.5"
<b>Umbrella Height Range:</b>	43.5" - 66.5"
<b>Umbrella Diameter:</b>	51.25"
<b>Item Weight:</b>	34 Pounds
<b>Maximum Weight Capacity (per bench):</b>	220 Pounds
<b>Seating Capacity:</b>	4 Children
<b>Recommended Age Range:</b>	Child (3+ years old)
<b>Indoor/Outdoor Usage:</b>	Outdoor
<b>Included Components:</b>	Assembly Guide, Table components, Umbrella, 2 Plastic Trays

# High-Quality Construction

An all-hemlock wood construction in a classic design is built to last for many playdates



Seats 4



220 LBS  
Weight Capacity



Image: An illustration highlighting the high-quality construction of the table, indicating it seats 4 children and has a 220 lbs weight capacity. The image shows the table without the umbrella, emphasizing its sturdy wooden build and the two blue activity bins.

**Certified and Safe**



**Certified materials make this a safe and fun option for playtime!**

Image: A gold seal indicating the product meets U.S. Federal Safety Standards, specifically ASTM F963-17 and CPSIA. This signifies that the materials are certified safe for children's use.

## **WARRANTY AND SUPPORT**

---

### **Warranty Information:**

Specific warranty details for your Best Choice Products Kids 3-in-1 Sand & Water Table may vary. Please refer to the documentation included with your purchase or visit the official Best Choice Products website for the most current warranty policy.

### **Customer Support:**

For assistance with assembly, missing parts, or any other product-related inquiries, please contact Best Choice Products customer service. You can typically find contact information on the product packaging, the included Assembly Guide, or on the Best Choice Products official website.

For additional resources, you may also refer to the official PDF Instructions for Use available online [Instructions for Use](#)

(PDF)

© 2025 Best Choice Products. All rights reserved.