

[Manuals.plus](#) /

> [Senlesen](#) /

> [Senlesen Freestanding Bathtub Faucet with Hand Shower \(Brushed Nickel\) - Instruction Manual](#)

Senlesen B07PHPGYCF

Senlesen Freestanding Bathtub Faucet with Hand Shower

Model: B07PHPGYCF - Brushed Nickel Finish

[Introduction](#) [Safety Information](#) [Package Contents](#) [Specifications](#) [Setup & Support](#)
[Installation](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#)

1. INTRODUCTION

Thank you for choosing the Senlesen Freestanding Bathtub Faucet with Hand Shower. This manual provides essential information for the safe installation, operation, and maintenance of your new faucet. Please read these instructions thoroughly before installation and keep them for future reference.



Figure 1.1: The Senlesen freestanding bathtub faucet in a brushed nickel finish, positioned beside a white freestanding bathtub. The faucet features a single handle and a hand shower.

2. SAFETY INFORMATION

Please observe the following safety precautions during installation and use:

- Always turn off the main water supply before beginning any installation or maintenance.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Do not use harsh chemicals or abrasive cleaners on the faucet finish.
- Protect the faucet from freezing temperatures to prevent damage.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Freestanding Faucet Body with Spout and Handle
- Hand Shower
- Hot & Cold Water Supply Lines (3/8" Connector)
- Base Cover
- Mounting Hardware (including tripod base and screws)
- Seals and Gaskets



Figure 3.1: This image displays all the individual parts included with the faucet, such as the main faucet body, hand shower, hoses, base cover, mounting hardware, and seals, ready for installation.

4. SPECIFICATIONS

Feature	Specification
Brand	Senlesen
Model Number	B07PHPGYCF
Color	Brushed Nickel
Material	Brass, Ceramic, Nickel
Finish Type	Brushed
Number of Handles	1
Mounting Type	Floor Mount
Overall Height	91 cm (35.5 inches)
Spout Height	87.5 cm (34 inches)
Spout Reach	16.5 cm (6.4 inches)
Item Weight	4.08 Kilograms (8.98 pounds)
Included Components	Base Cover, Handle, Mounting Hardware




Figure 4.1: A detailed diagram illustrating the dimensions of the Senlesen freestanding bathtub faucet, including overall height (35.5 inches), spout height (34 inches), spout reach (6.4 inches), and hand shower hose length (59 inches). Key components like the diverter knob and single handle are also labeled.

5. SETUP & INSTALLATION

This faucet is designed for floor-standing installation. Professional installation is recommended. Ensure you have all necessary tools and materials before starting.

5.1 Pre-Installation Steps

- Turn off the main water supply to your home.

- Clear the installation area and ensure sufficient space around the bathtub.
- Inspect all components for any damage.

5.2 Installation Procedure

1. **Prepare the Floor:** Mark the desired location for the faucet on the floor. Ensure it is stable and level.
2. **Install the Tripod Base:** Secure the brass tripod base to the floor using the provided screws. This base provides stability for the faucet.
3. **Connect Water Supply Lines:** Connect the hot and cold water supply lines (3/8" connectors) to your existing water supply. Use Teflon tape on all threaded connections to ensure a watertight seal.
4. **Attach Faucet Body:** Carefully attach the main faucet body to the tripod base. Ensure the connections for the water supply lines are properly aligned and tightened.
5. **Install Base Cover:** Slide the decorative base cover over the faucet body to conceal the mounting hardware.
6. **Connect Hand Shower:** Attach the hand shower hose to the designated outlet on the faucet body.
7. **Leak Test:** Slowly turn on the main water supply and check all connections for leaks. Address any leaks immediately by tightening connections.

Note: It is crucial to perform a thorough leak test before completing the installation to prevent potential water damage. Consider installing a drip pan underneath the faucet base as an additional precaution against unnoticed leaks.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the Senlesen Floor Mounted Freestanding Bathtub Faucet in operation, showcasing the water flow from the main spout and the functionality of the hand shower. It provides a visual guide to the faucet's features.

6. OPERATING INSTRUCTIONS

6.1 Main Faucet Operation

- **Turn On/Off:** Lift the single handle to turn on the water flow. Push down to turn off.
- **Adjust Temperature:** Move the single handle left for hot water and right for cold water.
- **Adjust Flow:** The height to which you lift the handle controls the water flow rate.



Figure 6.1: The brushed nickel faucet is shown actively filling a white freestanding bathtub, demonstrating the waterfall-style water flow from the spout.

6.2 Hand Shower Operation

- **Activate Hand Shower:** Pull the diverter knob (located near the main spout) to switch water flow from the main spout to the hand shower.
- **Deactivate Hand Shower:** Push the diverter knob back in to return water flow to the main spout.



Figure 6.2: A close-up of the hand shower, detached from its holder, spraying water. This illustrates its functionality for rinsing or cleaning.

7. MAINTENANCE

7.1 Cleaning the Faucet

- Clean the brushed nickel finish with a soft, damp cloth.
- Use mild soap and water if necessary.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Wipe the faucet dry after cleaning to prevent water spots.

7.2 Hand Shower Care

- After using the hand shower, allow any residual water to drain completely into the tub before placing it back in its holder. This helps prevent dripping onto the floor.

- Periodically check the hand shower hose for kinks or damage.

7.3 Ceramic Disc Cartridge

The faucet is equipped with a durable ceramic disc cartridge designed for long-lasting, reliable performance. No regular maintenance is typically required for the cartridge itself, but if leaks or persistent drips occur from the handle, the cartridge may need inspection or replacement by a qualified professional.

8. TROUBLESHOOTING

If you encounter any issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Pressure	Partially closed shut-off valves, clogged aerator, low household water pressure, or restricted supply lines.	Ensure shut-off valves are fully open. Clean or replace the aerator. Check household water pressure. Inspect supply lines for kinks or blockages. Consult a plumber if the issue persists.
Hand Shower Drips After Use	Residual water in the hose or shower head.	This is common. Allow the hand shower to drain completely into the tub before returning it to its holder.
Faucet Unit Moves/Wobbles	Mounting hardware not sufficiently tightened or inadequate floor support.	Ensure the tripod base and mounting screws are securely fastened to the floor. If the floor structure is insufficient, additional reinforcement may be required. Consult a professional.
Leaks from Connections	Loose connections, worn gaskets, or improper sealing.	Turn off water supply. Tighten all connections. Replace any damaged gaskets or O-rings. Ensure Teflon tape was used on threaded connections.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Senlesen customer service through the retailer where the product was purchased. Please have your model number (B07PHPGYCF) and purchase date available when contacting support.