

[Manuals.plus](#) /

› [Hoover](#) /

› Hoover Power Scrub Deluxe Carpet Cleaner Machine User Manual

Hoover FH50150

Hoover Power Scrub Deluxe Carpet Cleaner Machine User Manual

Models: FH50150, AH30950

INTRODUCTION

Thank you for choosing the Hoover Power Scrub Deluxe Carpet Cleaner Machine. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new carpet cleaner. Please read all instructions carefully before use to ensure optimal performance and longevity of your appliance.



The Hoover Power Scrub Deluxe Carpet Cleaner Machine, shown here with the included Oxy Carpet Cleaning Solution.

IMPORTANT SAFETY INFORMATION

When using an electrical appliance, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury. Always disconnect the appliance from the electrical outlet before servicing.

- Do not immerse the machine in water or other liquids.
- Use only Hoover cleaning solutions designed for carpet cleaners.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without tanks in place.
- Store the machine indoors in a dry place.

WHAT'S INCLUDED

Your Hoover Power Scrub Deluxe Carpet Cleaner Machine package includes the following components:

- Hoover Power Scrub Deluxe Carpet Cleaner Machine (FH50150)
- 50 oz bottle of Oxy carpet cleaning solution (AH30950)
- Sample bottle of cleaning solution
- Stair tool
- Upholstery tool
- Crevice tool

SETUP

Before first use, assemble the unit and prepare it for cleaning.

1. **Handle Assembly:** Insert the handle into the main body of the cleaner until it clicks securely into place.
2. **Fill Clean Water/Solution Tank:** The machine features an Automix Solution Tank. Remove the clean water tank (upper tank) from the unit. Fill the tank with warm tap water to the indicated fill line. Add the recommended amount of Hoover cleaning solution to the solution compartment. Replace the tank securely on the unit.
3. **Check Dirty Water Tank:** Ensure the dirty water tank (lower tank) is empty and properly seated before beginning operation.



Key components of the Hoover Power Scrub Deluxe, including the Automix Solution Tank and Dirty Water Tank.

OPERATION

The Hoover Power Scrub Deluxe is designed for deep cleaning carpets and upholstery. Its lightweight design (less than 19 pounds) allows for easy maneuverability.

Cleaning Carpets

1. **Pre-Clean:** Vacuum the area thoroughly to remove loose dirt and debris.
2. **Select Mode:** Turn the Wash/Rinse dial to 'Wash' for cleaning with solution, or 'Rinse' for rinsing with clean water only.
3. **Apply Solution:** Press the Water/Solution Trigger on the handle while pushing the cleaner forward slowly over the carpet. The Dual V Nozzle ensures even cleaning.
4. **Scrubbing Action:** The SpinScrub Brush System features powerful 360-degree brushes that rotate to deep

clean carpet fibers.

5. **Extract Water:** Release the trigger and pull the cleaner backward slowly over the same area to extract the dirty water. Repeat passes until the water being extracted appears clean.
6. **Faster Drying:** The Heat Force technology applies heated air to the carpet, aiding in faster drying times.



The Hoover Power Scrub Deluxe effectively deep cleans carpets.



SPINSCRUB® BRUSH SYSTEM

TOUGH ON STAINS. GENTLE ON CARPET.

The SpinScrub Brush System provides thorough cleaning action.

FASTER DRYING WITH HEATED CLEANING



Heat Force technology assists in faster drying of cleaned surfaces.

Cleaning Upholstery and Stairs

To clean upholstery, stairs, or other hard-to-reach areas, attach the appropriate tool (stair tool, upholstery tool, or crevice tool) to the hose connection. Follow the same wash and extract steps as for carpets, ensuring not to oversaturate the fabric.

CLEANS MORE THAN JUST YOUR CARPET



The upholstery tool allows for cleaning of furniture and other fabric surfaces.

MAINTENANCE

Regular maintenance ensures your carpet cleaner continues to perform effectively.

After Each Use

- **Empty and Rinse Dirty Water Tank:** Remove the dirty water tank and dispose of the contents. Rinse the tank thoroughly with clean water.
- **Rinse Clean Water/Solution Tank:** If any solution remains, empty and rinse the clean water tank.
- **Clean Nozzle and Brushes:** Remove the DualV Removable Nozzle and rinse it under running water. Check the SpinScrub brushes for any trapped debris (hair, fibers) and clean as necessary.
- **Wipe Down Unit:** Wipe the exterior of the machine with a soft cloth.

Storage

Store the carpet cleaner in a dry, indoor area. Ensure all tanks are empty and clean before storage to prevent odors or mildew.

TROUBLESHOOTING

If you encounter issues with your Hoover Power Scrub Deluxe, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
No spray from nozzle	Clean water tank empty; Solution tank empty; Nozzle clogged.	Refill tanks; Clean nozzle.
Poor suction	Dirty water tank full; Tank lid not sealed; Nozzle clogged; Hose not properly connected.	Empty dirty water tank; Ensure tank lid is secure; Clean nozzle; Reconnect hose securely.
Machine leaks	Tanks not properly seated; Tank seals are dirty or damaged; Machine stored with liquid in tanks.	Ensure tanks are securely in place; Clean or replace tank seals; Always empty tanks before storage.
Brushes not spinning	Debris caught in brushes; Belt broken.	Remove debris from brushes; Contact customer support for belt replacement.

SPECIFICATIONS

Feature	Detail
Model	FH50150
Item Weight	19 Pounds
Manufacturer	Hoover
Country of Origin	China
First Available	July 4, 2019

WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please contact Hoover Customer Service. Refer to your product registration card or the official Hoover website for specific warranty terms and contact details.

Hoover Customer Service: www.hoover.com/support

