

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Best Choice Products](#) /
- › [Best Choice Products 10x10ft Hardtop Gazebo Instruction Manual \(Model SKY5288\)](#)

Best Choice Products SKY5288

Best Choice Products 10x10ft Hardtop Gazebo

MODEL: SKY5288

Important Safety Information

Please read and understand all instructions and safety warnings before assembly and use of this product. Failure to follow these instructions may result in injury or damage to the product.

- **Always secure the gazebo to the ground** using the included stakes before use.
- Do not use the gazebo in windy or stormy conditions. High winds can cause structural damage or collapse.
- Always follow the assembly instructions carefully to ensure the gazebo is properly set up and stable.
- Regularly inspect all connections and fasteners to ensure they remain tight and secure.
- Remove any accumulated snow or heavy debris from the roof to prevent structural strain.

Product Overview

The Best Choice Products 10x10ft Hardtop Gazebo is designed to provide a shaded and protected outdoor space. It features a durable aluminum frame and a hardtop roof, offering protection from sun and light rain. Integrated netting and curtains provide additional versatility.



Image: The assembled 10x10ft Hardtop Gazebo providing a shaded area for outdoor seating.

Key Features:

- **10x10ft Hardtop Roof:** Tinted hardtop roof for sun protection.
- **Spacious Interior:** Accommodates outdoor dining or sofa sets.
- **Zippered Bug Net & Curtains:** Separate netting and rain-resistant curtains for protection and privacy.
- **Heavy-Duty Aluminum Frame:** Sturdy frame designed for longevity, includes stakes for ground securing.

HARD-TOP CONSTRUCTION

A polycarbonate top with an aluminum frame withstands the elements and guarantees long-term use



UV
Blocking



Rust
Resistant



Aluminum
Frame

Image: Detail of the hard-top construction, emphasizing UV blocking, rust resistance, and the aluminum frame material.

Setup and Assembly

Assembly of the gazebo requires at least two adults. It is recommended to set aside several hours for the complete assembly process. Ensure all parts are present and undamaged before beginning.

General Assembly Steps:

- Unpack and Identify Parts:** Carefully unpack all components and verify against the included parts list in your physical manual.
- Assemble Frame:** Follow the step-by-step instructions in your manual to construct the aluminum frame. Pay close attention to the orientation of each piece.
- Install Roof Panels:** Secure the hardtop roof panels according to the manual. Ensure any protective films are removed from both sides of the panels as instructed.
- Attach Curtains and Netting:** Install the bug netting and privacy curtains onto the designated tracks or hooks.

5. **Secure to Ground:** Use the provided stakes to firmly anchor the gazebo to the ground. For additional stability, especially in areas prone to strong winds, consider using alternative anchoring methods suitable for your specific ground type (e.g., concrete anchors for patios).

Note: Some users have reported minor alignment issues with pre-drilled holes during assembly. If encountered, a drill may be used to slightly adjust holes for proper fit. Do not force components if they do not align easily.

Operating Instructions

The gazebo features integrated bug netting and privacy curtains for versatile use.

Using the Netting and Curtains:

- **Opening:** To open the bug netting or curtains, slide them along their respective tracks and secure them to the corner posts using the built-in tie-backs or touch fasteners.
- **Closing:** To close, release the tie-backs and slide the netting or curtains along the tracks until they meet. Use the integrated zippers to fully close the netting for insect protection, or the curtains for privacy and weather protection.

EASILY OPEN GAZEBO

Pull back the bug netting and secure the curtains with built-in touch fasteners



Image: The gazebo with its curtains pulled back and secured, illustrating an open configuration.

EASILY CLOSE GAZEBO

Slide the weather-resistant curtains along the smooth track system to block the wind and rain



Image: The gazebo with its curtains fully closed, demonstrating privacy and protection from elements.

PROTECTIVE NETTING



Flying
Insects



Durable
Polyester



Zipper
Doors

Image: Detail of the protective netting, highlighting its fine mesh and zippered entry points for insect control.

Maintenance

Proper maintenance will extend the life and appearance of your gazebo.

- **Cleaning Frame:** Clean the aluminum frame with a mild soap and water solution. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners.
- **Cleaning Fabric:** The polyester curtains and netting can be spot cleaned with a mild detergent and water. For deeper cleaning, consult the fabric care instructions in your physical manual. Ensure fabrics are completely dry before storing or closing for extended periods to prevent mildew.
- **Roof Care:** Periodically clean the hardtop roof panels to remove leaves, dirt, and other debris. In snowy climates, remove heavy snow accumulation to prevent damage to the roof structure.
- **Seasonal Storage:** While the gazebo is designed for outdoor use, consider disassembling and storing the fabric components (curtains, netting) during harsh winter months or prolonged periods of non-use to prolong their lifespan.

Troubleshooting

- Parts Not Aligning During Assembly:** If holes do not perfectly align, gently adjust the components. In some cases, a drill may be needed to slightly widen a hole for a proper fit. Do not force parts together, as this can cause damage.
- Gazebo Instability:** Ensure all frame connections are securely tightened. Verify that the gazebo is properly anchored to the ground using all provided stakes. In high wind areas, consider additional anchoring methods.
- Water Leaks from Roof:** Check that all roof panels are correctly installed and sealed according to the assembly instructions. Ensure all screws and fasteners on the roof are tight.
- Curtains/Netting Sticking:** Clean the tracks and ensure no debris is obstructing the movement of the curtains or netting. Lubricate tracks with a silicone-based spray if necessary.

Specifications

Feature	Detail
Brand	Best Choice Products
Model Number	SKY5288
Product Dimensions	114.5" L x 112.75" W x 101.5" H
Floor Area	100 Square Feet
Frame Material	Aluminum
Roof Material	Hardtop (Polycarbonate)
Curtain/Netting Material	180g polyester
Item Weight	121.1 Pounds
Water Resistance Level	Water Resistant
Ultraviolet Light Protection	Yes
Assembly Required	Yes



Image: Dimensional diagram of the gazebo, indicating its length, width, and height.

Warranty and Support

For specific warranty details, please refer to the documentation included with your purchase or contact Best Choice Products customer support directly. General support for product inquiries, missing parts, or assembly assistance can be obtained through the manufacturer's official channels.

Contact Information: Please visit the [Best Choice Products Store on Amazon](#) or their official website for the most current support options.