

[Manuals.plus](#) /

› [Philips](#) /

› Philips Premium Air Fryer XXL with Smart Sensing Technology HD9861/99 (Black)

Philips HD9861/99

Philips Premium Air Fryer XXL HD9861/99 User Manual

Model: HD9861/99

INTRODUCTION

Welcome to the user manual for your Philips Premium Air Fryer XXL. This appliance is designed to provide a healthier way to fry, bake, grill, roast, and reheat your favorite meals with little to no added oil. Featuring Smart Sensing Technology and Fat Removal technology, it automatically adjusts time and temperature for perfect results and captures excess fat.

IMPORTANT SAFETY INFORMATION

Read this user manual carefully before you use the appliance and save it for future reference.

- Always place the appliance on a stable, horizontal, and level surface.
- Do not immerse the appliance in water or any other liquid.
- Do not block the air inlet and outlet openings.
- Keep the power cord away from hot surfaces.
- This appliance is intended for household use only.
- Ensure the voltage indicated on the appliance matches your local mains voltage.
- Do not use the appliance if the plug, the main cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning.
- The surfaces may become hot during use. Do not touch hot surfaces. Use handles or knobs.
- Do not operate the appliance with an external timer or separate remote-control system.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Philips Premium Air Fryer XXL.



This image displays the Philips Premium Air Fryer XXL in black with copper accents. The front panel features a digital display for temperature and time, along with touch controls. A prominent copper handle extends from the main body.



This image shows the Philips Premium Air Fryer XXL from a slightly different angle, with the cooking basket handle partially extended, indicating its pull-out design. The digital display shows 200 degrees Celsius and 60 minutes.



This image illustrates the physical dimensions of the Philips Premium Air Fryer XXL, showing its width (40cm), depth (40cm), and height (39cm) for easy placement and storage assessment.

SETUP

1. **Unpacking:** Carefully remove all packaging materials.
2. **Cleaning:** Before first use, clean the basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm of free space above the appliance.
4. **Power Connection:** Plug the main plug into a grounded wall outlet.

OPERATING INSTRUCTIONS

Basic Operation

1. Pull the pan out of the appliance.
2. Place the ingredients in the basket.

3. Slide the pan back into the appliance.
4. Turn the temperature control knob to the desired temperature.
5. Turn the timer knob to the desired preparation time.
6. Press the start/pause button to begin cooking.

Smart Sensing Technology

The Philips Premium Air Fryer XXL features Smart Sensing Technology, which automatically adjusts time and temperature for popular dishes like whole chicken, fries, and fish.

- Select the desired Smart Sensing preset on the control panel.
- The appliance will automatically detect the food quantity and adjust cooking parameters.



This close-up image highlights the digital control panel of the air fryer, specifically showing the selection for cooking fish, demonstrating the Smart Sensing Technology in action.

Cooking Examples



This image shows a whole roasted chicken perfectly cooked inside the air fryer's basket, demonstrating its capacity and capability for larger items.



This image displays a combination of crispy chicken pieces and golden french fries within the air fryer basket, showcasing its versatility for preparing different food types simultaneously.



This image features a vibrant assortment of roasted vegetables inside the air fryer, illustrating its ability to cook healthy side dishes.



This image shows several chicken drumsticks cooked to perfection in the air fryer, highlighting its suitability for various poultry preparations.



Another view of a whole roasted chicken inside the air fryer, emphasizing the spaciousness of the XXL model.

NutriU App Integration

For more recipes and cooking tips, download the NutriU recipe app.

philips.com/nutriu

Includes
NutriU
recipe app
philips.com/nutriu



This image displays a circular green graphic with text "Includes NutriU recipe app" and the Philips NutriU app logo, encouraging users to download the app for recipes.

MAINTENANCE AND CLEANING

Cleaning the Appliance

1. Unplug the appliance and let it cool down completely.
2. Wipe the outside of the appliance with a damp cloth.
3. Clean the pan and basket with hot water, dish soap, and a non-abrasive sponge. The pan and basket are dishwasher-safe.
4. For stubborn food residue, soak the pan and basket in hot water with some dish soap for 10 minutes.
5. Clean the heating element with a cleaning brush to remove any food residue.

Fat Removal Technology

The unique Fat Removal technology separates and captures excess fat from your food, which collects in the bottom of the pan. This fat should be discarded after each use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
The Air Fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Food is not cooked evenly.	Too much food in the basket.	Reduce the amount of food.
White smoke comes out of the appliance.	Fatty ingredients are being cooked.	This is normal for fatty foods. Clean the pan and basket thoroughly after each use.
Fresh fries are not crispy.	Not enough oil used.	Add a bit more oil to the fries before air frying.

SPECIFICATIONS

Feature	Detail
Brand	Philips
Model Number	HD9861/99
Colour	Black
Product Dimensions	40 x 40 x 39 cm
Item Weight	9.1 kg
Capacity	1.4 Kilograms
Power/Wattage	2225 watts
Voltage	240 Volts
Material	Copper
Special Features	Temperature Control, Automatic Shut-Off, Programmable

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included with your product or visit the official Philips website.

You can also visit the Philips store on Amazon for more information:[Philips Store](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question