

[manuals.plus](#) /› [Edifier](#) /› [Edifier TWS5 True Wireless Earbuds User Manual](#)

Edifier TWS5

Edifier TWS5 True Wireless Earbuds User Manual

Model: TWS5

1. INTRODUCTION

Thank you for purchasing the Edifier TWS5 True Wireless Earbuds. These earbuds are designed to provide a superior audio experience with true wireless freedom, extended battery life, and robust features for daily use.

2. PACKAGE CONTENTS

- Edifier TWS5 True Wireless Earbuds (Left & Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Silicone Ear Tips (S, M, L)
- User Manual (this document)

3. PRODUCT OVERVIEW

The Edifier TWS5 earbuds feature a compact, ergonomic design for comfortable wear. Each earbud is equipped with touch controls for easy management of audio playback and calls. The included charging case provides extended battery life and secure storage.



Figure 3.1: Edifier TWS5 Earbuds and Charging Case. The image shows both earbuds, one placed inside the open charging case and the other floating above it, highlighting their compact size and the case's design.



Figure 3.2: Side view of a single Edifier TWS5 earbud, showcasing its ergonomic shape and the Edifier logo on the touch-sensitive surface.

4. SETUP

4.1 Initial Charging

Before first use, ensure both the earbuds and the charging case are fully charged. Place the earbuds into the charging case and connect the case to a USB power source using the provided charging cable. The LED indicators on the case will show charging status.



Figure 4.1: Edifier TWS5 earbuds placed inside their charging case, with red indicator lights visible, signifying that they are charging.

4.2 Bluetooth Pairing

1. Ensure the earbuds are in the charging case and the case has power.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
4. Select "EDIFIER TWS5" from the list of available devices.
5. Once connected, you will hear an audible confirmation, and the LED indicators on the earbuds will change.
6. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

The TWS5 utilizes Bluetooth v5.0 with aptX for stable and high-quality wireless audio transmission.

Your browser does not support the video tag.

Video 4.2: Official product video demonstrating the features of the Edifier TWS5 True Wireless Stereo Earbuds, including their wireless capabilities and design.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The Edifier TWS5 earbuds feature intuitive touch controls on the outer surface of each earbud. Refer to the following table for common operations:

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	-	Double Tap
Previous Track	Double Tap	-
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press	Long Press
Activate Voice Assistant	Triple Tap	Triple Tap

5.2 Single Earbud Use

The Edifier TWS5 earbuds support independent use of either the left or right earbud. Simply remove one earbud from the charging case, and it will automatically connect to your device. The other earbud can remain in the case or be used simultaneously for stereo sound.



Figure 5.1: A person wearing a single Edifier TWS5 earbud, demonstrating its comfortable and discreet fit for individual use.

6. MAINTENANCE

6.1 Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, they can be removed and gently cleaned with mild soap and water, then thoroughly dried before reattaching.

6.2 Water Resistance (IPX5)

The Edifier TWS5 earbuds are rated IPX5, meaning they are protected against low-pressure water jets from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water. Avoid exposing the charging case to water.

7. TROUBLESHOOTING

- **No Sound/Connection Issues:**

- Ensure earbuds and device are charged.
- Verify Bluetooth is enabled on your device.
- Try unpairing and re-pairing the earbuds.
- Ensure earbuds are within the 10-meter Bluetooth range.

- **Only One Earbud Playing:**

- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and remove them simultaneously.
- Ensure both earbuds are charged.

- **Touch Controls Not Responding:**

- Ensure your fingers are clean and dry.
- Try restarting the earbuds by placing them in the case and taking them out.

- **Poor Audio Quality:**

- Ensure ear tips are correctly sized and provide a good seal in your ear canal.
- Clean the ear tips and earbud nozzles.
- Reduce interference by moving away from other wireless devices.

- **Charging Case Not Charging:**

- Check the USB cable and power adapter.
- Ensure the charging port is clean and free of debris.

- **Battery Life Shorter Than Expected:**

- Ensure both earbuds and case are fully charged before use.
- High volume levels can reduce battery life.

- **Water Droplets Triggering Touch Control:**

- Wipe the earbuds dry immediately after exposure to water or sweat.

8. SPECIFICATIONS

Feature	Detail
Model Name	edifier-tws5-black
Connectivity Technology	Wireless (Bluetooth v5.0 with aptX)
Bluetooth Range	Up to 10 meters (30 feet)
Battery Life (Earbuds)	Up to 8 hours (single charge)
Total Playback Time (with Case)	Up to 32 hours
Water Resistance Level	IPX5 (Splash & Sweatproof)
Control Type	Touch Control

Feature	Detail
Frequency Response	20Hz - 20kHz
Item Weight	3.2 ounces
Product Dimensions	2.36 x 0.87 x 1.57 inches
Manufacturer	Edifier
Model Number	96851818999
UPC	875674004605

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Edifier website or contact their customer service directly. Specific warranty terms may vary by region and retailer.

© 2023 Edifier. All rights reserved.