

## Amazon Basics WK130840-2-White

# Amazon Basics 3-Tier Rolling Utility or Kitchen Cart User Manual

Model: WK130840-2-White

## INTRODUCTION

---

Thank you for choosing the Amazon Basics 3-Tier Rolling Utility or Kitchen Cart. This versatile cart is designed for multifunctional use, providing convenient storage and easy mobility for various items. Its durable metal construction and lockable wheels make it suitable for use in kitchens, offices, utility rooms, and more.



Overall view of the Amazon Basics 3-Tier Rolling Utility Cart in white.

## SAFETY INFORMATION

- Do not exceed the maximum weight capacity of the cart. Distribute weight evenly across the shelves.

- Ensure all screws and fasteners are securely tightened before use and periodically check for looseness.
- Always engage the wheel locks when the cart needs to remain stationary to prevent accidental movement.
- Keep hands and fingers clear of moving parts, especially during assembly and when adjusting the cart.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

## PARTS LIST

---

Before beginning assembly, please ensure all the following parts are present and undamaged:

- 3 x Storage Baskets (with mesh bottoms)
- 4 x Vertical Support Poles (2 upper, 2 lower)
- 4 x Caster Wheels (2 with locking mechanism)
- 1 x Base Frame with Handle
- Screws and Allen Wrench (for assembly)



Examples of cart components: pole connection, basket connection, and a caster wheel with its locking mechanism.

## SETUP AND ASSEMBLY

---

Assembly is required. Please follow these steps carefully:

1. **Attach Caster Wheels:** Insert the four caster wheels into the designated holes on the bottom of the base frame. Ensure two of the wheels with locking mechanisms are placed on the same side for easy access.
2. **Connect Lower Vertical Poles:** Attach the two lower vertical poles to the base frame using the provided screws and Allen wrench. Ensure they are firmly secured.
3. **Install Bottom Basket:** Slide the first (bottom) storage basket onto the lower vertical poles and secure it in place with the screws. The mesh bottom should face upwards.
4. **Connect Upper Vertical Poles:** Attach the two upper vertical poles to the top of the lower vertical poles. Secure them with screws.
5. **Install Middle Basket:** Slide the second (middle) storage basket onto the poles and secure it with screws.
6. **Install Top Basket:** Slide the third (top) storage basket onto the upper poles and secure it with screws.
7. **Final Check:** Verify that all screws are tightened and the cart is stable.



## Easy To Move And Meet Different Storage Needs

Bedroom  
Living room  
Kitchen  
Laundry Room

An illustrative diagram showing the various components and their assembly points.

### OPERATING INSTRUCTIONS

#### Moving the Cart

To move the cart, ensure all four caster wheels are unlocked. Use the curved push handle at the top to steer and maneuver the cart to your desired location. The pivoting action of the wheels allows for easy mobility in any direction.

#### Locking the Wheels

To secure the cart in a stationary position, locate the two caster wheels with locking mechanisms. Press down on the lever of each locking wheel until it clicks into the 'ON' or 'LOCKED' position. To unlock, lift the lever back to the 'OFF' or 'UNLOCKED' position.



Detail of the caster wheel showing the lock lever in the 'ON' position.

### MAINTENANCE

Regular maintenance will help prolong the life of your utility cart:

- **Cleaning:** Wipe down the cart with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Dry thoroughly immediately after cleaning to prevent rust.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the painted finish.

- **Wheel Inspection:** Periodically check the caster wheels for any accumulated debris (hair, lint, etc.) that might hinder smooth rolling. Clean as necessary.
- **Fastener Check:** Routinely inspect all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.

## TROUBLESHOOTING

Issue	Solution
Cart does not roll smoothly.	Check caster wheels for debris (e.g., hair, lint) and remove if present. Ensure wheels are properly attached and not damaged.
Cart feels wobbly or unstable.	Verify that all screws and fasteners are securely tightened. Ensure the cart is assembled correctly according to the instructions.
Baskets are not level.	Check that the baskets are fully seated on the support poles and that their securing screws are tightened evenly.

## SPECIFICATIONS

Feature	Detail
Product Dimensions (D x W x H)	13.9" x 18.4" x 31" (35.3 cm x 46.7 cm x 78.7 cm)
Material	Metal
Color	White
Number of Shelves	3
Item Weight	8.6 Pounds (3.9 kg)
Number of Wheels	4 (Swivel Caster Type)
Assembly Required	Yes
Model Number	WK130840-2-White
UPC	745103855880



Detailed dimensions of the Amazon Basics 3-Tier Rolling Utility Cart.

## WARRANTY AND SUPPORT

This product is covered by a warranty. For detailed information regarding the warranty terms and conditions, please refer to the official Warranty PDF document available for download:

[Download Warranty \(PDF\)](#)

For further assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact Amazon Basics customer support. You may also refer to the comprehensive User Manual PDF for additional details:

[Download User Manual \(PDF\)](#)

## Related Documents



3-Tier Reading Ability or Kikano Card

3-Tiered Interactive 3-Tiered or Chapter of Cuisine  
Nato-oro Kikano-Adhikari 1-Digam  
Carnela Sorviretti Paragattoli di la Cacia a 3-Piani  
Cane de Cucina e de Trabajo con Rucola y 3-Wholes  
Kikano-Adhikari de 3-Tiered or 3-Tiered  
Mikoto de Kikano y Trena Mikoto  
Redings med 3-Hyler eller Kikano  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari

3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari  
3-Tiered or Kikano-Adhikari 3-Tiered or Kikano-Adhikari

EN	Page 2	SV	Stroma 14
FR	Page 4	SV	Sala 16
DE	Saite 6	日本	18
IT	Page 8	21 India	24
ES	Page 10		

Comprehensive user manual and assembly guide for the Amazon Basics 3-Tier Rolling Utility or Kitchen Cart. Includes safety instructions, specifications, cleaning, maintenance, delivery content, and assembly steps.



3-Tier Rolling Utility or Kitchen Cart  
 Desserts: Hazards or 3 Etages or Chariot de Cuisine  
 Nuts- or Kitchen-Rollwagen mit 3 Etagen  
 Carrelle Scroverelle Pastry Cart or de Cuisine or 3 Piani  
 Carrelle de Cuisine or de Travailler or 3 Stufen  
 Material- or Kuchwagen mit 3 Valden auf Weiltigen  
 Wägen de Kuchzi or Treppen Pökken  
 Rollwagen mit 3 Hyaler oder Kuchwagen  
 3 階車 (スターバスター) ユーティリティ車 (キッチンカート)  
 R07V126F20, R07TV18F05, R07TV19V36, R07V126F25

EN	.....	Page 2	EN	.....	Page 12
DE	.....	Page 4	DE	.....	Page 14
FR	.....	Page 6	FR	.....	Page 16
IT	.....	Page 8	IT	.....	Page 18
ES	.....	Page 10	ES	.....	Page 20

Comprehensive user manual for the Amazon Basics 3-Tier Rolling Utility or Kitchen Cart, including safety instructions, cleaning, maintenance, specifications, and assembly guides.



3-Tier Metal Rolling Cart	Charlot à Roulettes en Métal à 3 Niveaux		
3-Tier Metal Rolling Cart	Charlot à Roulettes en Métal à 3 Étages		
3-Tier Metal Rolling Cart	Carrello a Scorrere in Metallo a 3 Piani		
3-Tier Metal Rolling Cart	Carrito Metálico de 3 Niveles		
3-Layer Metal Transport Cart	バスターンカート、バスターン台		
3-Pushers Wheel on Kitching	3-Tier Rollage in metal		
R07L955GV			
EN	Page 4	ML	Page 14
FR	Page 6	DE	Page 16
IT	Page 10	ES	Page 20
JP	Page 12	SC	Page 22

Instructions and safety information for the Amazon Basics 3-Tier Metal Rolling Cart, including assembly, cleaning, maintenance, and specifications.



Bar und Kitchen Cart mit Basen  
Chaise de Bar et de Cuisine au Salon  
Bar- und Kichenwagen mit Korb  
Carrelis Bar et Cucina con Cintino  
Carrito de Cocina y Barra con Cesta  
Bar en Keukenkar met Mand  
Barowy i Kuchenny Wózek z Koszem  
Bar- und Kichenwagen mit Korb  
バー・キッチンカート(スケット付)  
عربة المطبخ مزودة بسلة

D071.9F9H29

EN	Page 2	PL	Strona 14
FR	Page 4	SV	Sida 16
DE	Seite 6	DA	Side 18
IT	Page 8	ES	Página 20
CS	Strana 10	RK	Стр. 22

Comprehensive user manual for the Amazon Basics 3-Tier Metal Basket Rolling Cart with Wood Top. Includes assembly instructions, features, usage guidelines, and specifications for this versatile silver storage solution.