

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Beetel](#) /
- › [Beetel BT Headphone SBT668 User Manual](#)

Beetel SBT668

Beetel BT Headphone SBT668 User Manual

Model: SBT668 | Brand: Beetel

INTRODUCTION

Thank you for choosing the Beetel BT Headphone SBT668. This manual provides essential information for the proper setup, operation, and maintenance of your new Bluetooth headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: Front view of the Beetel BT Headphone SBT668, showcasing its over-ear design and black finish.

WHAT'S IN THE BOX

Ensure all items are present upon unboxing:

- Beetel BT Headphone SBT668
- Charging Cable (Micro USB)

SETUP

1. Charging the Headphones

Before first use, fully charge the headphones.

1. Connect the small end of the supplied Micro USB charging cable to the charging port on the headphone.
2. Connect the large end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator on the headphone will illuminate during charging and turn off or change color when fully

charged.

Note: A full charge takes approximately 2 hours. The built-in Li-polymer battery has a capacity of 250mAh.

2. Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device (smartphone, tablet, laptop).

1. Ensure the headphones are turned off.
2. Press and hold the multi-function button (usually the power button) on the headphone until the LED indicator flashes red and blue alternately. This indicates pairing mode.
3. On your device, go to Bluetooth settings and ensure Bluetooth is enabled.
4. Search for available devices. You should see "SBT668" or "Beetel SBT668" in the list.
5. Select "SBT668" to connect. Once connected, the LED indicator on the headphone will typically flash blue slowly or turn solid blue.

Note: The headphones support Bluetooth 5.0 for stable and efficient connection. The operating distance is approximately 10 meters (33 feet) in an open environment.



Image: Side view of the Beetel BT Headphone SBT668, highlighting the ear cup and potential location of control buttons.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the LED indicator flashes blue.
- **Power Off:** Press and hold the multi-function button for approximately 3-5 seconds until the LED indicator flashes red and then turns off.

Music Playback

The headphones offer approximately 6 hours of playing time on a full charge at medium volume.

- **Play/Pause:** Short press the multi-function button.
- **Next Track:** Long press the '+' button (if available, or specific touch control).
- **Previous Track:** Long press the '-' button (if available, or specific touch control).
- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.

Note: The control method is touch-based. Refer to the specific touch areas on your headphone for precise control.

Hands-Free Calling

The headphones feature a built-in microphone for hands-free communication.

- **Answer Call:** Short press the multi-function button when a call comes in.
- **End Call:** Short press the multi-function button during a call.
- **Reject Call:** Long press the multi-function button when a call comes in.
- **Redial Last Number:** Double-press the multi-function button.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The headphones are foldable for compact storage.
- **Battery Care:** To preserve battery life, charge the headphones at least once every three months if not used regularly. Avoid fully discharging the battery frequently.



Image: The Beetel BT Headphone SBT668 shown in its folded configuration, demonstrating its portability and ease of storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Device Bluetooth off; Too far from device.	Ensure headphones are in pairing mode (flashing red/blue). Turn device Bluetooth off and on. Move headphones closer to device (within 10m).
No sound or distorted sound.	Volume too low; Not properly connected; Interference.	Increase volume on both headphones and device. Re-pair the headphones. Move away from other wireless devices.

Problem	Possible Cause	Solution
Charging not working.	Faulty cable or power source.	Try a different charging cable or USB power source.

SPECIFICATIONS




Image: A visual representation of key specifications for the Beitel BT Headphone SBT668, including Bluetooth version, playing time, and battery details.

Feature	Detail
Model Name	BT Headphone
Model Number	SBT668
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	Bluetooth 5.0
Playing Time	Up to 6 hours
Charging Time	Approximately 2 hours
Battery Capacity	250mAh built-in Li-polymer
Control Method	Touch
Microphone	Built-In
Frequency Range	20Hz - 20kHz

Feature	Detail
Impedance	32 Ohm
Item Weight	194 Grams
Product Dimensions	15 x 8.5 x 18.5 cm
Country of Origin	China

WARRANTY AND SUPPORT

The Beetel BT Headphone SBT668 comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, technical support, or any inquiries regarding your product, please contact Beetel customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: Beetel, Brightstar Telecommunications India Limited.