

Tangxi GZ-1002A-E3, GZ-1002B-E1, GZ-1002B-E3, GZ01-BEJ0-000

User Manual for Tangxi Air Conditioner Remote Control

Model: GZ-1002A-E3, GZ-1002B-E1, GZ-1002B-E3, GZ01-BEJ0-000

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Tangxi replacement remote control for Galanz Air Conditioners. This remote is designed to be compatible with specific Galanz models: GZ-1002A-E3, GZ-1002B-E1, GZ-1002B-E3, and GZ01-BEJ0-000. Please read this manual thoroughly before use to ensure proper functionality and extend the lifespan of your device.

SAFETY INFORMATION

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep the remote control away from direct sunlight, heat sources, and moisture.
- Avoid dropping or subjecting the remote control to strong impacts.

PRODUCT OVERVIEW

The Tangxi remote control is a compact and ergonomic device designed for easy handling and intuitive operation of your compatible Galanz air conditioner. It features a clear LCD display and well-labeled buttons for various functions.



Figure 1: Front view of the remote control with its display and buttons.



Figure 2: Front and back views of the remote control, highlighting the battery compartment on the rear.



Figure 3: Detailed views of the remote control's features, including button layout and battery area.

SETUP

Installing Batteries

The remote control requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.



Figure 4: Open battery compartment for AAA battery installation.

Note: Please replace all cells simultaneously with new ones if necessary. Do not use old and new batteries together.

OPERATING INSTRUCTIONS

This remote control is pre-programmed for compatible Galanz air conditioner models. Point the remote control directly at the air conditioner's receiver when operating. The effective remote distance is up to 10 meters (33 feet), though actual distance may vary based on environmental factors and the specific air conditioner model.

THE REMOTE DISTANCE IS UP TO 10M / 33FT

(Actual remote distance depends on the model of your air-con)



Figure 5: Remote control in use, demonstrating effective range.



This is a replacement remote control for Galanz GZ-1002A-E3 GZ-1002B-E1 GZ-1002B-E3 GZ01-BEJ0-000.

Figure 6: Remote control ready for operation with an air conditioner.

Button Functions

Button	Function
I/O (Power)	Turns the air conditioner On or Off.
ON / OFF	Separate buttons for turning the unit On or Off.
OPERATION MODE	Cycles through different operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
SWING	Controls the vertical swing of the air conditioner's louvers.
MANUAL	Likely for manual adjustment or specific manual mode activation.
FAN SPEED	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
SLEEP	Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep.

Button	Function
TIME	Used for setting timer functions (e.g., auto-on, auto-off).
SET	Confirms settings after adjustment (e.g., time, temperature).
CANCEL	Cancels current settings or timer functions.
Temperature Up/Down Arrows	Adjusts the desired temperature setting.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display dims. Always replace both batteries at the same time.
- **Storage:** If storing the remote for an extended period, remove the batteries to prevent corrosion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity.
Remote has short range.	Weak batteries; Obstruction between remote and AC unit.	Replace batteries. Ensure a clear line of sight to the AC unit's receiver.
Remote not controlling AC unit.	Not compatible with your specific AC model; Remote needs reset.	Verify your AC model is listed as compatible. If issues persist, press the "RESET" button (if available, often a small recessed button) for a few seconds.

SPECIFICATIONS

Feature	Detail
Applicable Models	Galanz GZ-1002A-E3, GZ-1002B-E1, GZ-1002B-E3, GZ01-BEJ0-000
Color	White
Shell Material	ABS
Dimensions (L*W*H)	Approx. 15.0 cm * 5.5 cm * 1.5 cm (5.9 in * 2.2 in * 0.6 in)
Weight	Approx. 70g (2.46 ounces)
Remote Control Distance	Up to 10 meters (33 feet)
Battery Type	2 * AAA batteries (NOT included)
Power	DC 3V
Special Feature	Ergonomic design

SIZE



Figure 7: Remote control dimensions.

WARRANTY AND SUPPORT

This product is typically covered by a standard return policy. For specific warranty details or technical support, please refer to the seller's information on the purchase platform or contact Tangxi customer service directly. Ensure you have your purchase details readily available when seeking support.

For further assistance, you may visit the [Tangxi Store on Amazon](#).

© 2024 Tangxi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I set the Tangxi GZ-1002A-E3 air conditioner remote to run for 4 hours and then turn off automatically?

To set your air conditioner to turn off automatically after 4 hours using the Tangxi GZ-1002A-E3 remote control, follow these steps: Turn the unit ON: Ensure the air conditioner is currently running. Press the...

[Read full answer](#)

How do I set the Tangxi GZ-1002A-E3 air conditioner remote to run for 4 hours and then turn off automatically?

To set your air conditioner to turn off automatically after 4 hours using the Tangxi GZ-1002A-E3 remote control, follow these steps: Turn the unit ON: Ensure the air conditioner is currently running. Press the...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B07V1N5JFD>

More documents and user manuals: <https://manuals.plus/>