

[Manuals.plus](#) /

› [Relaxdays](#) /

› Relaxdays 10026609_46 Trouser Hangers Instruction Manual

Relaxdays 10026609_46

Relaxdays 10026609_46 Trouser Hangers Instruction Manual

Model: 10026609_46

INTRODUCTION

Thank you for choosing the Relaxdays 10026609_46 Trouser Hangers. This set of 10 versatile hangers is designed to help organize your wardrobe efficiently. Featuring adjustable non-slip plastic clips and a 360-degree rotating metal hook, these hangers are suitable for trousers, skirts, and other garments, providing a practical solution for clothing storage.



Image: Relaxdays trouser hangers in use.

SETUP INSTRUCTIONS

The Relaxdays trouser hangers come pre-assembled and are ready for immediate use. No additional assembly is required.

1. **Unpack:** Carefully remove the hangers from their packaging.
2. **Inspect:** Before first use, inspect each hanger for any signs of damage. If any hanger is damaged, do not use it.

OPERATING INSTRUCTIONS

These hangers are designed for easy and flexible use with various garments.

Using the Adjustable Clips:

- **Adjusting Clip Position:** The two plastic clips on each hanger can slide horizontally along the bar. To adjust, simply

slide the clips to the desired width to accommodate your garment.

- **Attaching Garments:** Squeeze the clips to open them. Place the garment (e.g., waistband of trousers or skirt) between the jaws of the clip and release to secure. Ensure the garment is held firmly but not excessively pinched to avoid marks.
- **Non-Slip Feature:** The clips are designed with a non-slip surface to prevent garments from sliding off.



Image: Detail of the adjustable non-slip clip.

Utilizing the Rotating Hook:

- The metal hook is designed to rotate 360 degrees. This allows you to orient your garments in any direction on a wardrobe rail for easy access and viewing.
- Simply turn the hook to adjust the hanger's direction as needed.



Image: The 360-degree rotating metal hook.

Recommended Use:

- Ideal for hanging trousers, skirts, shorts, and other items that can be securely held by clips.
- For heavier garments like thick jeans, ensure the clips are positioned optimally to distribute weight and prevent slippage.



Image: Trousers and shorts organized on hangers.



Image: Skirts and scarves organized on hangers.

MAINTENANCE

To ensure the longevity and optimal performance of your Relaxdays trouser hangers, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the hangers with a soft, damp cloth to remove dust or dirt. Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic or metal components.
- **Drying:** Ensure the hangers are completely dry before storing or using them to prevent any potential rust on the metal hook.
- **Storage:** Store hangers in a dry environment, away from direct sunlight or extreme temperatures, which could affect the plastic material.

TROUBLESHOOTING

If you encounter any issues with your Relaxdays trouser hangers, consider the following common solutions:

Problem	Possible Cause	Solution
Garment slips from clips	Clips not fully closed, garment too heavy, or fabric too slippery.	Ensure clips are firmly closed. For heavier items, use two clips per garment and position them closer to the edges for better grip. For very delicate or slippery fabrics, consider folding them over the hanger bar if suitable, or use alternative hanging methods.
Hanger appears flimsy or bends	Overloading the hanger with excessively heavy items.	These hangers are designed for standard trousers and skirts. Avoid hanging multiple heavy items on a single hanger. If a hanger is damaged, discontinue use.
Clips are stiff or difficult to slide	Accumulation of dust or debris in the sliding mechanism.	Clean the hanger and the sliding tracks of the clips with a damp cloth. Ensure no foreign objects are obstructing the movement.

PRODUCT SPECIFICATIONS

Detailed specifications for the Relaxdays 10026609_46 Trouser Hangers:

- **Model Number:** 10026609_46
- **Quantity:** Set of 10 hangers
- **Dimensions (H x W x D):** Approximately 14 x 36 x 3 cm (5.5 x 14.2 x 1.2 inches)
- **Weight per hanger:** Approximately 40 g (0.09 lbs)
- **Material:** Plastic (clips and bar), Metal (hook)
- **Color:** Black
- **Special Features:** Flexible, Rotatable (360° hook), Space-saving, Adjustable clips, Non-slip
- **Recommended Use:** Skirts, Trousers
- **Country of Origin:** Germany



Image: Hanger dimensions diagram.

WARRANTY AND SUPPORT

Specific warranty information for the Relaxdays 10026609_46 Trouser Hangers is not provided in the product details. For any inquiries regarding warranty, product support, or to report a defect, please contact the manufacturer, Relaxdays, directly or refer to the retailer's return policy.

You may also find additional safety information in the provided PDF document:[Safety Information \(PDF\)](#).

© 2023 Relaxdays. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question