



Manuals.plus /

› Easytry123 /

› Easytry123 Replacement Remote Control Instruction Manual for Mistral Air Conditioners

Easytry123 GZ01-BEJ0-000, MSS2.0KW, MSS2.6KW, MSS3.3KW, MSS4.8KW, MSS6.5KW

Easytry123 Replacement Remote Control Instruction Manual

Model: GZ01-BEJ0-000, MSS2.0KW, MSS2.6KW, MSS3.3KW, MSS4.8KW, MSS6.5KW

Brand: Easytry123

1. INTRODUCTION

This document provides essential instructions for the setup, operation, and maintenance of your Easytry123 replacement infrared remote control. This remote is designed to function with specific Mistral A/C Air Conditioner models.

Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

2. PRODUCT OVERVIEW

The Easytry123 replacement remote control is an infrared device designed for ease of use. Its ergonomic design ensures comfortable handling.



Figure 2.1: Front view of the remote control. This image displays the primary buttons and the overall shape of the device.



Figure 2.2: Back view of the remote control, highlighting the battery compartment.

3. COMPATIBILITY

This replacement remote control is compatible with the following Mistral A/C Air Conditioner models:

- Mistral GZ01-BEJ0-000
- Mistral MSS2.0KW
- Mistral MSS2.6KW
- Mistral MSS3.3KW
- Mistral MSS4.8KW
- Mistral MSS6.5KW

Important:

For optimal functionality, ensure that your original remote control has the same appearance and button layout as the remote shown in this manual. Compatibility cannot be guaranteed if your original remote differs significantly in design or model number from those listed.

This replacement remote may not offer all functions present on your original remote control. Refer to your air conditioner's original manual for specific functions if needed.

4. SETUP

4.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by the "OPEN" arrow to remove it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Caution:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.

5. OPERATING INSTRUCTIONS

Once batteries are installed, the remote control is ready for use. Point the remote control directly at the infrared receiver on your Mistral air conditioner unit.

- **Power Button:** Press to turn the air conditioner ON or OFF.
- **Temperature Adjustment:** Use the *Up* and *Down* arrow buttons to increase or decrease the desired temperature.
- **Mode Selection:** Press the *Mode* button to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Fan Speed:** Use the *Fan* button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Function:** If available, press the *Swing* button to activate or deactivate the louver swing function.

Refer to the button labels on your specific remote control for all available functions. The functionality of each button corresponds to the standard operations of compatible Mistral air conditioners.

6. MAINTENANCE

6.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's finish or internal components.

6.2 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

7. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure the remote is pointed directly at the air conditioner's receiver.
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA batteries.

- Ensure there are no obstructions between the remote and the air conditioner.
- **Limited functionality:**
 - This replacement remote may not support all advanced functions of your original air conditioner remote. Verify if the desired function is present on the replacement remote's buttons.
 - Confirm that your air conditioner model is listed in the compatibility section.

8. SPECIFICATIONS

Product Type	Replacement Infrared Remote Control
Compatible Devices	Mistral A/C Air Conditioners (GZ01-BEJ0-000, MSS2.0KW, MSS2.6KW, MSS3.3KW, MSS4.8KW, MSS6.5KW)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Power Source	2 x AAA Batteries (not included)
Special Features	Ergonomic design

9. SUPPORT AND WARRANTY

This replacement remote control is provided without an explicit instruction manual from the manufacturer. For any questions, concerns, or troubleshooting assistance not covered in this document, please contact the seller directly through your purchase platform.

Information regarding specific warranty terms for this replacement product should be obtained from the point of purchase or the seller.