EGLO 204077A

EGLO LED Wall Light Model 204077A Instruction Manual

Brand: EGLO | Model: 204077A

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your EGLO LED Wall Light Model 204077A. Please read this manual thoroughly before installation and retain it for future reference.

The EGLO LED Wall Light 204077A features a matte nickel finish with a steel metal base and glass shade, designed to provide up/down lighting. It incorporates integrated LED technology for efficient illumination.

IMPORTANT SAFETY INFORMATION

- **Electrical Safety:** Always disconnect power at the circuit breaker before installing, servicing, or cleaning this fixture. Installation should be performed by a qualified electrician if you are not familiar with electrical wiring.

- **Mounting:** Ensure the mounting surface is structurally sound and can support the weight of the fixture.

- **Handling:** Handle glass components with care to prevent breakage.

- **Integrated LED:** This fixture uses integrated LED lights that are non-removable. Do not attempt to replace the LEDs.

- **Proposition 65 Warning:** This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- EGLO LED Wall Light Fixture (Model 204077A) - 1 unit

- Installation Hardware (screws, wire nuts, etc.) - 1 set (typically included with light fixtures)

- Instruction Manual

Figure 1: EGLO LED Wall Light 204077A. This image displays the complete wall light fixture in matte nickel finish with its glass shade.

SETUP AND INSTALLATION

Tools Required (not included): Screwdriver, wire strippers, electrical tape, safety glasses.

1. **Turn Off Power:** Locate the circuit breaker controlling the wall switch or outlet where the light will be installed. Turn off the power completely.

2. **Prepare Mounting Surface:** Ensure the electrical box is securely mounted and the wiring is accessible.

3. **Attach Mounting Bracket:** Secure the fixture's mounting bracket to the electrical box using the provided screws.

4. **Wire Connections:**
   - Connect the **black** wire from the fixture to the **black** (hot) wire from the electrical box.
   - Connect the **white** wire from the fixture to the **white** (neutral) wire from the electrical box.
   - Connect the **green** or **bare copper** ground wire from the fixture to the ground wire from the electrical box.

   Secure all connections with wire nuts and electrical tape.

5. **Mount Fixture:** Carefully align the fixture with the mounting bracket and secure it with the provided screws. Ensure no wires are pinched.

6. **Restore Power:** Once the fixture is securely mounted and all connections are checked, restore power at the circuit breaker.

Figure 2: Product Dimensions. This image illustrates the length (L: 13.82"), width (W: 3.15"), and height (H: 8.63") of the EGLO LED Wall Light 204077A.

OPERATING INSTRUCTIONS

The EGLO LED Wall Light Model 204077A is designed for simple operation.

- **Power On/Off:** Operate the light using the standard wall switch connected to the fixture.
- **Integrated Touch Control:** This fixture features a touch control mechanism. Gently touch the designated area on the fixture to cycle through light settings or to turn the light on/off, if applicable. Refer to the specific product packaging or a separate quick start guide for detailed touch control functionality.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your EGLO LED Wall Light.

- **Cleaning:** Before cleaning, ensure the power is turned off at the circuit breaker. Use a soft, dry, or slightly damp cloth to wipe the fixture. Avoid abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LED Care:** The integrated LEDs are designed for long life and do not require replacement. Do not attempt to disassemble the LED module.

- **Inspection:** Periodically inspect the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty wall switch.	Check circuit breaker. Ensure all wire connections are secure (power off first). Test or replace wall switch.
Light flickers.	Loose wire connection. Incompatible dimmer switch (if applicable).	Check wire connections (power off first). Ensure dimmer switch is LED-compatible.
Fixture is hot to the touch.	Normal operation for LED fixtures (some heat is expected). Overheating due to improper installation or ventilation.	Ensure proper air circulation around the fixture. If excessively hot, disconnect power and consult a qualified electrician.

SPECIFICATIONS

Brand	EGLO
Model Number	204077A
Product Dimensions (L x W x H)	13.88" x 3.13" x 11.38"
Item Weight	4 pounds
Finish	Matte Nickel
Material	Steel / Glass
Light Source Type	Integrated LED
Number of Light Sources	3
Wattage	6.7 watts
Voltage	120 Volts
Power Source	Corded Electric
Mounting Type	Protruding
Lighting Method	Up/Down Light
Control Method	Touch
Assembly Required	Yes
Energy Star Certified	Yes

WARRANTY AND SUPPORT

Manufacturer's Warranty: All EGLO products are covered under a 1-year warranty from the date of original shipment when purchased on Amazon. This warranty covers items and conditions identified in the original manufacturer's warranty. Exclusions include loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

Replacement Parts Policy: A 30-day replacement parts policy is provided to ensure a fully working item upon receipt.

For support or warranty claims, please contact EGLO customer service or refer to the official EGLO website for contact information. You may also visit the EGLO Store on Amazon for additional product information.

ADDITIONAL INFORMATION

Figure 3: EGLO LED Wall Light 204077A in a modern living room. This image shows the wall light installed in a contemporary interior, demonstrating its aesthetic integration and lighting effect.