CalExotics 14041PURPLE

CalExotics Aura Duo Instruction Manual

Model: 14041PURPLE | Brand: CalExotics

1. Introduction

The CalExotics Aura Duo is a personal massager designed for versatile stimulation. It features a contoured shape with dual stimulators, 12 vibration functions, and is constructed from body-safe silicone. The device is waterproof and rechargeable via USB, providing extended use on a single charge.



Image 1: CalExotics Aura Duo device and its retail packaging.

2. Important Safety Information

- Read all instructions thoroughly before first use and retain for future reference.
- This product is intended for adult use only.
- Do not use if the device appears damaged or compromised.
- Consult a healthcare professional if you have any medical conditions or concerns regarding use.
- Clean the device before and after each use as instructed in the Maintenance section.
- Only use water-based lubricants with this product. Oil-based or silicone-based lubricants may damage the silicone material.

- Do not overcharge the device. Disconnect the charger once fully charged.
- Keep out of reach of children.

3. Package Contents

- 1 x CalExotics Aura Duo Device
- 1 x USB Charging Cable
- 1 x Instruction Manual (this document)

4. Setup

4.1 Initial Charging

1. Before first use, ensure the Aura Duo is fully charged.
2. Locate the charging port on the device, typically at the base.
3. Connect the provided USB charging cable to the device's charging port.
4. Plug the other end of the USB cable into a standard USB power source (e.g., computer USB port, USB wall adapter - not included).
5. The indicator light on the device will illuminate or flash to indicate charging.
6. Allow approximately 2 hours for a full charge. The indicator light will change or turn off when charging is complete.



Image 2: Close-up view of the device's base, showing the charging port.

4.2 Initial Cleaning

Before the first use, and after every subsequent use, clean the device thoroughly. Refer to the Maintenance section for detailed cleaning instructions.

5. Operating Instructions



Image 3: Side view of the CalExotics Aura Duo, highlighting the control buttons.

5.1 Power On/Off

- To turn the device **ON**: Press and hold the power button (usually marked with a power symbol) for approximately 2 seconds. The device will vibrate briefly, and an indicator light may illuminate.
- To turn the device **OFF**: Press and hold the power button for approximately 2 seconds. The device will stop vibrating, and the indicator light will turn off.

5.2 Changing Vibration Functions

- Once the device is powered on, short press the function button (often located near the power button, or the same button if it's a single control) to cycle through the 12 available vibration patterns.
- Continue pressing the button until you find your desired function.

5.3 Travel Lock Feature

- To **activate** the travel lock: With the device turned off, press and hold both the power button and the function button simultaneously for approximately 3 seconds. The indicator light may flash to confirm activation.
- To **deactivate** the travel lock: Press and hold both the power button and the function button simultaneously for approximately 3 seconds. The indicator light will confirm deactivation, and the device can then be powered on normally.

5.4 Waterproof Use

The Aura Duo is designed to be waterproof, allowing for use in the shower or bath. Ensure the charging port is completely dry before connecting the charging cable.

6. Maintenance

6.1 Cleaning

1. Always clean the Aura Duo before and after each use.
2. Wash the device with warm water and a mild, antibacterial soap or a specialized toy cleaner.
3. Rinse thoroughly under warm running water to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely before storage.
5. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

6.2 Storage

- Store the device in a clean, dry, and cool place.
- Avoid direct sunlight and extreme temperatures.
- Keep the device separate from other toys or materials that could potentially react with or damage the silicone.

6.3 Lubricant Compatibility

For optimal performance and to preserve the integrity of the silicone material, only use **water-based lubricants** with the CalExotics Aura Duo. Avoid oil-based, silicone-based, or petroleum-based lubricants, as they can degrade the silicone over time.

7. Troubleshooting

- **Device will not turn on:**
  - Ensure the device is fully charged. Refer to Section 4.1 for charging instructions.
  - Check if the travel lock is activated. Deactivate it by holding both the power and function buttons for 3 seconds.
- **Device is not vibrating or vibrations are weak:**
  - Ensure the device is fully charged.
  - Verify the device is powered on and not in travel lock mode.
  - If recently charged, ensure the USB cable is disconnected from the device.
- **Device is not charging:**
  - Ensure the USB charging cable is securely connected to both the device and the power source.
  - Try using a different USB port or a different USB wall adapter.
  - Inspect the charging cable for any signs of damage.

8. Specifications

Feature	Detail
Model Number	14041PURPLE
Material	Silicone
Color	Multi (Purple)
Dimensions (L x W x H)	2.25 x 5.75 x 11.5 inches
Weight	6.9 ounces
Power Source	Rechargeable USB
Charge Time	Approximately 2 hours
Run Time	Up to 140 minutes (on lowest setting)
Waterproof	Yes
Vibration Functions	12

9. Warranty and Support

For specific warranty information, product support, or to address any concerns not covered in this manual, please contact CalExotics customer service directly. You can typically find contact details on the product packaging or the official CalExotics website.

Website: www.calexotics.com

© 2023 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question