

## Podazz AF-2003

# Podazz Automatic Fish Feeder AF-2003 Instruction Manual

Model: AF-2003 | Brand: Podazz

## 1. INTRODUCTION

The Podazz Automatic Fish Feeder AF-2003 is designed to provide convenient and reliable automatic feeding for your aquarium fish. This device ensures your fish are fed regularly, even when you are away, making it ideal for vacations or busy schedules. Please read this manual thoroughly before use to ensure proper setup and operation.

## 2. SAFETY INFORMATION

- This feeder is designed for **dry fish food only**. Do not use with wet or moist food, as this can cause blockages and damage the device.
- Ensure the feeder is placed in a position where it will not fall into the water.
- Use only the specified battery type (2x AAA 1.5V batteries). Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the feeder will not be used for an extended period.
- Keep out of reach of children.

## 3. PACKAGE CONTENTS

- Podazz Automatic Fish Feeder AF-2003 Main Unit
- Mounting Clip
- Double-sided Sticker (for alternative installation)
- Instruction Manual

## 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your automatic fish feeder:

- **Food Drum:** Transparent container for fish food.
- **Food Quantity Adjuster:** Slider or knob to control the amount of food dispensed.
- **Battery Compartment:** Located at the bottom or back, holds 2x AAA batteries.
- **Timer Switch:** To select 12-hour or 24-hour feeding intervals.
- **Manual Feed Button:** For instant feeding.
- **Mounting Bracket/Clip:** For attaching to the aquarium.



New and old packaging  
will be shipped randomly



Manual key  
Feeder Modes:12H/24H

Figure 1: Feeder Components (Food Tank, Main Body, Battery Cover, Clip)

## 5. SETUP

### 5.1 Battery Installation

1. Locate the battery compartment on the feeder.
2. Remove the battery cover. It may require a slight force to open.
3. Insert 2x AAA 1.5V batteries (not included), ensuring correct polarity (+/-).
4. Replace the battery cover securely.



Figure 2: Battery Installation

## 5.2 Filling the Food Drum

1. Gently pull the food drum away from the main feeder body to remove it.
2. Remove the transparent cover of the drum.
3. Fill the drum with your desired dry fish food (pellets, granular, strips, or flakes). Do not overfill.
4. Close the transparent cover and reinstall the food drum onto the feeder, ensuring it clicks into place.



Figure 3: Filling the Food Drum

## 5.3 Installation Methods

There are two primary ways to install the feeder on your aquarium:

### 1. Using the Mounting Clip:

Slide the feeder onto the edge of your aquarium tank. Tighten the screw on the mounting clip to secure the feeder firmly in place. Ensure the feeder is positioned above the water surface to prevent food from getting wet.

### 2. Using the Double-Sided Sticker:

Attach the double-sided sticker (included) to the bottom of the feeder. Then, fix the feeder onto the aquarium cover. Ensure the surface is clean and dry before applying the sticker for a secure hold.

## 2 Méthodes D'installation



Figure 4: Two Installation Methods

## 6. OPERATING INSTRUCTIONS

### 6.1 Setting Feeding Interval

The feeder offers two automatic feeding intervals: 12 hours and 24 hours.

1. Locate the 12H/24H switch on the feeder.
2. Slide the switch to your desired feeding interval (12H for twice a day, 24H for once a day).
3. The timer starts when you set the batteries and select an interval. To adjust the feeding time, switch the setting (e.g., from 12H to 24H and back to 12H) at the exact time you wish the first feeding to occur. The feeder will then dispense food at this time and repeat every 12 or 24 hours.



Figure 5: Setting Feeding Interval

### 6.2 Adjusting Food Quantity

You can adjust the amount of food dispensed per feeding:

1. Locate the food quantity adjuster (a slider or knob) on the front of the food drum.
2. Move the adjuster to select one of the 1-6 different quantity levels. Experiment to find the appropriate amount for your fish.

# Podazz

## Distributeur Automatique de Nourriture Pour Poissons



60 ml  
Capacité



Support D'alimentation  
Réglable



Installation  
Facile



Fonctionnement  
Silencieux



Alimentation  
Automatique



Alimenté Par  
Batterie



Figure 6: Adjustable Food Quantity

### 6.3 Manual Feeding

To feed your fish instantly outside of the programmed schedule, press the manual feed button (often located near the timer switch). This will dispense one portion of food without affecting the automatic timer.

## 7. MAINTENANCE

### 7.1 Cleaning

To ensure optimal performance and hygiene, clean the feeder regularly:

- Remove the food drum from the main unit.
- Hand wash the food drum with care using mild soap and water. Do not twist or apply excessive force.
- Ensure all parts are completely dry before reassembling and refilling with food.
- Do not immerse the main electronic unit in water. Wipe it with a damp cloth if necessary.

### 7.2 Food Type and Storage

- Only use dry fish food.
- Store fish food in a cool, dry place to prevent clumping.
- Ensure the feeder is positioned above the water to prevent moisture from entering the food drum, which can cause food to clump and block the dispenser.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Feeder does not dispense food.	Batteries are dead or incorrectly installed. Food is clumped or jammed. Food drum is empty.	Check and replace batteries. Clean the food drum and ensure food is dry and free-flowing. Refill the food drum.
Feeder dispenses too much/too little food.	Food quantity adjuster is set incorrectly.	Adjust the food quantity slider/knob to the desired level. Test with manual feed.
Feeder does not operate at the correct time.	Timer was not set at the desired start time.	Reset the timer by switching the 12H/24H selector at the exact time you want the first feeding to occur.
Battery compartment is difficult to open/close.	Tight fit.	Apply gentle, firm pressure. Ensure no obstructions.

## 9. SPECIFICATIONS

- **Model Number:** AF-2003
- **Brand:** Podazz
- **Material:** Plastic
- **Color:** Black
- **Capacity:** 60 Milliliters
- **Power Source:** Battery powered (2x AAA 1.5V batteries, not included)
- **Operating Mode:** Automatic, Manual
- **Item Dimensions (L x W x H):** 7.8 cm x 11.2 cm x 12.4 cm
- **Item Weight:** 40 Grams
- **Target Species:** Fish (suitable for small to large fish sizes)
- **Recommended Uses:** Aquarium fish feeding
- **Care Instructions:** Hand wash with care, do not twist, avoid using rechargeable batteries.



Figure 7: Product Dimensions



Figure 8: Compatible Food Types and Target Species

## 10. WARRANTY AND SUPPORT

Podazz is committed to providing quality products and customer satisfaction.

- **Return Policy:** 30-day no-reason return policy.
- **Warranty:** 36-month extended warranty.
- **Customer Service:** 24-hour quick reply customer service.
- **Technical Support:** Lifetime after-sales and technical support.

For any questions, concerns, or technical assistance, please contact Podazz customer service through the platform where you purchased the product.