

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JOYMOR](#) /

› [JOYMOR Inflatable Bouncing Castle Play Center with Air Blower Instruction Manual](#)

## JOYMOR Inflatable Bouncing Castle Play Center

# JOYMOR Inflatable Bouncing Castle Play Center Instruction Manual

**Brand:** JOYMOR | **Model:** Inflatable Bouncing Castle Play Center

## 1. PRODUCT OVERVIEW

The JOYMOR Inflatable Bouncing Castle Play Center is designed to provide a fun and engaging play environment for toddlers and young children. This play center features multiple activity zones including a bouncing area, an extra-long slide, a climbing wall, and a basketball hoop. It is constructed from durable oxford cloth materials and includes an air blower for continuous inflation during use. This manual provides essential information for safe setup, operation, and maintenance of the product.



Image 1: Overview of the JOYMOR Inflatable Bouncing Castle Play Center.

## 2. WHAT'S IN THE BOX

Please ensure all components are present before beginning assembly:

- 1x Inflatable Bouncing Playhouse (11ft W x 9ft L x 7ft H)
- 1x 450W Air Blower
- 6x Bouncer Stakes
- 4x Blower Stakes
- 1x Carry Bag
- 4x Bouncer Repair Sheets

## 3. SETUP INSTRUCTIONS

1. **Site Selection:** Choose a flat, level surface for placement. Ensure the area is free from sharp objects, debris, or any obstructions. The product dimensions are 130"L x 130"W x 86.6"H.
2. **Unpack and Unfold:** Remove the inflatable bouncer from its carry bag and spread it out completely on the chosen surface.
3. **Connect Air Blower:** Locate the air intake tube on the inflatable bouncer. Connect this tube securely to the outlet of the 450W air blower. Ensure the connection is tight to prevent air leakage.
4. **Secure the Blower:** Place the air blower on a stable surface. Use the provided 4 blower stakes to secure the blower to the ground, preventing it from tipping over during operation.
5. **Inflate:** Plug the air blower into a suitable electrical outlet and turn it on. The inflatable bouncy castle will inflate in less than 1 minute. The blower must remain on continuously during use to maintain inflation.
6. **Anchor the Bouncer:** Once fully inflated, use the provided 6 bouncer stakes to anchor the corners and sides of the inflatable play center to the ground. This prevents movement during play.



Image 2: Visual guide for quick inflation and setup.

## 4. OPERATING INSTRUCTIONS & FEATURES

The JOYMOR Inflatable Bouncing Castle Play Center offers various activities for children aged 3-10 years. It is designed to accommodate 2-3 children with a maximum weight recommendation of 250 lbs.

### Key Features:

- **Bouncing Area:** A spacious area for jumping and active play.
- **Long Slide:** An extended slide for sliding fun.
- **Climbing Wall:** Features foot and hand holds to assist children in climbing.
- **Basketball Hoop:** An integrated hoop for practicing throwing skills.



Image 3: Detailed view of the play center's multiple activity zones.

### Usage:

Children can enjoy the bouncing area, climb the wall to access the slide, and play basketball. The design encourages physical activity and interaction.



*Image 4: The bounce house can be used indoors.*



Image 5: The bounce house can be used outdoors.

## 5. SAFETY GUIDELINES

- The jumping area is surrounded by 3 sides of mesh safety netting to protect children from falling.
- Parents should supervise children at all times.
- Air leakage from seams is normal and necessary for continuous airflow inflation; it does not indicate a defect.
- Do not allow more than 2-3 children on the bouncer at one time for the best experience and safety.
- Maximum load capacity: 250 lbs.
- Suitable for children aged 3-10 years.
- **WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**
- Keep the inflatable away from open flames, heat sources, and sharp objects.
- Do not use in windy conditions without proper anchoring.

## 6. MAINTENANCE

- **Cleaning:** Clean the inflatable surface with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before storage.
- **Storage:** Ensure the inflatable is completely dry before folding and storing it in the provided carry bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repairs:** Use the included repair sheets for minor punctures. Apply the patch according to the instructions on the repair kit.

## 7. TROUBLESHOOTING

- **Inflatable not fully inflating:** Check that the air blower is securely attached to the intake tube and that the blower is powered on. Ensure there are no large tears or openings in the inflatable. Verify that the air intake tube is not twisted or obstructed.
- **Blower making unusual noise:** Turn off the blower immediately and inspect for any obstructions in the fan or motor area. If the issue persists, contact customer support.
- **Product moving during use:** Ensure all bouncer stakes are properly installed and securely anchored into the ground. Re-evaluate the play surface for stability.

## 8. SPECIFICATIONS

Feature	Detail
Brand	JOYMOR
Product Dimensions	130"L x 130"W x 86.6"H
Item Weight	44.8 Pounds
Age Range (Recommended)	3-10 years
Maximum Weight Recommendation	250 Pounds
Number of Players	2-3 (for best experience)
Material	840D and 420D Oxford Cloth
Air Blower Power	450W
UPC	840323503952



+



=

# High Quality Oxford Cloth



WATERPROOF



WEAR RESISTANT



UNEASY TO FADE



TEAR RESISTANT




Image 6: Illustration of the high-quality Oxford Cloth material.

## 9. WARRANTY AND SUPPORT

JOYMOR offers a **30-Day Return Policy**. During this period, the shipping cost for returns and replacements of defective and damaged items will be covered. For reasons beyond quality issues, the buyer is responsible for return shipping expenses. Products must be returned in their original packaging and shipped within 30 days of delivery.

For further assistance or inquiries, please refer to your purchase documentation or contact JOYMOR customer service directly.

