

[Manuals.plus](#) /

› [NETTA](#) /

› NETTA 5L Portable Mini Fridge Cooler and Warmer Instruction Manual

NETTA NT-5L-WHITE-MINIFRIDGE

NETTA 5L Portable Mini Fridge Cooler and Warmer

Model: NT-5L-WHITE-MINIFRIDGE

INTRODUCTION

Thank you for purchasing the NETTA 5L Portable Mini Fridge. This versatile appliance is designed to keep your items either cool or warm, making it ideal for various settings such as travel, offices, dorm rooms, and camping. Please read this manual thoroughly before use to ensure safe operation and optimal performance.



Image: The NETTA 5L Portable Mini Fridge, showcasing its compact design, interior capacity with beverages, and included AC/DC power cables.

SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance away from direct sunlight and heat sources.
- Ensure proper ventilation around the unit. Do not block air vents.

- Unplug the appliance from the power source when not in use or before cleaning.
- Do not use the appliance if the power cord or plug is damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use the appliance for purposes other than its intended use.
- Avoid placing hot items directly into the fridge when in cooling mode, or cold items when in warming mode, as this can affect performance.

PACKAGE CONTENTS

Please check the package contents upon unboxing:

- NETTA 5L Portable Mini Fridge
- AC Power Cable (for home/office use)
- DC 12V Car Power Cable (for vehicle use)
- Removable Shelf
- Instruction Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your mini fridge:

1. Main Unit (Housing)
2. Door Latch
3. Carry Handle
4. Removable Interior Shelf
5. Control Panel (Rear) with OFF/COLD/WARM switch and AC/DC ports
6. Power Indicator Lights (Green for Cold, Red for Warm)
7. Ventilation Grilles (Rear)



AC/DC WHITE 5L MINI FRIDGE



COOLS & WARMS
VERSATILE USE



5L CAPACITY WITH
REMOVABLE SHELF



AC/DC POWER
UK POWER



LIGHTWEIGHT
AND PORTABLE



QUIET
OPERATION



Image: Interior view of the mini fridge, showing the removable shelf and capacity for multiple beverage cans.

SETUP

Follow these steps for initial setup:

1. **Unpack:** Carefully remove the mini fridge and all accessories from the packaging.
2. **Placement:** Place the mini fridge on a flat, stable surface. Ensure there is adequate space (at least 10 cm) around the unit for proper ventilation, especially at the rear where the fan and vents are located.
3. **Interior Cleaning:** Before first use, wipe the interior with a damp cloth and mild detergent. Dry thoroughly.
4. **Shelf Installation:** Insert the removable shelf into the desired position inside the fridge.

OPERATING INSTRUCTIONS

Connecting to Power



AC/DC POWER
UK POWER




Image: The rear control panel of the mini fridge, illustrating the AC (220-240V) and DC (12V) power input ports, and the three-position switch for OFF, COLD, and WARM modes.

- **AC Power (Home/Office):** Connect the AC power cable to the AC port on the back of the fridge, then plug the other end into a standard wall outlet (220-240V).
- **DC Power (Vehicle):** Connect the DC 12V car power cable to the DC port on the back of the fridge, then plug the other end into your vehicle's cigarette lighter socket.
- **Important:** Ensure the fridge is switched to the 'OFF' position before connecting or disconnecting power cables. Do not connect both AC and DC power simultaneously.

Cooling Function



COOLS & WARMS
VERSATILE USE



Image: A diagram illustrating the internal cooling (blue swirls) and warming (orange rays) capabilities of the mini fridge.

- With the fridge connected to power, slide the switch on the back panel to the 'COLD' position.
- The green indicator light will illuminate, indicating cooling mode is active.
- The fridge can cool items up to 20°C below the ambient room temperature.
- Allow 1-2 hours for the fridge to reach its optimal cooling temperature.

Warming Function

- With the fridge connected to power, slide the switch on the back panel to the 'WARM' position.
- The red indicator light will illuminate, indicating warming mode is active.
- The fridge can warm items up to 65°C.
- Allow 1-2 hours for the fridge to reach its optimal warming temperature.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft cloth and mild detergent to clean the interior and exterior surfaces. Do not use abrasive cleaners or immerse the unit in water.

- **Defrosting:** This thermoelectric cooler may accumulate a thin layer of ice on the cooling plate over time, especially in humid conditions. To defrost, switch the unit off, unplug it, and leave the door ajar until the ice melts. Wipe away any excess water.
- **Ventilation:** Regularly check that the ventilation grilles on the back are free from dust and obstructions to ensure efficient operation.
- **Storage:** If storing the fridge for an extended period, ensure it is clean and dry. Leave the door slightly ajar to prevent odors.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance not turning on	No power supply; Power cable not connected properly; Switch in 'OFF' position.	Check power connection and wall outlet/car socket; Ensure switch is set to 'COLD' or 'WARM'.
Insufficient cooling/warming	Blocked ventilation; Ambient temperature too high/low; Door not closed properly; Excessive ice buildup.	Clear vents; Ensure door is sealed; Defrost unit if necessary; Allow sufficient time for temperature change.
Loud noise during operation	Fan obstruction; Unit not on a stable surface.	Check for obstructions in the fan; Place unit on a flat, stable surface.
Ice accumulation inside	High humidity; Prolonged use in cooling mode.	Perform manual defrost as described in the Maintenance section.

SPECIFICATIONS



Image: The NETTA Mini Fridge with visual indicators for its dimensions (Depth 18.4cm, Width 26cm, Height 27.3cm) and weight (2.5kg).

Feature	Detail
Brand	NETTA
Model	NT-5L-WHITE-MINIFRIDGE
Capacity	5 Liters
Dimensions (L x W x H)	18.4 x 26 x 27.3 cm
Weight	2.17 kg (Product), 2.5 kg (Shipping)
Noise Level	28 dB
Power Input	AC 220-240V, DC 12V
Power Consumption	48 Watts

Feature	Detail
Cooling Performance	Cools up to 20°C below ambient temperature
Warming Performance	Heats up to 65°C
Shelf Type	Plastic, Removable
Number of Doors	1
Defrost System	Manual Defrost
Color	White

WARRANTY AND SUPPORT

Your NETTA 5L Portable Mini Fridge comes with a standard manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included in your product packaging or contact NETTA customer support directly. If you encounter any issues or require assistance, please reach out to the retailer or manufacturer's customer service department with your model number and purchase date.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07V46QX9V>

More documents and user manuals: <https://manuals.plus/>