

## Simple Houseware CB-10C-1

# Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart (Model CB-10C-1) Instruction Manual

## 1. INTRODUCTION AND OVERVIEW

---

Thank you for choosing the Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart. This versatile and durable cart is designed to provide efficient storage and easy mobility for various items in your home or office. Its robust construction and thoughtful design make it an ideal solution for organizing kitchens, bathrooms, laundry rooms, garages, and workspaces.

This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new utility cart.

## 2. PRODUCT FEATURES

---

- **Heavy-Duty Construction:** Features a solid steel frame and sturdy metal baskets with a sleek black finish for lasting durability and modern style.
- **3 Metal Baskets:** Three spacious baskets provide open storage for organizing everyday items with ease. The mesh basket design ensures airflow and visibility of contents.
- **Heavy-Duty Casters:** Includes four heavy-duty 2-inch casters for smooth mobility, with two lockable casters for extra stability when the cart is stationary.
- **Modern Curved Handles:** Curved top handles offer easy maneuverability, allowing you to push and pull the cart as needed.
- **Versatile Use:** Perfect for organizing kitchens, bathrooms, laundry rooms, garages, offices, and more.

## 3. PACKAGE CONTENTS

---

Please ensure all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Side Frames (2)
- Bottom Frame (1)
- Metal Baskets (3)
- Casters (4, 2 with locks)
- Handle (1)
- Assembly Hardware (Screws, Allen Wrench)

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your utility cart:

1. **Attach Casters:** Turn the bottom frame upside down. Insert the four casters into the designated holes on the bottom frame. Two of the casters have locking mechanisms; ensure these are placed on the same side for easier access. Tighten them securely with the provided wrench.
2. **Connect Side Frames:** Attach the two side frames to the bottom frame using the provided screws. Do not fully tighten the screws yet to allow for slight adjustments.
3. **Install Baskets:** Slide the three metal baskets into the grooves on the side frames. Ensure they are evenly spaced and oriented correctly.
4. **Attach Handle:** Secure the curved handle to the top of the side frames using the remaining screws.
5. **Final Tightening:** Once all components are in place, fully tighten all screws to ensure the cart is stable and secure.



Image: Fully assembled Simple Houseware 3-Tier Utility Rolling Cart in black, showcasing its three spacious baskets and curved handle.



Image: Close-up view of a heavy-duty caster wheel with a locking mechanism, ensuring stability when the cart is stationary.

## 5. OPERATING INSTRUCTIONS

---

The Simple Houseware Utility Rolling Cart is designed for ease of use:

- **Moving the Cart:** Use the curved top handles to push or pull the cart to your desired location. The heavy-duty casters allow for smooth movement across various floor surfaces.
- **Locking the Wheels:** To keep the cart stationary, press down on the locking levers located on two of the casters. To unlock, simply lift the levers.
- **Loading the Baskets:** Distribute items evenly across the three baskets to maintain balance and stability. Avoid overloading any single basket beyond its weight capacity.



Image: The utility cart positioned next to an office desk, demonstrating its use for storing office supplies and enhancing workspace organization.

## 6. MAINTENANCE

---

To ensure the longevity and appearance of your utility cart, follow these maintenance guidelines:

- **Cleaning:** Wipe down the metal frame and baskets with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Drying:** Ensure all parts are thoroughly dried after cleaning to prevent rust, especially the mesh baskets.
- **Caster Care:** Periodically check the casters for any debris (hair, lint) that might impede smooth rolling. Clean as necessary.
- **Tighten Screws:** Occasionally check and tighten all assembly screws to maintain structural integrity.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your utility cart, refer to the following common solutions:

- **Cart is Wobbly:** Ensure all screws are fully tightened. Check that the baskets are correctly seated in their grooves.

- **Wheels Not Rolling Smoothly:** Check casters for trapped debris and clean if necessary. Ensure the locking mechanisms are disengaged.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure parts are oriented correctly before tightening screws. Do not overtighten screws until all parts are loosely fitted.

## 8. SPECIFICATIONS

<b>Product Dimensions</b>	12.5"D x 17"W x 31.5"H
<b>Brand</b>	Simple Houseware
<b>Material</b>	Alloy Steel, Metal
<b>Color</b>	Black
<b>Special Feature</b>	Locking Caster, Mobility, Sturdy
<b>Number of Shelves</b>	3
<b>Item Weight</b>	7.39 pounds (3.36 Kilograms)
<b>Model Number</b>	CB-10C-1
<b>UPC</b>	811244033842



Image: Diagram showing the dimensions of the utility cart: 12.5"D x 17"W x 31.5"H.

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or warranty information regarding your Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart, please contact Simple Houseware customer support through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.