

SoBuy BZR21-W

SoBuy Slim Tilt-Out Laundry Hamper Cabinet - Instruction Manual

Model: BZR21-W | Brand: SoBuy

1. PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your SoBuy Slim Tilt-Out Laundry Hamper Cabinet, Model BZR21-W. Designed for efficient space utilization, this cabinet offers discreet laundry storage and additional organizational features.

Key Features:

- **Space-Saving Design:** Ideal for compact spaces, providing smart laundry organization.
- **Tilt-Out Hamper:** Discreetly stores dirty clothes and towels with easy access.
- **Durable Construction:** Crafted from white lacquered MDF wood for longevity and easy cleaning.
- **Top Drawer Storage:** Convenient space for essentials like detergent or toiletries.
- **Removable Hamper Basket:** Facilitates easy laundry sorting and cleaning.
- **Modern Aesthetic:** Neutral finish and sleek lines complement various decor styles.

2. SETUP AND ASSEMBLY

The SoBuy Slim Tilt-Out Laundry Hamper Cabinet is designed for straightforward assembly. All necessary hardware and detailed instructions are included to ensure a smooth installation process.

2.1. Before You Begin

- Verify all parts and hardware are present against the included parts list.
- Ensure you have the recommended tools (e.g., screwdriver).
- Assemble on a clean, soft surface to prevent scratches.

2.2. Assembly Steps

Follow the step-by-step diagrams and instructions provided in the separate assembly manual. Each part is typically numbered for easy identification.



Image: The SoBuy Slim Tilt-Out Laundry Hamper Cabinet with its tilt-out door open, revealing the removable fabric hamper. A drawer is visible at the top.



Image: A diagram illustrating the dimensions of the SoBuy Slim Tilt-Out Laundry Hamper Cabinet in centimeters. The cabinet measures 40cm (width) x 38cm (depth) x 90cm (height). The drawer is 14cm high, and the tilt-out section is 67cm high.

2.3. Assembly Video



Video: An official product video from HaotainGroup demonstrating the assembly and features of the SoBuy Bathroom Laundry Cabinet with Basket, Model BZR21-W.

3. OPERATING INSTRUCTIONS

3.1. Using the Tilt-Out Hamper

To access the laundry hamper, gently pull the handle on the lower front panel. The panel will tilt forward, allowing you to place or retrieve items from the removable fabric basket. Push the panel back into place to close.



Image: The SoBuy Slim Tilt-Out Laundry Hamper Cabinet with its tilt-out door closed, showcasing its clean and modern design.

3.2. Using the Storage Drawer

The top drawer provides additional storage. Pull the knob to open the drawer and store small items such as detergents, fabric softeners, or personal care products. Push the drawer firmly to close.



Image: A close-up view of the SoBuy Slim Tilt-Out Laundry Hamper Cabinet's top drawer, shown open with various small items stored inside.

4. MAINTENANCE

4.1. Cleaning the Cabinet

Wipe the MDF wood surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish. Dry immediately with a clean cloth.

4.2. Cleaning the Hamper Basket

The non-woven fabric hamper basket is removable for easy cleaning. It can be spot cleaned with a mild detergent and water. Allow it to air dry completely before returning it to the cabinet.



Image: The removable fabric hamper basket, designed for easy transport of laundry, is shown outside the cabinet on the floor.

5. SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Do not attempt to lift or move the cabinet when it is fully assembled.
- Do not overload the cabinet beyond its load capacity of 88 lbs (approximately 40 kg).
- Keep the cabinet away from heat sources.
- Do not place heavy or sharp objects on top of the cabinet.
- Ensure the cabinet is placed on a stable, level surface to prevent tipping.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	BZR21-W (Note: BZR33-W also listed as item model number)

Feature	Detail
Color	White
Material	Engineered Wood (MDF)
Product Dimensions	15"D x 15.7"W x 35.4"H (38cm D x 40cm W x 90cm H)
Item Weight	33 pounds (15 Kilograms)
Weight Limit	88 Pounds
Special Feature	Tilt-out Hamper
Mounting Type	Floor Mount (Freestanding)
Room Type	Laundry Room, Bathroom
Number of Shelves	1 (internal shelf for hamper)
Assembly Required	Yes



Image: A diagram illustrating the dimensions of the SoBuy Slim Tilt-Out Laundry Hamper Cabinet in inches. The cabinet measures 15.7" (width) x 15" (depth) x 35.4" (height). The top drawer is 5.5" high, and the tilt-out section is 26.3" high.

7. TROUBLESHOOTING

7.1. Assembly Difficulties

- **Parts not fitting:** Double-check the part numbers against the manual's diagrams. Ensure components are oriented correctly.
- **Missing hardware:** Review the hardware list. If items are missing, contact customer support.
- **Wobbly cabinet:** Ensure all screws and fasteners are tightened securely. Verify the cabinet is on a level surface.

7.2. Hamper Operation Issues

- **Tilt-out door sticking:** Check for any obstructions or misaligned hinges. Ensure the hamper basket is not overfilled.
- **Drawer not sliding smoothly:** Inspect the drawer glides for debris or damage. Ensure they are properly installed and lubricated if necessary.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the contact details provided with your purchase documentation or visit the official SoBuy website. Keep your proof of purchase for any warranty claims.

8.1. Additional Seller Videos



Video: An official product video from Aosom Direct showcasing the HOMCOM 31" Tilt Out Laundry Hamper, Free Standing Home Organizer Hamper, Bathroom Storage Cabinet. This video demonstrates the functionality of a similar tilt-out hamper cabinet.



Video: An official product video from Homykic demonstrating the Homykic Tilt Out Laundry Hamper Cabinet. This video highlights the features and use of a comparable product.