

GROHE 30383000

GROHE Blue Pure Eurosmart Duo Starter Kit Instruction Manual

Model: 30383000

1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your GROHE Blue Pure Eurosmart Duo Starter Kit. This product is designed to provide both filtered and unfiltered tap water from a single C-spout mixer tap, enhancing water quality for drinking and cooking.

2. SAFETY INFORMATION

- Read all instructions carefully before installation and use.
- Ensure all connections are secure to prevent leaks.
- Do not use abrasive cleaners or scouring pads on the tap surface.
- Ensure the water supply is turned off before beginning installation or maintenance.
- The maximum supported water TDS level is 500 PPM.
- The upper temperature rating for the water is 100 degrees Fahrenheit.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- GROHE Blue Pure Eurosmart Filter Tap
- GROHE Blue Filter Head
- GROHE Blue Activated Carbon Filter (3000 Liters capacity)
- Filter Exchange Timer
- Flexible Connection Hoses

4. SETUP AND INSTALLATION

The GROHE Blue Pure Eurosmart Duo Starter Kit is designed for single-hole assembly. It features separated water guides within the tap to ensure filtered and unfiltered water do not mix.

4.1. Pre-Installation

- Turn off the main water supply.
- Clear the installation area under the sink.

4.2. Tap Installation

1. Insert the tap into the single-hole opening on your sink or countertop.
2. Secure the tap from underneath using the provided mounting hardware.
3. Connect the flexible connection hoses to your hot and cold water supply lines.
4. Ensure all connections are hand-tightened, then use a wrench for a final quarter turn, being careful not to overtighten.

4.3. Filter Head and Filter Installation

1. Mount the GROHE Blue Filter Head in an accessible location under the sink.
2. Connect the dedicated water line from the tap to the filter head.
3. Insert the Activated Carbon Filter into the filter head, ensuring it clicks into place.

4.4. Filter Exchange Timer Setup

1. Install the Filter Exchange Timer in a visible location near the tap or filter.
2. Set the timer to your desired filter cycle (90, 180, 270, or 360 days). The timer will provide an audible signal when a filter change is due.



Figure 1: Technical drawing showing the dimensions and installation components of the GROHE Blue Pure Eurosmart Duo Starter Kit. This diagram illustrates the tap's height, spout reach, and the placement of the filter unit and timer.

5. OPERATING INSTRUCTIONS

Your GROHE Blue Pure Eurosmart Duo tap provides both regular tap water and filtered drinking water.

5.1. Dispensing Unfiltered Water

Use the main single-lever handle for regular hot and cold tap water. Move the handle left or right to adjust temperature and up or down to control flow.

5.2. Dispensing Filtered Water

The separate handle on the side of the tap is dedicated to filtered water. Turn this handle to dispense filtered water. The internal waterways ensure that filtered water remains separate from unfiltered water.




Figure 2: Close-up view of the textured separate handle used to dispense filtered water. This handle is distinct from the main mixer lever.



Figure 3: An individual demonstrating the use of the separate handle to fill a glass with filtered water from the C-spout tap.

5.3. Swivelling Spout

The C-spout can swivel 360 degrees, providing flexibility for various sink configurations and tasks, such as filling large pots or cleaning the sink area.

6. MAINTENANCE

6.1. Filter Replacement

The GROHE Blue Activated Carbon Filter has a capacity of 3000 liters. The Filter Exchange Timer will alert you when it is time to replace the filter. Replace the filter promptly to maintain optimal water quality.

1. Turn off the water supply to the filter unit.
2. Twist the old filter cartridge counter-clockwise to remove it from the filter head.
3. Insert the new filter cartridge into the filter head and twist clockwise until it locks into place.
4. Turn the water supply back on and check for leaks.
5. Reset the Filter Exchange Timer according to the new filter's installation date.

6.2. Cleaning the Tap

Clean the tap regularly with a soft cloth and mild soap. Avoid using abrasive cleaners, harsh chemicals, or

scouring pads, as these can damage the chrome finish.

7. TROUBLESHOOTING

If you experience issues with your GROHE Blue Pure Eurosmart Duo Starter Kit, consider the following:

- **Reduced Water Flow:** Check if the filter needs replacement. Ensure water supply valves are fully open.
- **Leaking:** Verify all connections are tight. Check for damaged O-rings or seals.
- **Unusual Taste/Odor in Filtered Water:** The filter may be exhausted and require replacement. Ensure the filter is correctly installed.

For persistent issues, contact GROHE customer support.

8. SPECIFICATIONS



Figure 4: The GROHE Blue Pure Eurosmart Duo tap, showcasing its C-spout design and chrome finish within a kitchen environment.

Feature	Specification
---------	---------------

Feature	Specification
Brand	GROHE
Model Name	Grohe Blue Pure Eurosmart
Model Number	30383000
Product Dimensions (L x W x H)	4.8" x 4.8" x 18.4"
Item Weight	0.91 Kilograms
Material	Ceramic (Cartridge)
Installation Type	Single Hole
Purification Method	Activated Carbon
Filter Capacity	3000 Liters
Special Feature	Chlorine Reduction
Maximum Flow Rate	12 Liters Per Minute
Upper Temperature Rating	100 Degrees Fahrenheit
Supported Water TDS Level Maximum	500 PPM

9. WARRANTY AND SUPPORT

9.1. Manufacturer's Warranty

This product is covered by a **5-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

9.2. Customer Support

For technical assistance, spare parts, or warranty inquiries, please contact GROHE customer service. Refer to the GROHE official website for current contact information in your region.