

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DEKOPRO](#) /

› [DEKOPRO 158-Piece Tool Set Instruction Manual](#)

## DEKOPRO ewssddf-309

# DEKOPRO 158-Piece General Household Hand Tool Kit

Model: ewssddf-309

Brand: DEKOPRO

## INTRODUCTION

Thank you for choosing the DEKOPRO 158-Piece General Household Hand Tool Kit. This comprehensive tool set is designed to equip you with the essential tools needed for most small repairs and basic DIY projects around your home, garage, or workshop. Crafted from high-quality steel with a high-polish chrome finish, these tools offer strength, durability, and anti-corrosion protection, meeting or exceeding ANSI critical standards.

This manual provides important information on the components, setup, usage, maintenance, and specifications of your new tool set. Please read it thoroughly before using the tools to ensure safe and effective operation.

## PRODUCT OVERVIEW AND COMPONENTS

Your DEKOPRO 158-Piece Tool Set comes neatly organized in a durable plastic toolbox storage case, ensuring all tools are kept in one place for easy access and portability.



Figure 1: The DEKOPRO 158-Piece Tool Set, open and organized within its robust storage case.

### Key Components:

- **Combination Wrenches:** For gripping and turning nuts and bolts.
- **Long Nose Pliers:** Ideal for gripping small objects, bending wire, and other delicate tasks.
- **Polished Quick Release Ratchet:** For efficient tightening and loosening of fasteners with sockets.
- **Adjustable Wrench:** Versatile wrench for various sizes of fasteners.
- **Rip Claw Hammer:** For driving nails and prying objects.
- **Measure Tape Rule:** Essential for accurate measurements.
- **Drive Sockets:** A comprehensive range of sizes for various applications.
- **Screwdrivers & Screwdriver Bits:** Including precision screwdrivers and a wide assortment of bits for different screw types.
- **Hex Key Wrenches (Allen Wrenches):** For hexagonal socket screws.
- **Utility Knife:** For cutting various materials.
- **Wood Screw Assortment Kit:** A small collection of common screws and anchors.
- **Spinner Handle & Socket Adaptors:** For use with screwdriver bits and sockets.




Figure 2: Labeled diagram of the tool set components for easy identification.



Figure 3: A selection of individual tools from the kit, showcasing their design and finish.

## SETUP AND GETTING STARTED

1. **Unpacking:** Carefully remove the tool set from its packaging.
2. **Opening the Case:** Locate the two orange latches on the front of the case. Push them inwards to release the lid. The case will open to reveal tools organized on both sides.
3. **Initial Inspection:** Before first use, inspect all tools for any signs of damage or manufacturing defects. Ensure all 158 pieces are present and securely seated in their designated slots.
4. **Familiarization:** Take a moment to familiarize yourself with the different types of tools and their placement within the case. This will help you quickly locate the right tool for the job.



Figure 4: The compact and durable storage case when closed.

## OPERATING INSTRUCTIONS AND USAGE GUIDELINES

Always prioritize safety when using any tools. Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when necessary.

### General Safety Tips:

- Always select the correct tool for the task at hand.
- Ensure tools are clean and in good condition before use.
- Do not use excessive force; if a tool is not working, re-evaluate the task or tool selection.
- Keep tools out of reach of children.

### Specific Tool Usage:

- **Screwdrivers:** Choose the correct tip (Phillips, flathead, Torx, etc.) and size for the screw head. Apply firm, even pressure while turning to prevent stripping the screw head or damaging the tool.



Figure 5: Proper use of a screwdriver for assembly tasks.

- **Hex Key Wrenches:** Insert the hex key fully into the hexagonal socket. Turn clockwise to tighten and counter-clockwise to loosen.



Figure 6: Using a hex key for tightening components.

- **Ratchet and Sockets:** Select the correct socket size for the fastener. Attach it to the ratchet. Use the directional switch on the ratchet head to set for tightening or loosening.
- **Hammer:** Use the claw end for pulling nails and the flat face for driving nails. Always strike squarely.
- **Pliers:** Use for gripping, bending, or cutting. Ensure a firm grip on the object.
- **Wrenches:** Select the correct size wrench for the nut or bolt. Apply force in the direction of the turn.

- **Cleaning:** After each use, wipe down tools with a clean, dry cloth to remove dirt, grease, and moisture. For stubborn grime, a mild degreaser can be used, followed by thorough drying.
- **Lubrication:** Periodically apply a light coat of machine oil to moving parts of tools like ratchets and pliers to ensure smooth operation and prevent rust.
- **Storage:** Always return tools to their designated slots in the storage case. This keeps them organized, protected from damage, and prevents loss. Store the case in a dry environment to prevent corrosion.
- **Inspection:** Regularly inspect tools for wear, damage, or corrosion. Replace any damaged tools to ensure safety and effectiveness.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Tool feels loose or wobbly.	Worn mechanism or loose fasteners.	Inspect for loose screws; if worn, consider replacement.
Tools are rusting.	Exposure to moisture; improper storage.	Clean rust with a wire brush and rust remover, then apply a protective oil. Store in a dry place.
Screwdriver bits stripping screws.	Incorrect bit size; worn bit; insufficient pressure.	Ensure correct bit size, replace worn bits, apply firm and consistent pressure.
Ratchet mechanism not engaging.	Dirt or debris in mechanism; lack of lubrication.	Clean the ratchet head and apply a small amount of lubricant.

## SPECIFICATIONS

**Brand:** DEKOPRO

**Model Number:** ewssddf-309

**Material:** Stainless Steel

**Color:** Yellow

**Product Dimensions (Case):** 15.7"L x 3.4"W x 11"H

**Item Weight:** 9.74 pounds

**Number of Pieces:** 158

**Water Resistance Level:** Water Resistant

**Power Source:** Hand-powered

**UPC:** 711639924680

## WARRANTY AND SUPPORT

For specific warranty information and details regarding your DEKOPRO 158-Piece Tool Set, please refer to the warranty card included with your purchase or visit the official DEKOPRO website. Keep your proof of purchase for

any warranty claims.

If you encounter any issues or require technical assistance, please contact DEKOPRO customer support through their official channels. You can often find contact information on the product packaging or the brand's website.

For additional resources and product information, you may visit the [DEKOPRO Store on Amazon](#).