

[Manuals.plus](#) /

> [JoySusie](#) /

> JoySusie 500ml Wood Grain Essential Oil Diffuser User Manual (Model A88-Z300005)

JoySusie A88-Z300005

JoySusie 500ml Wood Grain Essential Oil Diffuser User Manual

Model: A88-Z300005

1. INTRODUCTION

Thank you for choosing the JoySusie 500ml Wood Grain Essential Oil Diffuser. This ultrasonic cool mist humidifier is designed to enhance your environment with soothing aromas and comfortable humidity. Featuring a stylish wood grain design, color-changing LED lights, and convenient timer settings with remote control, it is perfect for home or office use. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image 1: JoySusie 500ml Wood Grain Essential Oil Diffuser. This image shows the diffuser in its natural wood grain finish, emitting a fine mist.

2. PRODUCT OVERVIEW

Familiarize yourself with the components of your essential oil diffuser:



Image 2: Labeled diagram of the diffuser components. Key parts include the cover, mist outlet, light ring, MIST button, LIGHT button, DC socket, air intake, drainage outlet, water tank, MAX line, and main body.

Package Contents:

- Essential Oil Diffuser Unit
- Power Adapter
- Remote Control
- User Manual

3. SETUP INSTRUCTIONS

Follow these steps to set up your diffuser for the first time:

1. **Place the Diffuser:** Position the diffuser on a flat, stable surface away from direct sunlight or heat sources.
2. **Remove the Cover:** Gently lift the top cover of the diffuser.
3. **Connect Power:** Plug the power adapter into the DC socket at the bottom of the diffuser, then plug the adapter into a wall outlet.
4. **Add Water:** Fill the water tank with clean tap water up to the MAX line (500ml capacity). Do not overfill.
5. **Add Essential Oil:** Add 5-10 drops of your preferred essential oil directly into the water tank. Adjust the amount based on desired aroma intensity.
6. **Replace the Cover:** Carefully place the top cover back onto the diffuser, ensuring it is securely seated.



1. Lift up the cover



2. Add water



3. Add drops of essential oil (not included)



4. Press button to turn on

Image 3: Visual guide for diffuser setup, illustrating the steps of removing the cover, adding water, adding essential oil, and turning on the device.

Your browser does not support the video tag.

Video 1: An unboxing video demonstrating the contents of the essential oil diffuser package and initial setup steps.

4. OPERATING INSTRUCTIONS

Your JoySusie diffuser can be operated using the buttons on the unit or the included remote control.

4.1. Mist Control

- **Power On/Off:** Press the 'MIST' button once to turn on the mist. Press and hold the 'MIST' button to turn off the mist.
- **Mist Mode:** Short press the 'MIST' button to cycle through mist modes: one beep for high mist, two beeps for low mist.
- **Timer Settings:** Press the 'TIMER' button (on remote) or cycle through the 'MIST' button (on unit) to select 1H, 3H, 6H, or continuous mist.

4.2. LED Light Control

- **Turn On/Off:** Press the 'LIGHT' button once to turn on the LED light. Press and hold the 'LIGHT' button to turn off the light.
- **Change Color:** Short press the 'LIGHT' button to cycle through 7 soothing LED light colors.
- **Light Mode:** Choose between a certain colored light mode or a 7-colored lights cycled mode.



Image 4: The diffuser actively producing a fine, cool mist, demonstrating its primary function.

4.3. Auto Shut-Off Feature

The diffuser is equipped with an automatic shut-off function that activates when the water level is too low, ensuring safety and preventing damage to the unit.

5. MAINTENANCE

Regular cleaning helps maintain optimal performance and extends the lifespan of your diffuser.

5.1. Cleaning the Water Tank

1. Unplug the diffuser from the power outlet.
2. Remove the top cover and empty any remaining water from the tank.

3. Wipe the inside of the water tank with a soft cloth or sponge. For stubborn residue, use a small amount of mild detergent and rinse thoroughly.
4. Ensure the ultrasonic disc (located at the bottom of the water tank) is clean. Gently wipe it with a cotton swab dipped in white vinegar if mineral buildup is present.
5. Rinse the tank thoroughly to remove any detergent or vinegar residue.
6. Wipe the exterior of the diffuser with a soft, dry cloth.

Frequency: Clean the diffuser after every 5-6 uses or every 3-5 days, especially when changing essential oils.

6. TROUBLESHOOTING

If you encounter any issues with your diffuser, please refer to the following table:

Problem	Possible Cause	Solution
No mist or low mist output	Low water level Water over MAX line Ultrasonic disc dirty Cover not properly seated	Add water to MAX line Pour out excess water Clean the ultrasonic disc Ensure cover is securely placed
No power	Power adapter not connected No power from outlet	Check power connection Test outlet with another device
Light not working	Light function off Unit malfunction	Press the 'LIGHT' button Contact customer support
Unusual noise	Insufficient water Unit not on a flat surface	Add water Place on a stable, flat surface

7. SPECIFICATIONS

Feature	Detail
Brand	JoySusie
Model Number	A88-Z300005
Capacity	500 Milliliters
Runtime	Up to 10 hours (low mist)
Coverage Area	Up to 250 Square Feet
Power Source	Corded Electric
Wattage	12 watts
Special Features	Automatic Shut-Off, Cool Mist, Multi-color LED Light, Remote Control
Material	Wood Grain Finish (ABS/PP)
Dimensions (L x W x H)	6.6"L x 6.6"W x 5.75"H
Item Weight	0.51 Kilograms




Image 5: Diagram showing the dimensions of the diffuser, indicating a width of 6.6 inches and a height of 5.75 inches.

8. WARRANTY & SUPPORT

Your JoySusie Essential Oil Diffuser is backed by a 45-day money-back guarantee and a 12-month worry-free warranty. For any product inquiries, technical support, or warranty claims, please contact JoySusie customer service through the retailer where you purchased the product.