

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Yaheetech](#) /
- › [Yaheetech Mobile TV Stand YT-00093701 Instruction Manual](#)

## Yaheetech YT-00093701

# Yaheetech Mobile TV Stand Instruction Manual

Model: YT-00093701

Brand: Yaheetech

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Yaheetech Mobile TV Stand. Designed for flat panel screens ranging from 32 to 75 inches and supporting up to 110 pounds, this stand offers mobility, adjustable viewing angles, and convenient storage. Please read this manual thoroughly before assembly and use to ensure safe and optimal performance.





Figure 1: Yaheetech Mobile TV Stand with a mounted television.

The Yaheetech Mobile TV Stand is equipped with multi-directional locking castors for easy movement and stability, adjustable height and tilt for optimal viewing, and integrated cable management to keep your setup tidy. It also includes multiple shelves for media devices and accessories.

## 2. SAFETY GUIDELINES

---

Adhere to the following safety precautions to prevent injury or damage to the product:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 110 pounds (50 kg) for the TV mount and 22 pounds (10 kg) for each shelf.
- **TV Size:** Ensure your TV is within the recommended size range of 32-75 inches.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern is compatible (100x100mm to 600x400mm).
- **Assembly:** Assemble the stand on a soft, clean surface to prevent scratches. Follow all assembly steps precisely.
- **Stability:** Always lock the wheels when the stand is stationary to prevent accidental movement.
- **Children and Pets:** Keep children and pets away from the stand during assembly and ensure the TV is securely mounted to prevent tipping.
- **Movement:** When moving the stand, ensure the TV is stable and move slowly, especially over uneven surfaces.

### 3. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts are present and undamaged. Refer to the detailed parts list provided in the official PDF installation manual for a complete inventory.

You can access the official installation manual [here](#).

### 4. ASSEMBLY INSTRUCTIONS

For detailed, step-by-step assembly instructions, please refer to the official PDF installation manual linked above. The following provides a general overview of the assembly process.

#### 4.1. Base Assembly

Attach the support columns to the base frame, ensuring all screws are tightened securely. Install the universal wheels onto the base, making sure the locking wheels are positioned as desired for easy access.



Figure 2: Key components and features of the TV stand.

#### 4.2. Shelf Installation

The two main shelves and the top tray are adjustable. Position them at your desired height along the support columns. Ensure they are level and securely fastened. The non-slip large trays provide stable surfaces for your devices.

### 4.3. TV Mount Attachment

Attach the TV mounting brackets to the rear of your television using the appropriate screws and spacers provided. Ensure the VESA pattern on your TV matches the compatible patterns of the mount. The mount supports VESA patterns from 100x100mm to 600x400mm.




Figure 3: VESA compatibility and TV screw selection guide.

### 4.4. Mounting the TV

Carefully lift your TV and hook the mounted brackets onto the TV stand's main mounting plate. Secure the TV in place using the safety screws or locking mechanisms to prevent accidental dislodgement. Ensure the TV is centered and stable.


## 5. OPERATION

## 5.1. Height Adjustment

The TV mount plate can be adjusted in height from 43.3 inches to 63 inches (from the ground). To adjust, loosen the securing bolts on the main columns, carefully raise or lower the TV to the desired height, and then re-tighten the bolts firmly. Ensure both sides are adjusted equally.

## 5.2. Tilt Adjustment

The TV mount allows for a tilt adjustment of up to  $\pm 13$  degrees. To adjust the tilt, loosen the tilt adjustment knobs on the side of the TV mount, angle the TV to your preferred viewing position, and then tighten the knobs to secure it.






Figure 4: TV tilt adjustment mechanism.

### **5.3. Mobility and Locking Wheels**

The stand features four 360° swivel castors for easy movement. Two of these wheels are equipped with brakes. To move the stand, unlock the braked wheels. To secure the stand in a stationary position, press down on the brake levers on the two locking wheels until they click into place.



Figure 5: Engaging the wheel lock for stability.

#### 5.4. Cable Management

The main support columns are designed with hollow sections for cable management. Route your TV and device cables through these hollow tubes to maintain a clean and organized appearance, preventing tangles and potential hazards.

# Cable Management

Keep your devices and cables in order



Figure 6: Cable management through the stand's columns.

## 6. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspections:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Wheel Care:** Keep the wheels free of debris to ensure smooth movement.

## 7. TROUBLESHOOTING

**Issue: Stand is unstable or wobbles.**

**Solution:** Ensure all assembly screws are fully tightened. Verify the TV is securely mounted and centered. Check that the floor surface is level. If moving, ensure wheels are locked when stationary.

**Issue: Wheels do not roll smoothly or lock properly.**

**Solution:** Check for any debris or obstructions in the wheels. Ensure the brake levers are fully engaged or disengaged. Clean the wheels if necessary.

**Issue: TV cannot be tilted or adjusted for height.**

**Solution:** Loosen the adjustment knobs/bolts sufficiently before attempting to adjust. Ensure no cables are obstructing movement. Re-tighten after adjustment.

## 8. SPECIFICATIONS

---

| Feature                    | Detail                         |
|----------------------------|--------------------------------|
| Model Number               | YT-00093701                    |
| Compatible TV Sizes        | 32-75 inches                   |
| Maximum TV Weight Capacity | 110 lbs (50 kg)                |
| VESA Compatibility         | 100x100mm to 600x400mm         |
| Height Adjustment Range    | 43.3 - 63 inches (from ground) |
| Tilt Angle                 | ±13 degrees                    |
| Shelf Weight Capacity      | 22 lbs (10 kg) per shelf       |
| Material                   | Alloy Steel                    |
| Color                      | Black                          |
| Product Dimensions         | 35.04 x 25.98 x 77.36 inches   |
| Item Weight                | 33.3 pounds                    |




Figure 7: Product dimensions overview.

## 9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Yaheetech customer service or visit the official Yaheetech store on Amazon:

[Visit the Yaheetech Store](#)

Please retain your purchase receipt for warranty claims.

## 10. ADDITIONAL RESOURCES

While no official seller videos were provided in the product data, you may find additional visual guides or tips by searching for 'Yaheetech Mobile TV Stand assembly' on video platforms. Always refer to this manual and the official PDF for accurate product information.





Figure 8: The mobile TV stand in a home environment.



Figure 9: The mobile TV stand in a professional office environment.

## Related Documents - YT-00093701


|   |   |
|---|---|
|    | <p><a href="#">Yaheetech Adjustable Mobile TV Stand Assembly Instructions</a></p> <p>Assembly instructions for the Yaheetech adjustable mobile TV stand (Model # 610856). Includes a parts list and step-by-step assembly guide.</p>  |
|    | <p><a href="#">Yaheetech 592071 Mobile TV Stand Assembly Instructions</a></p> <p>Comprehensive assembly guide for the Yaheetech 592071 mobile TV stand. Includes a detailed parts list, safety warnings, step-by-step installation instructions with textual descriptions of diagrams, and support contact information.</p> |
|  | <p><a href="#">Yaheetech 615158 Kitchen Island Cart Assembly Instructions</a></p> <p>Detailed assembly guide for the Yaheetech 615158 Kitchen Island Cart on Wheels. Includes parts list, step-by-step instructions, and care information.</p>  |
|  | <p><a href="#">Yaheetech 592567 Rolling Cart Assembly Instructions</a></p> <p>Comprehensive assembly guide for the Yaheetech 592567 rolling cart. Includes a detailed parts list, step-by-step instructions with visual descriptions, and essential safety information for a smooth setup.</p>                              |
|  | <p><a href="#">Yaheetech 614187 Kitchen Cart Assembly Instructions</a></p> <p>Comprehensive assembly guide for the Yaheetech 614187 Kitchen Cart on Wheels, detailing all parts, hardware, and step-by-step instructions for proper assembly.</p>   |



[Yaheetech 615109 Kitchen Island Cart Assembly and Care Instructions](#)

Comprehensive installation manual and care guide for the Yaheetech 615109 Kitchen Island Cart. Includes parts list, step-by-step assembly instructions, safety warnings, and maintenance tips.

Documents - Yaheetech – YT-00093701



[\[pdf\] User Manual](#)

611001EN cdr Administrator Yaheetech Mobile TV Stand Adjustable Rolling Cart w Locking Wheels for 32 75 LCD LED Plasma Flat Panel Screen up to 110LB Portable Flexible Laptop Shelf Max VESA 600x400 YT 00093701 Installation Manual B1MYsjFSPES m media amazon images I |||

... lang: score:20 filesize: 3.43 M page\_count: 8 document date: 2020-03-23